

[Manuals.plus](#) /

› [LEGO](#) /

› [LEGO NINJAGO Nya's Samurai X MECH Action Figure, 71775 Robot Ninja Toy with Golden Jay Plus 7 Minifigures Standard Packaging](#)

LEGO 71775

LEGO NINJAGO Nya's Samurai X MECH (71775) Instruction Manual

MODEL: 71775

INTRODUCTION

The LEGO NINJAGO Nya's Samurai X MECH (71775) playset allows builders aged 10 and up to relive thrilling action from the NINJAGO: Crystallized TV series. This impressive mech features posable knees, arms, legs, and hips, along with two swords, two spring-loaded shooters, and a cockpit designed for Nya. The set also includes an array of exclusive LEGO NINJAGO minifigures and a Crystal Beast build, offering extensive play possibilities.

WHAT'S IN THE BOX

Your LEGO NINJAGO Nya's Samurai X MECH set contains the following:

- LEGO Building Elements (1,003 pieces)
- 8 LEGO NINJAGO Minifigures: Samurai X Nya, Golden Jay, Master Wu, Oni Garmadon, Lil' Nelson, General Pythor, The Mechanic, and Vengestone Warrior
- Instruction Manuals



The complete LEGO NINJAGO Nya's Samurai X MECH set, including the box, assembled mech, Crystal Beast, and all minifigures.

KEY FEATURES

- Posable Samurai X Mech action figure with articulated knees, arms, legs, and hips.
- Equipped with 2 swords and 2 spring-loaded shooters for dynamic play.
- Features a minifigure cockpit for Samurai X Nya.
- Includes 8 unique NINJAGO minifigures, many of which are exclusive to this set.
- Stands over 12.5 inches (32 cm) tall, making it an impressive display piece.

SETUP

Follow these steps to assemble your LEGO NINJAGO Nya's Samurai X MECH:

1. **Unpack Components:** Carefully open the box and sort all LEGO building elements. It is recommended to sort pieces by color and type to facilitate the building process.
2. **Access Digital Instructions:** For an enhanced building experience, download the free LEGO Building Instructions app on your smartphone or tablet. The app provides interactive zoom and rotate tools to help visualize the model during construction.
3. **Follow Step-by-Step Guide:** Begin assembly by following the detailed instructions provided in the physical manual or the digital app. Ensure each piece is securely connected.
4. **Assemble Minifigures:** Construct the 8 minifigures according to the instructions.



A child assembling the LEGO NINJAGO Nya's Samurai X MECH, demonstrating the sorting of pieces before construction.

OPERATING

Once assembled, the Nya's Samurai X MECH offers dynamic play features:

- **Poseability:** Utilize the articulated knees, arms, legs, and hips to create various action poses for the mech.

- **Spring-Loaded Shooters:** Load the two spring-loaded shooters located on the mech's arms with the provided projectiles. Press the trigger mechanism to fire.
- **Minifigure Cockpit:** Open the cockpit to place Samurai X Nya inside, ready to pilot the mech into battle.
- **Crystal Beast Interaction:** Engage the Samurai X MECH in battles against the included Crystal Beast, which also features posable limbs for dynamic encounters.



The Nya's Samurai X MECH in an action pose, ready for battle alongside the included minifigures.

Official video showcasing the LEGO NINJAGO Nya's Samurai X MECH in action, highlighting its features and play potential.

Official video demonstrating the various features and play scenarios of the LEGO NINJAGO Nya's Samurai X MECH.

MAINTENANCE

To ensure the longevity and cleanliness of your LEGO set:

- **Cleaning:** Use a soft brush or a damp cloth with mild soap to gently clean any dust or dirt from the bricks.

Avoid harsh chemicals or abrasive materials.

- **Drying:** Air dry all pieces thoroughly before reassembling or storing to prevent water damage.
- **Storage:** Store the set in a cool, dry place away from direct sunlight or extreme temperatures, which can cause discoloration or warping of the plastic.

TROUBLESHOOTING

- **Missing Pieces:** If you find any missing pieces, please contact LEGO Customer Service directly through their official website.
- **Assembly Difficulties:** Double-check the instruction manual or the digital app for any missed steps. Sometimes, a small misplacement can affect subsequent steps.
- **Loose Connections:** If parts feel loose, ensure they are pushed together firmly. For persistent issues, try disassembling and reassembling the specific section.

SPECIFICATIONS

- **Model Number:** 71775
- **Product Dimensions:** 18.9 x 14.88 x 2.78 inches
- **Item Weight:** 15.8 ounces
- **Manufacturer Recommended Age:** 10 years and up



A detailed view of the assembled mech, highlighting its intricate design and the recommended age/piece count.

WARRANTY & SUPPORT

For information regarding product warranty or additional support, please refer to the official LEGO website or contact their customer service department. Specific warranty details may vary by region and purchase location.