

[Manuals.plus](#) /

> [ODK](#) /

> ODK 4-Drawer Fabric Dresser Instruction Manual (Model 0414ZVSMHOS)

ODK 0414ZVSMHOS

ODK 4-Drawer Fabric Dresser Instruction Manual

Model: 0414ZVSMHOS

1. PRODUCT OVERVIEW

The ODK 4-Drawer Fabric Dresser is designed for efficient storage in small spaces, such as bedrooms, closets, or entryways. It features a sturdy steel frame, a durable wooden top, and four fabric drawers. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your dresser.





Image 1.1: The ODK 4-Drawer Fabric Dresser in Dark Grey, featuring a wooden top and four fabric drawers.

Dimensions:



Dimension



Image 1.2: Detailed dimensions of the dresser. Overall: 15.7"D x 11.7"W x 31.6"H. Each drawer is approximately 14.4" wide and 6.9" high.

- **Overall Dimensions:** 15.7" (Depth) x 11.7" (Width) x 31.6" (Height)
- **Drawer Dimensions:** Approximately 14.4" (Width) x 10.8" (Depth) x 6.9" (Height)
- **Weight:** 11.66 pounds

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.

- Do not overload drawers. Distribute weight evenly to maintain stability.
- For added stability, especially in households with children, consider anchoring the dresser to a wall using appropriate anti-tip hardware (not included unless specified).
- Do not climb on or stand on the dresser.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

Part	Description	Quantity
A	Top Wooden Board	1
B	Steel Frame (Side Panels)	2
C	Steel Frame (Back X-Crossbar)	1
D	Fabric Drawers	4
E	Drawer Handles	4
F	Adjustable Feet	4
G	Assembly Hardware (Screws, Allen Wrench)	1 Set

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your ODK 4-Drawer Fabric Dresser. Assembly is designed to be straightforward.

1. **Prepare the Area:** Unpack all components and lay them out on a clean, soft surface to prevent damage. Identify all parts against the package contents list.
2. **Assemble the Steel Frame:** Connect the side panels of the steel frame using the provided hardware. Ensure all connections are secure but do not fully tighten screws until the frame is complete.
3. **Attach the X-Crossbar:** Secure the X-crossbar to the back of the steel frame. This component enhances stability. Fully tighten all frame screws once the X-crossbar is in place.



Image 4.1: The X-crossbar provides enhanced stability to the dresser frame.

4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the steel frame. These feet help stabilize the dresser on uneven surfaces.



Image 4.2: Adjustable feet allow for leveling the dresser on uneven floors.

5. **Place the Wooden Top:** Carefully place the wooden top onto the assembled steel frame. Ensure it is aligned correctly.
6. **Assemble Drawers:** Unfold each fabric drawer. Insert the bottom support panel into the base of each drawer.
7. **Attach Drawer Handles:** Secure the handles to the front of each fabric drawer using the provided screws.



Image 4.3: A close-up view of the ergonomic drawer handle.

8. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the steel frame.

5. USAGE

The ODK 4-Drawer Fabric Dresser is designed for organizing various items in your home.

- Use the drawers to store clothing, linens, toys, accessories, or other household items.
- The wooden top surface can be used to display decorative items, lamps, or store frequently accessed items.
- Adjust the feet as needed to ensure the dresser is level and stable on your floor.



Image 5.1: The dresser with drawers partially open, demonstrating its storage capacity for various items.

Storage Capacity:

Each drawer offers ample space for your belongings. For example, the dresser can hold:

- Over 20 small toys
- Over 150 pairs of socks
- Over 30 pairs of pants
- Over 50 T-shirts

6. CARE AND MAINTENANCE

Proper care will help maintain the appearance and functionality of your dresser.

- **Cleaning:** Wipe the wooden top and steel frame with a dry cloth. For fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry. Avoid harsh chemicals.

- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Placement:** Avoid placing the dresser in direct sunlight or near heat sources to prevent material degradation.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dresser is wobbly/unstable	Uneven floor; loose screws	Adjust the leveling feet at the bottom of the frame. Ensure all assembly screws are tightened.
Drawers do not slide smoothly	Drawer not fully assembled; overloaded drawer; obstruction	Ensure the bottom support panel is correctly inserted in the drawer. Reduce drawer contents. Check for any items obstructing the drawer path.
Missing parts during assembly	Packaging oversight	Contact ODK customer service immediately for replacement parts.

8. SPECIFICATIONS

- **Brand:** ODK
- **Model Name:** Dresser
- **Item Model Number:** 0414ZVSMHOS
- **Product Dimensions:** 15.7"D x 11.7"W x 31.6"H
- **Color:** Dark Grey
- **Room Type:** Bedroom
- **Item Weight:** 11.66 Pounds
- **Assembly Required:** Yes
- **Number of Pieces:** 1 (dresser unit)
- **UPC:** 850038294441

9. WARRANTY AND CUSTOMER SUPPORT

ODK provides a limited warranty for this product. For specific warranty details, please refer to the documentation included with your purchase or contact customer service.

We offer lifetime customer service and 24/7 support for installation assistance and quick replacements for quality issues. If you have any questions, concerns, or require assistance, please do not hesitate to contact us through the retailer's platform or ODK's official support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09XWSR5WM>

More documents and user manuals: <https://manuals.plus/>