

[Manuals.plus](#) /

› [XDOBO](#) /

› XDOBO Draco Mini Bluetooth Speaker User Manual

XDOBO Draco Mini

XDOBO Draco Mini Bluetooth Speaker User Manual

Model: Draco Mini

1. INTRODUCTION

Thank you for choosing the XDOBO Draco Mini Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully before use to ensure optimal performance and longevity of your device.



Image 1.1: Top view of the XDOBO Draco Mini Bluetooth Speaker, showing the power, volume, and play/pause controls.

2. SETUP

2.1 Initial Charging

Before first use, fully charge the speaker. Connect the provided USB cable to the speaker's charging port and a compatible USB power adapter (not included). The charging indicator light will show the charging status.

2.2 Power On/Off

- To power on: Press and hold the power button () for 2-3 seconds until you hear an audible prompt.
- To power off: Press and hold the power button () for 2-3 seconds until the speaker shuts down.

2.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "XDOBO Draco Mini" from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will become solid.



Image 2.1: The XDOBO Draco Mini speaker maintaining a stable Bluetooth 5.0 connection with a mobile device.

2.4 True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two XDOBO Draco Mini speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one of the speakers, double-press the power button (). It will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. You will hear a confirmation tone once TWS pairing is successful.
4. Now, connect your device to one of the speakers via Bluetooth as described in Section 2.3. Both speakers will play audio in stereo.

True Wireless Stereo

Connect two Draco Mini speakers to get stereo sound.



Image 2.2: Two XDOBO Draco Mini speakers wirelessly connected to provide a True Wireless Stereo sound experience.

3. OPERATING

3.1 Basic Controls

- **Play/Pause:** Short press the Play/Pause button (▶).
- **Volume Up:** Short press the Volume Up button (⬆).
- **Volume Down:** Short press the Volume Down button (⬇).
- **Next Track:** Long press the Volume Up button (⬆).
- **Previous Track:** Long press the Volume Down button (⬇).

3.2 Voice Assistant

The XDOBO Draco Mini supports voice assistant activation:

- Short press the Voice Assistant button (often indicated by a microphone icon or the Play/Pause button on some models) to activate the voice assistant on your connected Bluetooth device.

- Speak your command through the speaker's microphone.




Image 3.1: Activating the voice assistant on a connected device through the XDOBO Draco Mini speaker.

3.3 Connectivity Options

In addition to Bluetooth, the speaker supports other connectivity methods:

- **Auxiliary Input:** Connect devices via a 3.5mm audio cable to the AUX port.
- **USB Playback:** Insert a USB drive with audio files into the USB port for direct playback.

4. MAINTENANCE

4.1 Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as they may damage the surface.

4.2 Water Resistance (IPX6)

The XDOBO Draco Mini is IPX6 water-resistant, meaning it can withstand powerful water jets. It is suitable for outdoor use and can handle splashes or light rain. **Do not submerge the speaker in water.** Ensure the charging port cover is securely closed to maintain water resistance.



Image 4.1: The XDOBO Draco Mini speaker demonstrating its IPX6 water resistance against splashes.

4.3 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its health.

5. TROUBLESHOOTING

- **Speaker does not power on:** Ensure the battery is charged. Connect the speaker to a power source and try again.
- **No sound:** Check the volume level on both the speaker and your connected device. Ensure the speaker is correctly paired via Bluetooth or connected via AUX/USB.
- **Bluetooth pairing issues:** Make sure the speaker is in pairing mode. Turn off Bluetooth on your device and turn it back on. Clear previous pairings from your device's Bluetooth list and try pairing again. Move the speaker closer to your device.
- **TWS pairing issues:** Ensure both speakers are fully charged and not connected to any other Bluetooth device before attempting TWS pairing.

- **Poor sound quality:** Ensure the speaker is within Bluetooth range. Check for interference from other wireless devices. Try playing different audio sources.

6. SPECIFICATIONS

Feature	Specification
Model	Draco Mini
Bluetooth Version	5.0
Output Power	15 Watts
Battery Life	Up to 18 Hours (varies by volume level and audio content)
Water Resistance	IPX6
Connectivity	Bluetooth, Auxiliary (AUX), USB
Dimensions (L x W x H)	12 x 18 x 7 cm (approx.)
Power Source	Battery

Playing Time Up to 24 Hours

(varies by volume level and audio content)



Image 6.1: The XDOBO Draco Mini speaker highlighting its extended battery life, which can vary based on usage.

7. WARRANTY AND SUPPORT

XDOBO products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official XDOBO website. Keep your proof of purchase for any warranty claims.

For technical assistance or inquiries, please contact XDOBO customer service through the contact information provided on the official website or your retailer's support channels.

© 2023 XDOBO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question