

[Manuals.plus](#) /

› [Relaxdays](#) /

› Relaxdays Folding Metal Sawhorse with Chainsaw Holder, Model 10039935

Relaxdays 10039935

Relaxdays Folding Metal Sawhorse with Chainsaw Holder

Model: 10039935

Brand: Relaxdays

INTRODUCTION

This manual provides instructions for the safe and efficient use of your Relaxdays Folding Metal Sawhorse with Chainsaw Holder. Please read all instructions carefully before assembly and operation to ensure proper use and safety.

- **Efficient:** Practical sawhorse with chainsaw holder for safe and quick wood cutting.
- **Secure:** Clamping support for chainsaws of all types. Features a red chain guard for guide bars up to 45 cm.
- **Maximum Load:** Sturdy metal sawhorse designed for logs up to 120 kg. Equipped with round feet for stable support.
- **Practical:** Foldable design for easy storage. Includes an adjustable measuring rod for precise cutting lengths. Ergonomic design promotes back-friendly work.
- **Details:** Suitable for wood up to a maximum of 180 cm in length and 20 cm in diameter. Overall dimensions (Height x Width x Depth): approximately 86 x 88 x 73 cm.

SETUP INSTRUCTIONS

Follow these steps to assemble your sawhorse:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not provided in this manual, refer to original packaging).
2. **Assemble Main Frame:** Connect the main frame sections using the provided bolts and nuts. Ensure all connections are finger-tight initially.
3. **Attach Chainsaw Holder and Chain Guard:** Secure the chainsaw holder mechanism and the red chain guard to the designated points on the frame.

4. **Secure All Connections:** Once the frame and attachments are in place, fully tighten all bolts and nuts with appropriate tools. Do not overtighten.
5. **Verify Stability:** Before use, ensure the sawhorse is stable and all parts are securely fastened.




Figure 1: Sawhorse folding and unfolding stages.



Figure 2: Detail of bolts and stable feet.

OPERATING INSTRUCTIONS

Always prioritize safety when operating the sawhorse with a chainsaw. Wear appropriate personal protective equipment (PPE) including safety glasses, gloves, and hearing protection.

1. **Placement:** Place the sawhorse on a firm, level, and non-slip surface. Ensure there is ample clear space around the sawhorse for safe operation.
2. **Chainsaw Mounting:** Securely clamp your chainsaw into the designated holder. Ensure the chainsaw is stable and cannot move during operation. The holder is designed to accommodate various chainsaw types.
3. **Log Positioning:** Place the log to be cut onto the sawhorse. Ensure the log is stable and balanced.
4. **Adjust Cutting Length:** Utilize the integrated measuring rod to mark or estimate your desired cutting lengths on the log.
5. **Chain Guard:** Ensure the red chain guard is properly positioned to protect the chainsaw bar and chain when not actively cutting.
6. **Safe Operation:** Operate the chainsaw according to its manufacturer's instructions. Maintain a firm grip on the

chainsaw handles and keep a safe distance from the cutting area. Never force the chainsaw.



Figure 3: Safe operation with chainsaw and log.




Figure 4: Chainsaw holder mechanism detail.




Figure 5: Adjustable measuring bar.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your sawhorse.

- **Cleaning:** After each use, clean the sawhorse to remove sawdust, debris, and sap. Use a damp cloth and mild detergent if necessary. Dry thoroughly.
- **Inspection:** Periodically inspect all bolts, nuts, and joints for tightness. Tighten any loose fasteners. Check for any signs of damage, wear, or corrosion.
- **Storage:** Store the sawhorse in a dry, protected area to prevent rust and damage. The foldable design allows for compact storage.

TROUBLESHOOTING

If you encounter issues with your sawhorse, refer to the following common solutions:

- **Stability Issues:** If the sawhorse feels unstable, re-check all assembly bolts and nuts to ensure they are securely tightened. Ensure the sawhorse is placed on a flat, even surface.
- **Chainsaw Not Fitting:** Verify that your chainsaw's dimensions are compatible with the holder's specifications. Ensure the clamping mechanism is correctly adjusted.
- **Difficulty Folding/Unfolding:** Check for any obstructions, bent parts, or debris that might be hindering the folding mechanism. Apply a small amount of lubricant to moving joints if necessary.

SPECIFICATIONS

Feature	Specification
Brand	Relaxdays
Model Number	10039935
Material	100% Steel
Overall Dimensions (H x W x D)	Approx. 86 x 88 x 73 cm
Weight	Approx. 10.9 kg
Maximum Load Capacity	120 kg
Maximum Wood Length	180 cm
Maximum Wood Diameter	20 cm
Chain Guide Length (for guard)	Up to 45 cm



Figure 6: Sawhorse dimensions.

WARRANTY INFORMATION

Specific warranty details are not provided within this instruction manual. For information regarding product warranty, please refer to the original product packaging, purchase documentation, or contact Relaxdays customer service directly.

CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your Relaxdays Folding Metal Sawhorse, please contact Relaxdays customer support. Contact information can typically be found on the product packaging or the official Relaxdays website.

You may also find additional safety information in the provided PDF document [Safety Information \(PDF\)](#).

