Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iDance BLASTER B2X

iDance BLASTER B2X Wireless Bluetooth Speaker Instruction Manual

Model: BLASTER B2X

1. Introduction

Thank you for purchasing the iDance BLASTER B2X Wireless Bluetooth Speaker. This portable speaker is designed to deliver powerful sound with dynamic disco LED lighting, making it ideal for parties and gatherings. It features Bluetooth connectivity, a USB/MP3 player, FM radio, and a karaoke function. Please read this manual carefully to ensure proper use and to maximize your enjoyment of the product.

2. Safety Information

- Do not expose the device to water, moisture, or extreme temperatures.
- Avoid direct sunlight and heat sources.
- Do not disassemble, repair, or modify the unit. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Use only the provided USB charging cable. Ensure your charger is 5V1A (not included).
- Do not block ventilation openings.

3. Package Contents

Ensure all items are present in the box:

- iDance BLASTER B2X Speaker
- USB Charging Cable (for connecting to a 5V1A charger, not included)
- Instruction Manual (this document)

4. Product Overview

Front View



The front of the speaker features two large woofers with integrated disco LED rings, protected by a metal grille.


Top Panel Controls



The top panel includes power, mode, playback, volume controls, and a dedicated LED button. It also features a dock for smartphones or tablets.

Rear Panel Ports


NO
OFF
DC 5V
TF
USB
AUX



The rear panel houses the power switch, USB port for media playback, and the charging input.

5. Setup

5.1 Initial Charging

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a 5V1A USB power adapter (not included). The charging indicator will show the charging status.



The speaker offers 4-8 hours of play time on a full charge.

5.2 Powering On/Off

Locate the power switch on the rear panel of the speaker. Slide it to the 'ON' position to power on the device. Slide it to the 'OFF' position to power off.

6. Operating Instructions

6.1 Bluetooth Pairing

1. Power on the BLASTER B2X speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "BLASTER B2X" from the list of devices.
4. Once paired, the speaker will emit a confirmation sound, and the LED will stop flashing. You can now play audio from your device.

6.2 USB/TF Card Playback

1. Insert a USB flash drive or TF (Micro SD) card into the corresponding port on the speaker.
2. The speaker will automatically switch to USB/TF card mode and begin playing MP3 files.
3. Use the playback controls (Play/Pause, Next/Previous Track) on the top panel to manage your music.



Supports USB and TF card for MP3 playback.

6.3 FM Radio

1. Press the 'M' (Mode) button on the top panel to switch to FM radio mode.
2. Press and hold the Play/Pause button to automatically scan and save available FM stations.

3. Use the Next/Previous Track buttons to navigate between saved stations.

6.4 Karaoke Function

The BLASTER B2X is karaoke-ready. Connect a microphone (not included) to the microphone input port. Adjust the microphone volume and echo effect using the dedicated controls if available (refer to product diagram for specific controls).



Enjoy singing along with your favorite tracks. Compatible with YouTube, Spotify, and most karaoke applications.

6.5 Wireless Audio Sharing (TWS)

You can connect two BLASTER B2X speakers wirelessly for a stereo sound experience.

1. Ensure both BLASTER B2X speakers are powered on and in Bluetooth mode, but not yet paired with any device.
2. On one of the speakers, double-tap the 'SHARING' button (if available, otherwise refer to the manual's specific TWS pairing instructions). The speakers will attempt to connect to each other.
3. Once connected, one speaker will act as the master. Pair your mobile device to this master speaker via Bluetooth as described in section 6.1.
4. Both speakers will now play audio simultaneously.

6.6 Disco LED Lighting

The speaker features dynamic disco LED rings. Press the 'LED' button on the top panel to cycle through different lighting modes or to turn the lights off.

7. Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Avoid dropping the speaker or subjecting it to strong impacts.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB cable and a 5V1A adapter.
No sound from the speaker.	Volume is too low or muted. Device not properly connected.	Increase volume on both the speaker and your connected device. Re-pair Bluetooth or re-insert USB/TF card.
Bluetooth pairing fails.	Speaker is not in pairing mode. Device is too far. Interference.	Ensure speaker is in pairing mode. Move device closer to speaker. Turn off other Bluetooth devices.
LED lights are not working.	LED mode is off or selected mode has no lights.	Press the 'LED' button to cycle through different lighting modes.

9. Specifications

- **Brand:** iDance
- **Model Number:** BLASTER B2X
- **Output Wattage:** 100 Watts
- **Connectivity Technology:** Bluetooth, AUX, USB
- **Compatible Devices:** Smartphones, Tablets, USB drives, TF cards
- **Power Source:** Battery Powered
- **Battery Life:** 4-8 hours
- **Material:** ABS Plastic
- **Color:** Black
- **Item Dimensions (L x W x H):** 15 x 16 x 29 centimeters
- **Frequency Response:** 20000 Hz
- **Impedance:** 4 Ohms
- **Mounting Type:** Floor Mount
- **UPC:** 886898020463

10. Warranty and Support

The iDance BLASTER B2X speaker comes with a **2-year manufacturer warranty**. Please retain your proof of purchase for warranty claims.
For technical support or warranty inquiries, please refer to the contact information provided on the iDance official website or your retailer's support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Y1QKN44

More documents and user manuals: **https://manuals.plus/**