

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bitty Boomers](#) /
- › [Bitty Boomers Star Wars: The Mandalorian - Grogu in Pram - Mini Bluetooth Speaker User Manual](#)

Bitty Boomers BITTYGROGUPRAM

Bitty Boomers Star Wars: The Mandalorian - Grogu in Pram - Mini Bluetooth Speaker User Manual

Model: BITTYGROGUPRAM

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Bitty Boomers Star Wars: The Mandalorian - Grogu in Pram Mini Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.

The Bitty Boomers speaker is an ultra-portable audio device designed for wireless connectivity with Bluetooth-enabled devices. It offers over 4 hours of music playback on a single charge and features the ability to connect two Bitty Boomers for a true wireless stereo experience, as well as a selfie remote function.



Figure 1: Front view of the Bitty Boomers Grogu in Pram Mini Bluetooth Speaker.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Bitty Boomers Grogu in Pram Mini Bluetooth Speaker
- Micro USB Charging Cable
- Lanyard/Backpack Clip



Figure 2: The Bitty Boomers Grogu in Pram speaker shown in its retail packaging.

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge your Bitty Boomers speaker. A full charge provides over 4 hours of music playback.

1. Locate the Micro USB charging port on the back of the speaker.
2. Connect the supplied Micro USB cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator will illuminate during charging and turn off when fully charged.



Figure 3: Rear view of the speaker, highlighting the Micro USB charging port.

3.2 Powering On/Off

- To power on: Press and hold the power button (usually located on the bottom or back) until you hear an audible cue and the LED indicator lights up.
- To power off: Press and hold the power button again until you hear an audible cue and the LED indicator turns off.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

The speaker uses Bluetooth 5.0 technology for wireless connection.

1. Ensure the speaker is powered on and within 30 feet (9 meters) of your Bluetooth-enabled device.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light.
3. On your device (smartphone, tablet, computer), go to the Bluetooth settings and search for available devices.
4. Select "Bitty Boomers" from the list.

5. Once paired, the LED indicator will stop flashing and remain solid, and you will hear a confirmation tone.



Figure 4: Front view of the speaker, ready for use.

4.2 True Wireless Stereo (TWS) Pairing (Optional)

You can connect two Bitty Boomers speakers together for a stereo sound experience.

1. Ensure both Bitty Boomers speakers are powered off.
2. Power on both speakers simultaneously. They will enter pairing mode.
3. Double-press the power button on one of the speakers. It will search for the other speaker.
4. Once connected, you will hear a confirmation tone, and the LED indicators on both speakers will change to a solid light.
5. Now, connect your device to one of the paired Bitty Boomers speakers via Bluetooth as described in section 4.1. Both speakers will play audio in stereo.

4.3 Selfie Remote Function

When connected to your smartphone via Bluetooth, the Bitty Boomers speaker can act as a remote shutter for your phone's camera.

- Open your smartphone's camera application.
- Press the power button on the Bitty Boomers speaker once to trigger the camera shutter.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use liquid cleaners or aerosols.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly,

even if not in use for extended periods.

- **Water Resistance:** This product is water resistant, not waterproof. Avoid submerging it in water or exposing it to heavy rain.

6. TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source using the Micro USB cable.
Cannot pair with Bluetooth device.	<ul style="list-style-type: none">◦ Ensure the speaker is in pairing mode (flashing LED).◦ Make sure Bluetooth is enabled on your device.◦ Move the speaker closer to your device (within 30 feet).◦ Turn off and on both the speaker and your device's Bluetooth.◦ Forget "Bitty Boomers" from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">◦ Increase the volume on both the speaker and your connected device.◦ Ensure the speaker is properly paired.◦ Check if the audio source is playing.
True Wireless Stereo (TWS) pairing fails.	<ul style="list-style-type: none">◦ Ensure both speakers are Bitty Boomers and are powered off before attempting TWS pairing.◦ Make sure they are close to each other during the pairing process.◦ Try repeating the TWS pairing steps carefully.

7. SPECIFICATIONS

Model Name:	Bitty Boomers Star Wars: The Mandalorian - Grogu in Pram
Model Number:	BITTYGROGUPRAM
Connectivity Technology:	Bluetooth 5.0, USB
Wireless Range:	Up to 30 feet (9 meters)
Battery Life:	Over 4 hours of music play on a single charge
Speaker Size:	2 inches
Speaker Maximum Output Power:	5 Watts
Audio Output Mode:	Mono (Stereo with TWS pairing)
Power Source:	Battery Powered (Rechargeable via Micro USB)
Product Dimensions:	2"D x 3"W x 5"H (approximate)
Item Weight:	3 Ounces
Material:	Plastic

Special Features:	True Wireless Stereo (TWS) pairing, Selfie Remote Function, Backpack Clip/Strap included
Water Resistance Level:	Water Resistant

8. WARRANTY INFORMATION

This Bitty Boomers speaker comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and claims process, please refer to the warranty card included with your product or contact Bitty Boomers customer support.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Bitty Boomers product, please visit the official Bitty Boomers website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.



© 2024 Bitty Boomers. All rights reserved. Star Wars and related properties are trademarks and/or copyrights in the United States and other countries, of Lucasfilm Ltd. and/or its affiliates.