

[Manuals.plus](#) /

› [VOLTRX](#) /

› VOLTRX Premium Electric Protein Shaker Bottle User Manual

VOLTRX VortexBoost Electric Protein Shaker (Model ARB-002)

VOLTRX VortexBoost Electric Protein Shaker Bottle User Manual

Model: ARB-002

PRODUCT OVERVIEW

The VOLTRX VortexBoost Electric Protein Shaker Bottle is designed for efficient and clump-free mixing of protein shakes and other powdered supplements. Featuring a powerful motor and a vibrant light-up base, it provides a smooth mixing experience. The bottle is constructed from durable Tritan material, ensuring it is BPA-free, shatter-resistant, and wear-resistant. Its advanced IPX5 waterproof body allows for easy cleaning.





Image: VOLTRX VortexBoost Electric Protein Shaker Bottle in Sakura Pink, showing the powerful vortex mixing action.

WHAT'S INCLUDED

- One (1) VOLTRX VortexBoost Electric Shaker Bottle
- One (1) Fast charging USB-C power cord
- VOLTRactiveX animated packaging
- Product brochure



Image: Package contents of the VOLTRX VortexBoost Electric Protein Shaker Bottle.

SETUP

1. **Initial Charge:** Before first use, fully charge the shaker bottle using the provided USB-C power cord. The charging port is located on the base of the unit.
2. **Base Attachment:** Ensure the detachable motor base is securely attached to the bottle.
3. **Preparation:** Add your desired liquid (e.g., water, milk) to the bottle, up to 14oz (450ml).
4. **Add Powder:** Add up to 5 scoops of your preferred protein powder or supplement. For best results, add powder after the liquid.



Waterproof type-c charging port

Image: Waterproof USB-C charging port on the shaker base.

OPERATING INSTRUCTIONS

1. **Secure Lid:** Ensure the lid is tightly closed to prevent leaks. The lid features a clear removable plastic rim for easy cleaning and a convenient carry handle.
2. **Activate Mixing:** Press the power button located on the front of the motor base. The colorful light-up base will illuminate, and the vortex mixing action will begin.

3. **Mixing Duration:** A single press typically activates a 30-second mixing cycle. Double-clicking the button may activate a longer cycle (e.g., 1 minute).
4. **Stop Mixing:** The mixer will automatically stop after the cycle completes, or you can press the power button again to stop it manually.
5. **Enjoy:** Once mixing is complete, open the lid and consume your perfectly blended shake.



Image: Achieving delicious shakes in seconds with the VortexBoost.



Image: The shaker bottle's colorful light-up base in action.

MAINTENANCE AND CLEANING

The advanced IPX5 waterproof body of the VortexBoost protein shake mixer cup makes cleaning simple. To clean:

1. **Rinse:** Simply rinse the shaker bottle under running tap water.
2. **Self-Cleaning:** For faster cleaning, you can switch on the self-stirring function under running water.

- 3. **Detachable Base:** The motor base is detachable for thorough cleaning of the bottle.
- 4. **Hand Wash Only:** The motor base is **not dishwasher safe**. Ensure it does not get submerged in water for more than 1 minute and maintain a depth of less than 8 inches (20 cm) if rinsing.
- 5. **Lid Cleaning:** The lid has a clear removable plastic rim which can be detached for easier and more thorough cleaning.



Image: The shaker base is 100% waterproof for easy rinsing.

TROUBLESHOOTING

- **Shaker not mixing:** Ensure the battery is charged. Connect the USB-C cable to recharge.
- **Lid leaking:** Ensure the lid is securely fastened and the removable plastic rim is correctly seated.
- **Powder not mixing completely:** Ensure liquid is added before powder. For thicker powders, allow a slightly longer mixing cycle.
- **Base not detaching:** Ensure the base is twisted counter-clockwise to unlock before attempting to pull it off.

SPECIFICATIONS

Brand	VOLTRX
Model Name	VOLTRX VortexBoost Electric Protein Shaker
Item Model Number	ARB-002
Material	Tritan (BPA Free)
Capacity	24 oz (approx. 1.5 Pounds)
Color	Sakura Pink
Special Features	BPA Free, Dazzle Colored Base, USB-C Rechargeable, IPX5 Waterproof Base
Battery Type	Lithium Polymer (included)
Product Dimensions	3.94"W x 3.94"H
Item Weight	8.8 ounces
Care Instructions	Hand Wash Only (Base not dishwasher safe)

WARRANTY AND SUPPORT

The VOLTRX VortexBoost Electric Protein Shaker Bottle comes with a **12-month warranty**. For any questions, concerns, or support needs, please contact VOLTRX customer service. Our team of experts is available to assist you. You can find more information and contact details on the official VOLTRX website or through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question