**Kichler 52459BK**

# Kichler Baile 37 Inch 10-Light Chandelier Instruction Manual

Model: 52459BK

## Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler Baile 37 Inch 10-Light Chandelier. Please read all instructions carefully before beginning installation and retain this manual for future reference.
The Kichler Baile chandelier features a design with Natural Brass arcs and Black curves, designed to accommodate ten candelabra bulbs. When illuminated, it provides ambient lighting suitable for various indoor spaces.

## Safety Information

**WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.**

- Always disconnect power at the main fuse or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about the installation process.
- Do not exceed the maximum wattage specified for the bulbs.
- Ensure the fixture is securely mounted to a structural element capable of supporting its weight.
- This fixture is intended for indoor use only.

## Package Contents

Verify that all components are present before beginning installation:

- Chandelier Fixture (Model 52459BK)
- Mounting hardware (typically includes mounting plate, screws, wire nuts)

- Multiple stems for height adjustment

*Note: Light bulbs are not included and must be purchased separately.*

## Specifications

| | |
|---|---|
| **Brand** | Kichler |
| **Model Name** | Baile |
| **Item Model Number** | 52459BK |
| **Dimensions (L x W x H)** | 37" x 37" x 21.5" |
| **Adjustable Height** | Up to 53 inches (with included stems) |
| **Item Weight** | 15.75 Pounds |
| **Material** | Alloy Steel, Glass (Shade Material) |
| **Finish** | Black |
| **Color** | Black (with Natural Brass accents) |
| **Number of Light Sources** | 10 |
| **Bulb Base** | B10 Candelabra |
| **Max Wattage per Bulb** | 60 Watts |
| **Voltage** | 120 Volts |
| **Power Source** | Corded Electric |
| **Installation Type** | Semi Flush Mount |
| **Room Type** | Bedroom, Dining Room, Living Room |
| **Control Method** | Remote / Pull Chain (verify specific model features) |

## Setup and Installation

Professional installation by a qualified electrician is recommended for all electrical fixtures to ensure safety and compliance with electrical codes.

1. **Prepare for Installation:** Turn off power at the circuit breaker or fuse box. Ensure the power is completely off before proceeding.
2. **Unpack Contents:** Carefully remove all components from the packaging. Inspect for any damage.
3. **Assemble Fixture (if necessary):** Follow any specific assembly instructions provided with the fixture. This may involve attaching arms or decorative elements.
4. **Determine Hanging Height:** The chandelier includes multiple stems to adjust its overall height up to 53 inches. Select the appropriate stem length for your desired hanging height.
5. **Mounting:** Secure the mounting plate to the junction box in the ceiling. Ensure the junction box and mounting hardware can safely support the fixture's weight (15.75 lbs).

6. **Electrical Connections:** Connect the fixture's wires to the household electrical wires according to standard wiring practices (black to black, white to white, ground to ground). Use approved wire connectors.
7. **Secure Fixture:** Carefully lift the chandelier and attach it to the mounting plate, ensuring all connections are secure and the fixture is stable.
8. **Install Bulbs:** Insert ten B10 candelabra base bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
9. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.




Figure 1: Kichler Baile Chandelier showing overall dimensions (37" width, 21.5" height, adjustable up to 53" overall height).



Figure 2: Front view of the Kichler Baile 10-Light Chandelier, highlighting the Natural Brass and Black finish.

## Operation

Once installed and powered, the Kichler Baile chandelier can be operated using its designated control method. Depending on the specific model and installation, this may involve a wall switch, a remote control, or a pull chain. Refer to your home's electrical setup for the primary control point.

The chandelier is designed to provide up to 2000 lumens of light output when equipped with appropriate bulbs. The light color will depend on the bulbs selected.

## Maintenance

- **Cleaning:** To clean the fixture, ensure power is off. Use a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Always turn off power before replacing bulbs. Allow bulbs to cool completely before touching. Replace with B10 candelabra base bulbs, not exceeding 60 watts.
- **Inspection:** Periodically inspect the fixture for any loose wiring or damage. If any issues are found, disconnect power and consult a qualified electrician.

## Troubleshooting

If your Kichler Baile chandelier is not functioning correctly, consider the following common issues and solutions:

- **Light does not turn on:**
  - Check if the power is on at the circuit breaker.
  - Ensure bulbs are securely screwed into their sockets.
  - Test bulbs in another working fixture to confirm they are not faulty.
  - Verify all electrical connections are secure.
- **Flickering lights:**
  - Ensure bulbs are fully tightened.
  - Check for loose wiring connections.
  - Confirm that the dimmer switch (if installed) is compatible with the bulbs being used.
- **Fixture is loose:**
  - Turn off power and re-tighten mounting screws.
  - Ensure the mounting plate is securely fastened to the ceiling junction box.

If these steps do not resolve the issue, contact a qualified electrician or Kichler customer support for assistance.

## Warranty and Support

The Kichler Baile 37 Inch 10-Light Chandelier (Model 52459BK) comes with a**1-year limited manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use and service.
For warranty claims, technical support, or replacement parts, please contact Kichler customer service directly. Keep your proof of purchase for warranty validation.
**Manufacturer:** Kichler Lighting
**UPC:** 783927013802

© 2023 Kichler Lighting. All rights reserved.