



[Manuals.plus](#) /

› [GOOJODOQ](#) /

› GOOJODOQ GD13 Stylus Pen User Manual

GOOJODOQ GD13

GOOJODOQ GD13 Stylus Pen User Manual

Model: GD13 | Brand: GOOJODOQ

INTRODUCTION

Thank you for choosing the GOOJODOQ GD13 Stylus Pen. This advanced stylus is designed to enhance your iPad experience with features like true wireless charging, tilt sensitivity, and palm rejection. This manual will guide you through the setup, operation, and maintenance of your new GD13 stylus.



Image: The GOOJODOQ GD13 Stylus Pen, shown alongside an iPad displaying its wireless charging status and the three included replacement nibs.

SETUP

1. Initial Charging

The GD13 stylus supports true wireless charging. Simply attach the stylus magnetically to the side of your compatible iPad. The stylus will automatically begin charging.

Wireless Charging

Ditch the cables, magnetically attach to the iPad for charging and storage



Image: The GD13 stylus magnetically attached to the side of an iPad, illustrating its wireless charging capability.

2. Bluetooth Pairing (If Required)

For full functionality and battery status display, Bluetooth pairing is recommended. If you have previously connected an Apple Pencil, please disconnect it first.

1. Go to your iPad's **Settings**.
2. Tap on **Bluetooth** and ensure it is turned **On**.
3. Look for "GD13 pencil" in the list of devices and tap to connect.




Image: A screenshot of an iPad's Bluetooth settings, highlighting the "GD13 pencil" as an available device for connection.

OPERATING INSTRUCTIONS

Wireless Charging & Smart Mode

The GD13 stylus eliminates the need for charging cables. When not in use, simply attach it to the side of your compatible iPad. It will automatically switch to smart charging mode, ensuring it's always ready when you need it.

Quick Wake Feature

To quickly access notes, double-tap the iPad screen with the GD13 stylus. This will instantly open a blank memo in the notes application, allowing you to capture ideas without delay.

Quickly Use

Double-tap the iPad screen with the GD13 pencil to wake up and quickly open the notes app

Tap to wake



Image: A hand demonstrating the quick wake feature by double-tapping the iPad screen with the GD13 stylus to open the notes app.

Tilt Sensitivity & Palm Rejection

The GD13 stylus dynamically adjusts line thickness based on the angle at which you hold it, mimicking a traditional pencil. The advanced Palm Rejection technology allows you to rest your hand naturally on the iPad screen while writing or drawing, without interfering with the stylus's input.

Plam Rejection

Keine luftdichten handschuhe erforderlich



ours

other




Image: An illustration demonstrating the GD13 stylus's tilt sensitivity, showing how line thickness changes with angle, and its palm rejection feature, allowing comfortable hand placement on the screen.

Quick Gestures

- **Access Notes:** Swipe the GD13 stylus from the bottom right corner of the iPad screen towards the center to immediately access notes.
- **Take Screenshot:** Swipe the GD13 stylus from the bottom left corner of the iPad screen towards the center to quickly take a screenshot.

Battery Capacity Indicator

The GD13 stylus features an indicator light to show its battery status:

- **Red Light:** 0-30% battery
- **Blue Light:** 30-70% battery
- **Green Light:** 70-100% battery
- The light will blink while charging.

Battery Capacity Indicator & Compatible Nibs

Indicator color to confirm battery status
Blinking while charging



Indicator light



Include



Compatible with Apple Pencil
1th/2th, Logitech nibs



0-30%



30-70%



70-100%

Image: A visual guide to the GD13 stylus's battery indicator light colors (red, blue, green) corresponding to charge levels, and illustrating the compatibility of its nib with Apple Pencil and Logitech nibs.

MAINTENANCE

Nib Replacement

The GD13 stylus nib is designed for durability, but may require replacement over time due to wear. The GD13 nib is compatible with Apple Pencil (1st/2nd Gen) and Logitech nibs, making replacements widely available.

To replace the nib:

1. Gently twist the old nib counter-clockwise to remove it.
2. Align the new nib with the stylus tip and twist clockwise until securely fastened.

Always ensure the stylus and nib are clean and free of debris for optimal performance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stylus not connecting/responding.	Bluetooth not enabled, previously paired Apple Pencil, low battery, incompatible iPad model.	<ul style="list-style-type: none"> • Ensure iPad Bluetooth is On. • Forget/disconnect any previously paired Apple Pencils. • Charge the GD13 stylus fully. • Verify your iPad model is compatible (refer to Specifications section). • Restart your iPad.
Stylus not charging.	Not properly attached to iPad, dirty contact area, incompatible iPad model.	<ul style="list-style-type: none"> • Ensure the stylus is firmly attached to the magnetic charging strip on your iPad. • Clean the charging area on both the stylus and iPad. • Verify your iPad model supports wireless charging for styluses.
Inaccurate input or lag.	Low battery, worn-out nib, screen protector interference, software issue.	<ul style="list-style-type: none"> • Charge the stylus. • Replace the nib if it appears worn. • Ensure your screen protector is stylus-compatible. • Restart the application or iPad.

SPECIFICATIONS

- **Brand:** GOOJODOQ
- **Model:** GD13
- **Color:** White
- **Material:** Polyoxymethylene
- **Weight:** 30 Grams
- **Battery Type:** Lithium-ion (1 included)
- **Charging:** Wireless Magnetic Charging
- **Features:** Tilt Sensitivity, Palm Rejection, Quick Wake, Quick Gestures

Compatible iPad Models:

The GD13 stylus is compatible with the following iPad models. Please check the model number on the back of your iPad to confirm compatibility.



For iPad Air	For iPad Pro 12.9	For iPad Pro 11	For iPad mini
For iPad Air	3rd/4th/5/6th Gen	1st/2nd/3rd /4thGen	6th Gen
A2072/A2316/ A2324/A2325 A2588/A2589/ A2591	A1876/A1895/ A1983/A2014 A2229/A2069/ A2232/A2233 A2378/A2379/ A2461/A2462	A1980/A2013/ A1934/A1979 A2228/A2068/ A2230/A2231 A2377/A2301/ A2459/A2460	A1980/A2013/ A1934/A1979 A2228/A2068/ A2230/A2231 A2377/A2301/ A2459/A2460

Image: A comprehensive table listing compatible iPad Air, iPad Pro 12.9-inch, iPad Pro 11-inch, and iPad Mini models, along with their corresponding model numbers, for the GD13 stylus.

iPad Model	Compatible Generations	Model Numbers (Axxxx)
iPad Air	4th/5th Gen	A2072, A2316, A2324, A2325, A2588, A2589, A2591
iPad Pro 12.9-inch	3rd/4th/5th/6th Gen	A1876, A2014, A1895, A1983, A2229, A2069, A2232, A2233, A2378, A2461, A2379, A2462
iPad Pro 11-inch	1st/2nd/3rd/4th Gen	A1980, A2013, A1934, A1979, A2228, A2068, A2230, A2231, A2377, A2459, A2301, A2460
iPad Mini	6th Gen	A2567, A2568, A2569

WARRANTY AND SUPPORT

Specific warranty information for the GOOJODOQ GD13 Stylus Pen is not provided in this manual. For warranty claims, technical support, or any product-related inquiries, please contact GOOJODOQ customer service through their official website or the platform where you purchased the product.

You can often find support contact details on the product packaging or the seller's page.