

[Manuals.plus](#) /

> [uehba](#) /

> uehba RM-AAU013 Universal Replacement Remote Control for Sony AV Receivers

uehba RM-AAU013

uehba RM-AAU013 Universal Replacement Remote Control Instruction Manual

For Sony AV Receivers

1. INTRODUCTION

This manual provides instructions for the uehba RM-AAU013 Universal Replacement Remote Control. This remote is designed to function as a direct replacement for original Sony AV Receiver remote models RM-AAU013 and RM-AAP013. It is pre-programmed and requires no additional setup.

RM-AAU013

Replacement Remote Control for Sony AV Receiver :

STR-K1500 HT-DDW685 HT-DDW790
E15 STR-DG500 STR-DH100 STR-DH500

Use Directly without settings !



Strong Signal



Key Sensitive

This image displays the uehba RM-AAU013 remote control, highlighting its compatibility with various Sony AV Receiver models such as STR-K1500, HT-DDW685, HT-DDW790, E15, STR-DG500, STR-DH100, and STR-DH500. It emphasizes that the remote can be used directly without any settings.

2. COMPATIBLE MODELS

The uehba RM-AAU013 remote control is compatible with the following Sony AV Receiver models:

- STR-K1500
- HT-DDW685
- HT-DDW790
- E15
- STR-DG500
- STR-DH100
- STR-DH500

3. SETUP

To begin using your uehba RM-AAU013 remote control, follow these simple steps:

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two (2) 1.5V AA Alkaline batteries (not included), ensuring correct polarity (+ and - terminals).
3. Close the battery compartment cover securely.
4. The remote control is now ready for use with your compatible Sony AV Receiver. No programming is required.



**Requires 2x AA Batteries
(not included)**

A view of the back of the RM-AAU013 remote control with the battery cover removed, illustrating where two AA batteries are to be inserted.
The image clearly indicates that batteries are not included.

4. OPERATING INSTRUCTIONS

The uehba RM-AAU013 remote control is pre-programmed for immediate use with compatible Sony AV Receivers. Simply point the remote control towards your receiver and press the desired function buttons.

Key Features:

- **No Programming Required:** Functions directly out of the box.
- **Strong Infrared Signal:** Ensures reliable communication with your receiver.
- **Sensitive Key Response:** Provides accurate and responsive button presses.



**No need programming !
Work right out of the box !**

This image shows a hand holding the RM-AAU013 remote control in a living room setting, demonstrating its 'no programming needed' feature. The remote is ready to function right out of the box.

5. MAINTENANCE

Battery Replacement:

When the remote control's performance diminishes or it stops responding, it is time to replace the batteries. Always use two new 1.5V AA Alkaline batteries. Do not mix old and new batteries, or different types of batteries, as this can affect performance and potentially damage the remote.

Cleaning:

To clean the remote control, wipe it gently with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, which could damage the surface or internal components.

6. TROUBLESHOOTING

If you experience issues with your uehba RM-AAU013 remote control, please refer to the following common solutions:

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace the batteries with new 1.5V AA Alkaline batteries.
 - Ensure there are no obstructions between the remote control and the AV receiver's infrared sensor.
 - Verify that you are within the maximum operating range (approximately 10 meters).
- **Limited Range or Intermittent Functionality:**
 - This often indicates low battery power. Replace the batteries.
 - Ensure a clear line of sight to the AV receiver. Strong light sources or other electronic devices can sometimes interfere with the infrared signal.

7. SPECIFICATIONS

Feature	Detail
Brand	uehba
Model Name/Number	RM-AAU013
Special Feature	No Programming Required
Color	Off White
Max Number of Supported Devices	1
Compatible Devices	Home Theater (Sony AV Receivers)
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 Meters
Batteries Required	2 AA Alkaline Batteries (not included)
Item Weight	70 Grams
Manufacturer	uehba
UPC	730637668327



A composite image presenting the uehba RM-AAU013 remote control from various angles: front, side, and back. This provides a comprehensive visual overview of the product's design.

8. WARRANTY AND SUPPORT

Warranty Information:

This product comes with a 1-year warranty from the date of purchase.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact the manufacturer, uehba, through your purchase platform or their official support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09Y4H4MFF>

More documents and user manuals: <https://manuals.plus/>