

Dapsang 800

Dapsang Electric Eyebrow Trimmer

MODEL 800 USER MANUAL

Product Overview

The Dapsang Electric Eyebrow Trimmer is designed for gentle and effective hair removal. Its hypoallergenic blade system minimizes skin irritation, providing a painless experience for various facial and body areas.

This versatile trimmer is suitable for precise hair removal on eyebrows, ears, sideburns, lips, mustache, underarms, arms, and legs. It includes a double-head grooming comb for shaping eyebrows to desired lengths.

An integrated LED light illuminates fine hairs for precise grooming. This feature enhances visibility, making the trimming process more efficient. The device can also be used for gentle hair removal on sensitive areas.

The trimmer is USB rechargeable, eliminating the need for frequent battery changes. Its portable design allows for convenient use anywhere. The detachable blade head is rinseable for easy and thorough cleaning with the included brush.



Image: Dapsang Electric Eyebrow Trimmer, Model 800.

Safety Information

- Potential skin irritation may occur from stainless steel components.
- Exercise caution during cleaning.
- This device is not intended for use on infants.
- Always ensure the protection cover is attached when not in use.
- Keep out of reach of children.

What's Included

The Dapsang Electric Eyebrow Trimmer package includes:

- Eyebrow trimmer unit
- Replacement blade

- Protection cover
- Eyebrow trimming comb
- Charging cable (USB-C)
- Cleaning brush

MULTI-PURPOSE USE


Ears



Eyebrows



Armpit



Leg



Lips



Sideburns



Image: All components included with the Dapsang Electric Eyebrow Trimmer.

Product Features

Dapsang

RECHARGEABLE EYEBROW TRIMMER

Painless & Safe



Skin-Friendly Design: Features double blades and an R-shaped design for safe, painless trimming.

USB-C RECHARGEABLE

- Charging 2 hours, running time up to 120 minutes.
- Charging indicator shows charging process.



Multi-Purpose Use: Effective for eyebrows, ears, armpits, legs, lips, and sideburns.

- The double blade design has a protective effect on the skin.
- Provide you with a painless and safe shaving experience.



SAFE DUAL BLADE

Eyebrow Guide or Comb: Helps create desired eyebrow length and shape.



UNLIMITED USING BUTTON

- Flexible touched control, it can be pressed millions of times.

LED Light Design: Illuminates fine hairs for precise and efficient

grooming.

**LED LIGHT**

- The LED design makes you easier to see details and shave with precision.



USB-C Fast Charge: Provides up to 2 hours of use after a full charge.

**MULTIFUNCTIONAL EYEBROW TRIMMER KIT**

Perfect for multiple area shaving



Eyebrows



Forehead



cheek



Chin



Arms



Leg



Convenient Charging Method: Can be charged via computer, adapter, or power bank.



Lightweight & Portable: Pen-sized design for easy carrying and travel.

Setup

1. **Charge the Device:** Before first use, fully charge the device using the provided USB-C charging cable. The charging indicator lights will show the charging status. A full charge typically provides up to 2 hours of use. You can charge the device via a computer, adapter, or power bank.

Operating Instructions

1. **Power On/Off:** Press and hold the power button for a few seconds to turn the trimmer on or off.
2. **LED Light:** Press the power button once to activate the LED light for enhanced visibility during trimming. Press again to turn off the light.
3. **Attach Protection Cover:** For general trimming, ensure the appropriate protection cover is attached to the blade head.
4. **Use Eyebrow Comb:** For precise eyebrow shaping, attach the double-head grooming comb. Select the desired length (e.g., 2mm, 5mm, 10mm, 25mm) by adjusting the comb.
5. **Trimming:** Gently glide the trimmer against the direction of hair growth. Use light pressure. The fixed and moving blades work together for a smooth, painless trim.
6. **Target Areas:** The trimmer is suitable for eyebrows, facial hair (peach fuzz), ears, sideburns, lips, and other body areas like underarms, arms, and legs.

Maintenance

1. **Detach Blade Head:** Turn off the trimmer. Gently twist or pull the blade head to detach it from the main unit.
2. **Rinse Blade:** Rinse the detached blade head under running water. The blade is waterproof.
3. **Clean with Brush:** Use the included cleaning brush to remove any trapped hairs from the blade and the trimmer body.
4. **Dry:** Allow the blade head to air dry completely before reattaching it to the trimmer.
5. **Storage:** Store the trimmer with the protection cover on in a clean, dry place.

USB-C FAST CHARGE



**Charging
indicator**



**2 hours
of use tim**



**Energy-saving
li-po**



Image: Detachable blade head being cleaned under water.

Troubleshooting

For common issues, ensure the device is fully charged and the blade is clean and properly attached. If problems persist, please refer to the warranty and support section for assistance.

Specifications

Feature	Detail
Product Dimensions	6.1 x 0.8 x 0.6 inches
Item Weight	3 ounces
Model Number	800
Power Source	Cordless & Electric (USB Rechargeable)
Battery Type	1 Lithium Polymer battery (included)
Material Type	Acrylonitrile Butadiene Styrene, Stainless Steel
Blade Material	Stainless Steel
Color	White
Special Features	LED Light, USB Rechargeable, Cordless
Recommended Uses	Eyebrow, Face, Arm, Leg
Target Audience	Women (also suitable for men)

Official Product Video

Your browser does not support the video tag.

Video: Rechargeable Facial Hair Trimmer with Replacement Blade by Dapsang.

Warranty and Support

Dapsang offers a 1-year after-sales service for this product. For any questions or support needs, please contact Dapsang customer service. Your satisfaction is our top priority.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question