SoBuy FST86

SoBuy FST86-W Bar Stool Instruction Manual

Model: FST86

1. Introduction

Thank you for choosing the SoBuy FST86-W Bar Stool. This manual provides essential information for the safe assembly, operation, and maintenance of your new bar stool. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: Two SoBuy FST86-W bar stools positioned at a kitchen counter.

2. Safety Information

WARNING: To prevent serious injury, always follow these safety guidelines:

- Do not exceed the maximum load capacity of**120 kg (264 lbs)**.
- Always use the bar stool on a stable, level surface to prevent tipping.
- Ensure all screws and fasteners are securely tightened before use and periodically check for tightness.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Do not stand on the stool or use it as a ladder.
- Avoid exposing the stool to direct sunlight or extreme temperatures to prevent material damage.

3. Package Contents

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, contact SoBuy customer service immediately.

The package typically includes:

- Seat (ABS Plastic)
- Legs (Beech Wood)
- Footrest Ring (Metal)
- Assembly Hardware (screws, washers, Allen key)
- Instruction Manual

Note: Decorative elements shown in product images are not included.

4. Setup and Assembly

Assembly of the SoBuy FST86-W Bar Stool is designed to be straightforward. Follow the numbered steps and illustrations provided in the included assembly guide. Ensure you have enough space and the necessary tools (usually an Allen key, which is provided).

1. **Attach Legs to Seat:** Securely fasten the beech wood legs to the underside of the ABS plastic seat using the provided screws and washers. Ensure the legs are oriented correctly.
2. **Install Footrest:** Attach the metal footrest ring to the designated slots on the legs. Tighten the screws to ensure the footrest is stable and provides adequate support.
3. **Final Tightening:** Once all components are in place, carefully tighten all screws. Do not overtighten.
4. **Stability Check:** Before use, gently rock the stool to ensure it is stable and all connections are secure.



Image 4.1: Detail of the secure leg-to-seat connection.



Image 4.2: Detail of the integrated metal footrest for comfort and stability.

5. Operating Instructions (Usage)

The SoBuy FST86-W Bar Stool is designed for seating at bars, kitchen islands, bistros, or similar high-counter environments. Its ergonomic seat and low backrest provide comfortable support.

- Sit centrally on the seat to distribute weight evenly.
- Utilize the footrest for added comfort and stability.
- When moving the stool, lift it rather than dragging it to prevent damage to floor surfaces and reduce noise. The legs are equipped with rubber joints to protect floors.



Image 5.1: Detail of the rubber floor protector on the stool leg.

6. Maintenance and Care

Proper care will extend the life and appearance of your bar stool.

- **Cleaning:** Wipe the seat and legs with a slightly damp cloth. For stubborn stains, use a mild soap solution and dry immediately with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically inspect all connections and screws to ensure they remain tight. Retighten if necessary.
- **Environment:** Keep the stool in a dry environment. Avoid prolonged exposure to direct sunlight or high humidity, which can affect the wood and plastic materials.

7. Troubleshooting

Problem	Possible Cause	Solution
Stool is wobbly or unstable.	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the stool is on a flat, level surface.
Difficulty during assembly.	Incorrect part orientation or missing hardware.	Refer to the detailed assembly instructions and illustrations. Verify all parts are present. Contact customer service if parts are missing.
Scratches on floor.	Missing or damaged floor protectors.	Ensure rubber joints are properly installed on all legs. Replace if damaged. Avoid dragging the stool.

If you encounter issues not listed here, please contact SoBuy customer service for assistance.

8. Specifications

Feature	Detail
Model Number	FST86-W
Brand	SoBuy
Material	Seat: ABS Plastic, Legs: Beech Wood
Overall Dimensions (L x W x H)	41 x 41 x 84 cm (16.1 x 16.1 x 33.1 inches)
Seat Height	70 cm (27.6 inches)
Maximum Load Capacity	120 kg (264 lbs)
Item Weight	Approx. 4.3 kg (9.5 lbs)
Color	White (Seat)



Image 8.1: Dimensional diagram of the bar stool.

9. Warranty and Customer Support

SoBuy provides dedicated customer service before and after your purchase. For any questions, concerns, or assistance with your product, please contact SoBuy customer support. Please have your model number (FST86-W) and purchase

details ready when contacting support.

For more information or to contact support, please visit the official SoBuy store or website.

Note: Specific warranty terms and conditions may vary by region and retailer. Please refer to your purchase documentation for details.

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question