

[Manuals.plus](#) /

› [Dapsang](#) /

› Dapsang Electric Eyebrow Trimmer Model 800 User Manual

Dapsang 800

Dapsang Electric Eyebrow Trimmer Model 800 User Manual

Model: 800 | Brand: Dapsang

1. INTRODUCTION

Thank you for choosing the Dapsang Electric Eyebrow Trimmer Model 800. This device is designed for precise and painless hair removal, suitable for various facial and body areas. Please read this manual thoroughly before use to ensure safe and optimal performance.



Image 1.1: Dapsang Electric Eyebrow Trimmer Model 800.

2. PRODUCT FEATURES

- **Skin-Friendly and Painless:** Hypoallergenic design with excellent sharpness for a safe and painless shaving experience, preventing pulling or skin damage.
- **Multifunctional Use:** Ideal for trimming eyebrows, ears, sideburns, lips, mustache, underarms, arms, and legs.
- **LED Light for Precision:** Integrated LED light illuminates fine hairs, enabling precise grooming even in low-light conditions.
- **USB Rechargeable:** Comes with a charging cable for convenient recharging, eliminating the need for frequent battery changes.
- **Easy Cleaning:** Detachable blade head can be rinsed with water for thorough cleaning, aided by the included cleaning brush.

- **Portable Design:** Compact and lightweight, making it easy to carry for travel or daily use.



Image 2.1: Skin-friendly design with double blade trimming and R-shaped blade for safety.




Image 2.2: LED light for enhanced visibility during trimming.

3. PACKAGE CONTENTS

The Dapsang Electric Eyebrow Trimmer Model 800 package includes:

- 1 x Eyebrow Trimmer
- 1 x Replacement Blade
- 1 x Protection Cover
- 1 x Eyebrow Trimming Comb (double-head)
- 1 x Charging Cable
- 1 x Cleaning Brush



Image 3.1: Illustration of the Dapsang Eyebrow Trimmer and its included accessories.

4. SETUP

4.1 Charging the Device

1. Ensure the trimmer is turned off before charging.
2. Connect the provided USB charging cable to the trimmer's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter, power bank).
4. The LED indicator lights will show the charging status. A full charge typically takes approximately 2 hours and provides up to 120 minutes of use.

USB-C FAST CHARGE



Charging
indicator



2 hours
of use tim



Energy-saving
li-po



Image 4.1: The trimmer connected to a USB power source for charging.

Convenient Charging Method



Computer



Adapter



Power bank



Image 4.2: Various options for charging the trimmer, including computer, adapter, and power bank.

4.2 Attaching/Detaching Accessories

1. To attach the eyebrow trimming comb: Align the comb with the trimmer head and gently slide it on until it clicks into place.
2. To detach the eyebrow trimming comb: Gently pull the comb away from the trimmer head.
3. To replace the blade: Carefully remove the existing blade by pushing it off. Align the new blade and press it firmly into place until it secures.

EYEBROW GUIDE OR COMB

Create the desired eyebrow length what you want



Before



After




Image 4.3: The eyebrow trimming comb, showing different length settings (2mm, 5mm, 10mm, 25mm).

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- Press and hold the power button for a few seconds to turn the trimmer on. The LED indicator lights will illuminate.

- Press and hold the power button again to turn the trimmer off.

5.2 Using the LED Light

- Once the trimmer is powered on, the LED light will automatically activate, providing illumination for precise trimming.

5.3 Trimming Different Areas

For optimal results, ensure your skin is clean and dry before trimming.

- **Eyebrows:** Use the precision blade to shape and trim unwanted eyebrow hairs. For consistent length, attach the eyebrow trimming comb.
- **Face (Lips, Peach Fuzz):** Gently glide the trimmer against the direction of hair growth to remove fine facial hair.
- **Body (Ears, Sideburns, Neck, Underarms, Arms, Legs):** Use the trimmer to remove hair from these areas. The skin-friendly design minimizes irritation.

MULTI-PURPOSE USE


Ears



Eyebrows



Sideburns



Neck



Lips



arm



Image 5.1: Demonstrates the trimmer's versatility for various body and facial hair removal.

Video 5.1: Official Dapsang video demonstrating the rechargeable facial hair trimmer with replacement blade.

6. MAINTENANCE

6.1 Cleaning the Blade

1. Turn off the trimmer and detach the blade head.
2. Rinse the blade head under running water to remove hair and debris.
3. Use the included cleaning brush to remove any stubborn hairs from the blade and trimmer body.
4. Allow the blade head to air dry completely before reattaching it to the trimmer.

6.2 Replacing the Blade

For continued optimal performance, replace the blade when you notice a decrease in cutting efficiency or increased pulling. Refer to section 4.2 for instructions on replacing the blade.

7. TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the device is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to turn it on again.
- **Poor trimming performance:** Check if the blade head is clean and free of hair buildup. Clean the blade as described in section 6.1. If performance does not improve, consider replacing the blade.
- **Device feels hot during use:** This is normal for electronic devices during operation. If it becomes excessively hot or emits smoke/unusual odors, discontinue use immediately and contact support.
- **Unusual noise:** Ensure the blade head is properly attached. If the noise persists, clean the blade and check for any obstructions.

8. SPECIFICATIONS

Product Dimensions	6.1 x 0.8 x 0.6 inches
Item Weight	3 Ounces
Model Number	800
Power Source	Cordless & Electric (USB Rechargeable)
Battery Type	1 Lithium Polymer battery (included)
Blade Material	Stainless Steel
Material Type	Acrylonitrile Butadiene Styrene, Stainless Steel
Special Features	LED Light, USB Rechargeable, Cordless
Recommended Uses	Eyebrow, Face, Arm, Leg
Target Audience	Women, Men
UPC	782917147114

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Dapsang product comes with a 1-year after-sales service. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, concerns, or support needs regarding your Dapsang Electric Eyebrow Trimmer Model 800, please contact our customer service team. Your satisfaction is our top priority.

Contact information can typically be found on the product packaging or the official Dapsang website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question