

[Manuals.plus](#) /

› [Pigeon](#) /

› Pigeon 1.5L Electric Kettle and Stainless Steel Water Bottle Combo User Manual

Pigeon 14913

Pigeon 1.5L Electric Kettle and Stainless Steel Water Bottle Combo User Manual

Model: 14913

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Pigeon 1.5L Electric Kettle and Stainless Steel Water Bottle Combo. Please read all instructions carefully before first use and retain for future reference.



Image: The Pigeon 1.5L Electric Kettle and Stainless Steel Water Bottle shown together.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been

damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle is for household use only.
- Do not fill the kettle above the MAX line or below the MIN line.
- Ensure the lid is securely closed before operating the kettle.
- The stainless steel water bottle is not suitable for carbonated beverages or dairy products.

3. PACKAGE CONTENTS

Your Pigeon 1.5L Electric Kettle and Stainless Steel Water Bottle Combo package includes:

- 1 x Pigeon 1.5L Electric Kettle
- 1 x Stainless Steel Water Bottle

4. SETUP

4.1 Electric Kettle Setup

1. **Unpacking:** Carefully remove the kettle and its base from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water up to the MAX level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.



Image: The Pigeon 1.5L Electric Kettle highlighting its 1.5L capacity and rustproof stainless steel body.

4.2 Stainless Steel Water Bottle Setup

1. **Unpacking:** Remove the water bottle from its packaging.
2. **Initial Cleaning:** Wash the bottle and its cap thoroughly with warm soapy water before first use. Rinse well.



Image: The Pigeon Stainless Steel Water Bottle, illustrating its sipper cap, wide mouth, stainless steel construction, and lightweight design.

5. OPERATING INSTRUCTIONS

5.1 Electric Kettle Operation

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of water. Ensure the water level is between the MIN and MAX marks on the water level indicator.
2. **Close the Lid:** Securely close the lid.
3. **Place on Base:** Place the kettle onto its power base. The 360° swivel base allows for easy placement from any direction.
4. **Power On:** Plug the power cord into a suitable electrical outlet. Press the ON/OFF switch down. The indicator light will illuminate, signifying that the kettle is heating.
5. **Automatic Shut-Off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn

off.

6. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Exercise caution as steam and hot water can cause burns.
7. **Re-boiling:** If the kettle has just boiled, wait a few moments before pressing the switch again to allow the thermostat to reset.



Image: The Pigeon Electric Kettle highlighting its cordless design, pull-flip lid for easy filling, and power indicator light.

5.2 Stainless Steel Water Bottle Operation

1. **Filling:** Open the sipper cap and fill the bottle with your desired beverage (hot or cold). Do not overfill.
2. **Sealing:** Ensure the sipper cap is securely closed to prevent leaks.
3. **Usage:** The bottle is designed for carrying water, tea, coffee, or other non-carbonated beverages. It is suitable for both hot and cold liquids.



Image: The Pigeon Stainless Steel Water Bottle, showing its 700ml capacity, ease of carrying and cleaning, and spill-proof design.



Image: The Pigeon Stainless Steel Water Bottle, emphasizing its odour-free properties, suitability for hot and cold beverages, and refrigerator compatibility.

6. MAINTENANCE AND CLEANING

6.1 Electric Kettle Cleaning

Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.

- **Exterior:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior/Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
 - a. Fill the kettle with 1 part white vinegar and 2 parts water.
 - b. Bring to a boil and let it stand for at least 30 minutes, or longer for heavy deposits.
 - c. Discard the solution and rinse the kettle thoroughly with fresh water several times.
 - d. Alternatively, use a commercial descaling solution following the product's instructions.

- **Base:** Never immerse the power base in water or any other liquid. Wipe with a damp cloth if necessary.

6.2 Stainless Steel Water Bottle Cleaning

- Wash the bottle and cap with warm soapy water after each use.
- Use a bottle brush for thorough cleaning of the interior.
- Rinse thoroughly with clean water and allow to air dry with the cap off.
- Do not use bleach or cleaners containing chlorine.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	No power supply; Kettle not properly placed on base; ON/OFF switch not pressed.	Check power outlet; Ensure kettle is correctly seated on the base; Press the ON/OFF switch.
Kettle switches off before boiling.	Limescale buildup; Kettle is underfilled.	Descale the kettle (refer to Section 6.1); Ensure water level is above the MIN mark.
Kettle does not switch off after boiling.	Lid is not properly closed.	Ensure the lid is securely closed.
Water bottle leaks.	Cap not securely tightened; Seal ring is damaged or missing.	Ensure the cap is tightly closed; Check the seal ring for proper placement and condition.
Bottle exterior gets hot with hot water.	This bottle is designed to be suitable for hot beverages, but the exterior may warm up depending on the temperature of the liquid.	Exercise caution when handling the bottle with very hot liquids. Use a protective sleeve if desired.

8. SPECIFICATIONS

Brand	Pigeon
Model Name	14913
Kettle Capacity	1.5 Liters
Bottle Capacity	700 ml
Material	Stainless Steel
Colour	Black & Silver
Special Feature (Kettle)	Automatic Shut-Off
Voltage	240 V

Wattage (Kettle)	1300 Watts
Product Dimensions (Kettle)	18.5L x 18.5W x 21.2H Centimeters
Item Weight	900 Grams (Total)
Country of Origin	India

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Pigeon Electric Kettle and Stainless Steel Water Bottle Combo comes with a **1 Year Warranty** from the date of purchase. The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

9.2 Customer Support

For any product-related queries, service requests, or warranty claims, please contact:

- **Manufacturer:** Stovekraft Limited
- **Customer Care Number:** 080 26985800
- **Address:** 81/1 Harohalli Industrial Area Kanakapura Taluk Bangalore Kanakapura, Bengaluru, Karnataka 562112, India

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09Y5FZK9N>

More documents and user manuals: <https://manuals.plus/>