

[Manuals.plus](#) /

› [Rapoo](#) /

› RAPOO 9350m C-Type Rechargeable Bluetooth Wireless Multi-Device Keyboard Mouse Combo User Manual

Rapoo 9350m

RAPOO 9350m C-Type Rechargeable Bluetooth Wireless Multi-Device Keyboard Mouse Combo User Manual

Model: 9350m

1. PRODUCT OVERVIEW

The RAPOO 9350m is a versatile wireless keyboard and mouse combo designed for multi-device connectivity. It supports seamless switching between up to four devices, offering both Bluetooth and 2.4G wireless connection options. The keyboard features an ultra-slim design with scissor keys and multimedia hotkeys, while the mouse provides adjustable DPI and silent clicks.



The RAPOO 9350m keyboard and mouse combo, featuring a full-size keyboard, ergonomic mouse, and a 2.4G USB receiver.

2. PACKAGE CONTENTS

- RAPOO 9350m Wireless Keyboard
- RAPOO 9350m Wireless Mouse
- USB Receiver (stored inside the mouse)
- USB-C Charging Cable
- User Manual (this document)

3. SETUP INSTRUCTIONS

3.1 Initial Charging

Before first use, ensure both the keyboard and mouse are fully charged. Connect the provided USB-C charging cable to the charging port on each device and to a USB power source. A full charge typically takes approximately 1

hour and 15 minutes.

3.2 Powering On/Off

Locate the ON/OFF switch on the underside of both the keyboard and the mouse. Slide the switch to the 'ON' position to power on the devices. Slide to 'OFF' when not in use to conserve battery.



View of the keyboard's aluminum alloy backplate and the mouse's underside, indicating the storage slot for the USB receiver, the ON/OFF switch, and the Bluetooth switch.

3.3 Connecting to Devices (Multi-Mode)

The RAPOO 9350m combo supports connection to up to four devices simultaneously via 2.4G wireless and Bluetooth (Bluetooth 3.0 and Bluetooth 5.0).

3.3.1 2.4G Wireless Connection

1. Remove the USB receiver from its storage compartment on the underside of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Ensure both the keyboard and mouse are powered on.

4. The devices should automatically connect to your computer. The keyboard's 2.4G indicator (often F1/F2/F3 keys with blue numbers) will illuminate.

3.3.2 Bluetooth Connection (BT1, BT2, BT3)

1. Ensure the keyboard and mouse are powered on.
2. On the keyboard, press and hold one of the Bluetooth keys (e.g., F1, F2, or F3, indicated by blue Bluetooth icons) for 3-5 seconds until the indicator light above the key starts blinking rapidly. This indicates pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for new devices.
4. Select "RAPOO 9350m Keyboard" from the list of available devices to pair.
5. For the mouse, press the Bluetooth switch on its underside to cycle through available Bluetooth channels (often indicated by a small LED). Hold the switch for 3-5 seconds until the LED blinks rapidly.
6. On your device, select "RAPOO 9350m Mouse" from the Bluetooth device list to pair.
7. Repeat for additional Bluetooth devices using different Bluetooth channels (F1, F2, F3 on keyboard; corresponding channels on mouse).



Illustration showing the RAPOO 9350m keyboard and mouse simultaneously connected to a desktop, smartphone, and tablet, highlighting its multi-device capability.

4. OPERATING INSTRUCTIONS

4.1 Switching Between Connected Devices

To switch between your connected devices, simply press the corresponding function key on the keyboard (e.g., F1, F2, F3 for Bluetooth, or the 2.4G indicator key). The mouse will automatically switch to the active device.

4.2 Keyboard Functions

4.2.1 Multimedia Hotkeys

The keyboard features 13 multimedia shortcut keys (F1-F12, and other dedicated keys) for quick access to functions like media playback control (play/pause, next/previous track), volume adjustment, and more. These keys are typically activated by pressing the 'Fn' key in combination with the desired function key, or directly if the 'Fn Lock' is enabled.

13 MULTIMEDIA SHORTCUTS & QUIET SCISSOR FOOT KEYS


Keycaps with a little sunken, bring you better typing experience



Anti-scratch



Anti-fingerprint



Silent



Close-up of the RAPOO 9350m keyboard, showcasing its 13 multimedia shortcut keys and the quiet scissor-foot key mechanism for comfortable typing.

4.2.2 Operating System Layout

The keyboard supports both Windows and Mac OS layouts. Use the dedicated switch or key combination (if available) to toggle between layouts for optimal compatibility.

4.3 Mouse Functions

4.3.1 DPI Adjustment

The mouse features a 1600 DPI tracking engine with 4 adjustable DPI levels (600, 1000, 1300, 1600). Press the DPI button (usually located near the scroll wheel) to cycle through the sensitivity settings to match your preference and task requirements.


4.3.2 Silent Clicks

The mouse is designed with silent click technology to minimize noise during use.

4 DPI ADJUSTABLE & WHISPER QUIET



5,000,000 Keystrokes



4 DPI Adjustable



Silent



Detailed view of the RAPOO 9350m mouse, illustrating its 4-level DPI adjustment (600, 1000, 1300, 1600) and silent click design.

5. MAINTENANCE

5.1 Cleaning

To clean the keyboard and mouse, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. For the keyboard, you can use compressed air to remove debris from between the keys. The keyboard is spill-resistant, but it is recommended to clean up any spills immediately.

5.2 Battery Care

Recharge the devices when the battery indicator light signals low power. Use only the provided USB-C cable or a compatible high-quality cable for charging. Avoid exposing the devices to extreme temperatures.

6. TROUBLESHOOTING

- Device Not Connecting:**
Ensure both the keyboard and mouse are powered on. Check if the USB receiver is securely plugged in for 2.4G connection. For Bluetooth, ensure Bluetooth is enabled on your device and the combo is in pairing mode. Try re-pairing the devices.
- Lag or Disconnection:**
Move the devices closer to the receiver or Bluetooth-enabled device. Avoid using the devices near strong interference sources (e.g., Wi-Fi routers, other wireless devices). Ensure batteries are sufficiently charged.
- Mouse Tracking Issues:**
Clean the mouse sensor. Try adjusting the DPI settings. Ensure you are using the mouse on a suitable surface.
- Keyboard Input Errors:**
Check if the correct operating system layout is selected (Windows/Mac). Ensure no keys are stuck. Recharge the keyboard.
- Battery Draining Quickly:**
Ensure devices are powered off when not in use. Reduce the distance to the connected device.

7. SPECIFICATIONS

Feature	Detail
Brand	Rapoo
Model	9350m
Connectivity Technology	Bluetooth (3.0, 5.0), 2.4G Wireless
Multi-Device Support	Up to 4 devices
Keyboard Type	Ultra-slim, Scissor Key, Numpad
Mouse DPI	1600 DPI (adjustable)
Power Source	Rechargeable Lithium Ion Battery (included)
Charging Port	USB Type-C
Operating System Compatibility	Windows, Mac OS, Chrome OS, Linux, Android
Keyboard Dimensions (LxWxH)	34.3 x 11.4 x 1.9 cm
Item Weight	660 g (combo)

WIDE COMPATIBILITY

Compatible with Windows and Mac OS,Fn+ ~switch system



Visual representation of the RAPOO 9350m combo's wide compatibility with Windows (7, 8, 10, Vista), macOS 12, and other systems, demonstrating its versatility.

ULTRA-SLIM DESIGN



Diagram illustrating the ultra-slim design and precise dimensions of the RAPOO 9350m keyboard (36.23cm x 11.47cm x 0.5cm) and mouse (10.39cm x 6.54cm x 3.72cm).

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This RAPOO 9350m Keyboard Mouse Combo comes with a **3-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions.

8.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact RAPOO customer support through their official website or the retailer where the product was purchased. Refer to the product packaging for specific contact details.



© 2023 RAPOO. All rights reserved.