

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Samsung](#) /

> [Samsung HW-S60B/ZC 3.1ch Soundbar User Manual](#)

## Samsung HW-S60B/ZC

# Samsung HW-S60B/ZC 3.1ch Soundbar User Manual

MODEL: HW-S60B/ZC

## Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Samsung HW-S60B/ZC 3.1ch Soundbar. Please read these instructions carefully to ensure optimal performance and longevity of your device. Keep this manual for future reference.

## Setup

### 1. Unpacking

Carefully remove all components from the packaging. Verify that all items listed in the package contents are present. Retain packaging materials for potential future transport or service.

### 2. Placement

Position the soundbar centrally below your television for the best audio experience. Ensure there is adequate space around the soundbar for proper ventilation. The soundbar can also be wall-mounted using the included wall mount kit.



Image: Front view of the Samsung HW-S60B/ZC Soundbar. This image displays the sleek, black soundbar from the front, highlighting its minimalist design and speaker grille.

### 3. Connections

- Power Connection:** Connect the power adapter to the soundbar's power input and then plug it into a wall outlet.
- HDMI Connection (Recommended):** For optimal audio quality, connect an HDMI cable from the

soundbar's HDMI OUT (TV eARC/ARC) port to your TV's HDMI IN (eARC/ARC) port. This enables advanced audio features like Dolby Atmos and Q-Symphony.

3. **Optical Connection:** If your TV does not support HDMI ARC/eARC, connect an optical cable from the soundbar's DIGITAL AUDIO IN (OPTICAL) port to your TV's optical digital audio output port.
4. **Bluetooth Connection:** For wireless audio from mobile devices, refer to the 'Bluetooth Pairing' section under Operating.



Image: Rear view of the Samsung HW-S60B/ZC Soundbar. This image shows the back panel of the soundbar, detailing the various input and output ports for power, HDMI, and optical connections.

## 4. Initial Power On

After connecting the power, press the Power button on the soundbar or the remote control to turn on the device. The display will indicate the current input source.

## Operating

### 1. Basic Controls

- **Power:** Press to turn the soundbar on or off.
- **Volume:** Use the Volume Up/Down buttons on the remote or soundbar to adjust the audio level.
- **Source:** Press the Source button to cycle through available input sources (HDMI, Optical, Bluetooth).

### 2. Sound Modes

The soundbar offers various sound modes to enhance your listening experience:

- **Dolby Atmos / DTS Virtual:X:** Provides immersive 3D audio. This mode activates automatically when compatible content is played via HDMI.
- **Adaptive Sound:** Optimizes audio based on content, enhancing voice clarity.
- **Game Mode:** Synchronizes directional audio for an enhanced gaming experience.

## Wireless Dolby Atmos

Object based audio formats Dolby Atmos is incorporated wirelessly for the first time into Samsung Soundbars. Experience the ultimate 3D sound from Dolby Atmos for all sorts of content including movie and music, without HDMI cables.

\* Wireless Dolby Atmos transmission via Wi-Fi, works with (selected) 2022 Samsung TVs  
\*\* Dolby Atmos and DTS:X applies to all 2022 Q Series Soundbars.  
\*\*\* Dolby Atmos and Virtual:X source content required.



Image: Diagram illustrating Wireless Dolby Atmos and DTS Virtual:X logos. This graphic highlights the soundbar's support for advanced audio formats, indicating immersive sound capabilities.

### 3. Bluetooth Pairing

1. Press the Source button on the soundbar or remote until 'BT' (Bluetooth) is displayed.
2. On your mobile device, navigate to Bluetooth settings and select 'Samsung Soundbar HW-S60B' from the list of available devices.
3. Once connected, the soundbar will indicate successful pairing, and you can play audio from your device.

### 4. Q-Symphony (with compatible Samsung TVs)

If you have a compatible Samsung TV (2022 model or newer), Q-Symphony allows the TV speakers and soundbar to operate simultaneously for a more expansive soundstage. Ensure your TV is connected via HDMI ARC/eARC and enable Q-Symphony in your TV's sound settings.

#### Q-Symphony

Q-Symphony is one of the Samsung's exclusive technologies. It enables both TV speakers and Soundbar to work simultaneously, creating the ultimate sound synergy.

\* Q-Symphony is compatible with selected Samsung TVs.  
\*\* Features may not be compatible with all Samsung TVs. Check for product specifications by TV model.  
\*\*\* Function requires HDMI, Optical or Wi-Fi connection to TV.  
\*\*\*\* TV sold separately.



Image: Diagram comparing conventional sound with Q-Symphony sound. This graphic visually represents how Q-Symphony integrates TV and soundbar speakers for a richer audio experience.

### 5. Built-in Center Speaker

The integrated center speaker enhances dialogue clarity, ensuring that vocals are distinct even during complex audio scenes.



### Built-in center speaker

The built-in center channel speaker provides optimal sound experience and delivers dialogue more clearly by enhancing the human voice.

Image: Soundbar below a TV, illustrating sound waves from the center speaker. This image demonstrates the function of the built-in center speaker in clarifying dialogue.

## Maintenance

### 1. Cleaning

To clean the soundbar, use a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical sprays, as these can damage the finish or internal components.

### 2. Storage

If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place, preferably in its original packaging.

## Troubleshooting

Problem	Solution
No sound from soundbar.	<ul style="list-style-type: none"><li>• Ensure the soundbar is powered on.</li><li>• Verify the correct input source is selected.</li><li>• Check all cable connections (HDMI, Optical).</li><li>• Increase the volume on both the soundbar and your TV/source device.</li></ul>
Poor sound quality.	<ul style="list-style-type: none"><li>• Check for loose cable connections.</li><li>• Ensure the soundbar is not obstructed.</li><li>• Adjust sound modes or equalizer settings.</li></ul>
Bluetooth device cannot connect.	<ul style="list-style-type: none"><li>• Ensure the soundbar is in Bluetooth pairing mode.</li><li>• Move the Bluetooth device closer to the soundbar.</li><li>• Remove previous Bluetooth pairings from your device and try again.</li></ul>

Problem	Solution
Remote control not working.	<ul style="list-style-type: none"> <li>• Replace the batteries (2 AAA batteries required).</li> <li>• Ensure there are no obstructions between the remote and the soundbar.</li> </ul>

## Specifications

Feature	Detail
Model Name	HW-S60B/ZC
Speaker Type	Soundbar
Channels	3.1ch (5.0 surround sound channel configuration)
Special Features	Bluetooth, Wireless, Dolby Atmos, DTS Virtual:X, Q-Symphony, Adaptive Sound, Game Mode
Connectivity	Bluetooth, HDMI (eARC/ARC), Optical
Control Method	Remote Control, Voice
Speaker Maximum Output Power	200 Watts
Item Weight	2.7 Kilograms
Product Dimensions	1 x 1 x 1 cm
Included Components	Remote Control TM2261S, Power Adapter, HDMI cable, Wall Mount Kit

## Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Samsung website. You can find detailed support resources, FAQs, and contact information there.

**Samsung Official Website:** [www.samsung.com](http://www.samsung.com)