



[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM Manual Recliner Armchair User Manual - Model 839-339BG

## HOMCOM 839-339BG

# HOMCOM Manual Recliner Armchair User Manual

Brand: HOMCOM | Model: 839-339BG

### INTRODUCTION AND SAFETY INFORMATION

This manual provides instructions for the assembly, operation, and maintenance of your HOMCOM Manual Recliner Armchair. Please read all instructions carefully before assembly and use to ensure safe and correct operation.



Image: The HOMCOM Manual Recliner Armchair, showcasing its design and presence in a typical home environment.

### **Important Safety Warnings:**

- This armchair has a maximum weight capacity of 150 kg (330 lbs). Do not exceed this limit.
- Ensure correct assembly by following all instructions precisely. Improper assembly can lead to instability and injury.
- Be aware of the armchair's stability when reclining. Avoid sudden movements or excessive force.
- Keep children and pets away from moving parts during operation.
- Regularly check all bolts and fasteners to ensure they are tight. Retighten if necessary.

### **SETUP AND ASSEMBLY**

Assembly is required for this product. Please ensure all components are present before beginning. It is recommended to assemble the armchair on a soft, clean surface to prevent damage.

### **Components Included:**

- 1 x Backrest
- 1 x Seat
- 2 x Armrests

- Hardware pack (screws, washers, Allen key, etc.)

### Assembly Steps:

1. Unpack all components and verify against the included parts list.
2. Attach the armrests to the seat base using the provided hardware. Ensure they are securely fastened.
3. Slide the backrest onto the metal brackets located at the rear of the seat base until it clicks into place. Ensure a firm connection.
4. Once assembled, gently test the stability of the armchair before full use.

### OPERATING INSTRUCTIONS

Your HOMCOM Manual Recliner Armchair is designed for comfortable relaxation with a simple manual reclining mechanism.



Image: Visual representation of the armchair's various positions: upright for working, partially reclined for relaxing, and fully reclined for napping.

### Reclining the Armchair:

1. To recline, push back gently against the backrest while applying slight pressure with your feet on the

footrest. The armchair will smoothly recline up to 135 degrees.

2. The integrated footrest will extend as you recline, providing leg support.
3. To return to the upright position, lean forward and push the footrest down with your legs until it locks into place. The backrest will follow.

### Using the Side Pockets:

The armchair features practical side pockets on the armrests. These are designed for convenient storage of small items such as remote controls, mobile phones, or reading materials.



Image: Detailed views highlighting the padded armrests, high backrest, comfortable headrest, and functional side pockets for storage.

## MAINTENANCE AND CARE

Proper care will extend the life and appearance of your recliner armchair.

### Cleaning Instructions:

- For general cleaning, wipe the velvet fabric with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals.
- For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- Vacuum the armchair regularly using an upholstery attachment to remove dust and debris.

## General Care:

- Avoid direct sunlight exposure to prevent fading of the fabric.
- Keep the armchair away from heat sources like radiators or fireplaces.
- Periodically check and tighten all assembly hardware to ensure stability.

## TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Armchair does not recline smoothly or is difficult to recline.	Mechanism obstruction; insufficient force applied; loose connections.	Check for any objects obstructing the reclining mechanism. Ensure you are applying firm, consistent pressure to the backrest and footrest. Verify all assembly bolts are tight.
Armchair feels unstable or wobbly.	Loose assembly hardware.	Inspect all bolts and screws. Tighten any loose fasteners. Ensure the backrest is fully engaged with the seat base.
Footrest does not retract fully.	Mechanism obstruction; lack of downward pressure.	Check for obstructions. Apply firm downward pressure with your legs until the footrest locks into the closed position.

If the problem persists, please contact customer support.

## SPECIFICATIONS



Image: Detailed dimensions of the armchair in both upright and reclined positions, including seat height and width, and maximum weight capacity.

Feature	Detail
Brand	HOMCOM
Model Number	839-339BG
Color	Beige
Material	Polyester, Foam, Metal
Overall Dimensions (Upright)	88W x 91D x 108H cm (34.6"W x 35.8"D x 42.5"H)
Reclined Dimensions	91W x 163D x 86H cm (35.8"W x 64.2"D x 33.9"H)
Seat Dimensions	49W x 54D x 49H cm (19.3"W x 21.3"D x 19.3"H)
Item Weight	27.6 kg (60.8 lbs)

Feature	Detail
Maximum Supported Weight	150 kg (330 lbs)
Reclining Angle	Up to 135°
Assembly Required	Yes
Special Features	Ergonomic design, Padded armrests, High backrest, Integrated headrest, Side pockets

## WARRANTY INFORMATION

Specific warranty details for your HOMCOM Manual Recliner Armchair are typically provided at the point of purchase or included with the product packaging. Please refer to your purchase receipt or contact the retailer for information regarding warranty coverage, terms, and conditions.

Generally, warranties cover manufacturing defects under normal use. Damage resulting from improper assembly, misuse, or neglect is usually not covered.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact HOMCOM customer service or your retailer.

When contacting support, please have your product model number (839-339BG) and proof of purchase readily available to expedite the process.

For more information about HOMCOM products, you may visit the official HOMCOM store online.