

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BAOFENG](#) /

› [BAOFENG AR-152 Tactical Speaker Microphone User Manual](#)

BAOFENG AR-152

BAOFENG AR-152 Tactical Speaker Microphone User Manual

Model: AR-152 | Brand: BAOFENG

Introduction Product

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the BAOFENG AR-152 Tactical Speaker Microphone. Designed for enhanced communication, this accessory offers clear audio transmission and reception, a volume adjustment feature, and compatibility with various BAOFENG two-way radios. Please read this manual thoroughly to ensure proper use and maintenance of your device.

2. PRODUCT OVERVIEW

2.1 Key Features

- Enhanced Voice Transmission:** High-quality speaker and microphone units for clear audio.
- Adjustable Volume:** Integrated volume control button on the speaker microphone for convenient sound level adjustment.
- Durable PU Material Cable:** 5mm diameter wire with improved ductility, allowing for flexible placement of the radio.
- 3.5mm Headphone Jack:** Allows connection of an earpiece for discreet communication in various environments.
- Wide Compatibility:** Compatible with BAOFENG AR-152, UV-5R, UV-82, BF-888S, BF-F8+, UV-S9 PLUS, BF-F9 V2+, GT-3TP, and similar models.
- 360° Rotating Clip:** For secure and flexible attachment to clothing or gear.

2.2 Components

- BAOFENG AR-152 Tactical Speaker Microphone
- Acoustic Tube Earpiece (with clip)
- 2-Pin K Type Connector Cable



Figure 2.1: Overview of the BAOFENG AR-152 Tactical Speaker Microphone with included earpiece and radio connector.



Figure 2.2: Detailed view highlighting the volume adjustment button and the 3.5mm headphone jack on the speaker microphone.

3. SETUP

1. Connect to Radio:

Align the 2-pin K type connector of the speaker microphone with the corresponding ports on your compatible BAOFENG radio. Ensure the pins are correctly oriented (3.5mm and 2.5mm jacks, 11mm apart) and push firmly until securely connected.



Figure 3.1: Proper connection of the speaker microphone to a compatible two-way radio.

2. Attach Earpiece (Optional):

If using the acoustic tube earpiece, insert its 3.5mm plug into the 3.5mm headphone jack located on the side of the speaker microphone. Ensure the earpiece is securely connected. The earpiece features a rotatable clip for comfortable positioning.



Figure 3.2: Steps for connecting the acoustic tube earpiece.

3. Secure the Microphone:

Use the 360° rotating clip on the back of the speaker microphone to attach it to your collar, lapel, or other convenient location for easy access and clear communication.



Figure 3.3: The 360° rotating clip for flexible attachment.

4. OPERATING INSTRUCTIONS

- Power On/Off:** The speaker microphone draws power from the connected radio. Ensure your radio is powered on.
- Transmit (PTT):** To transmit your voice, press and hold the Push-To-Talk (PTT) button located on the side of the speaker microphone. Speak clearly into the microphone grille. Release the PTT button to stop transmitting and return to receive mode.
- Receive Audio:** Audio from the radio will be output through the speaker on the microphone. If an earpiece is connected, audio will be routed to the earpiece for private listening.
- Adjust Volume:** Rotate the volume adjustment knob, typically located near the speaker grille, to increase or decrease the audio output level. This allows for fine-tuning the listening volume directly from the microphone unit.
- Using the Earpiece:** When the acoustic tube earpiece is connected, it provides discreet audio reception. Position the earpiece comfortably in your ear.



Figure 4.1: Location of the volume adjustment button on the speaker microphone.

5. MAINTENANCE

- **Cleaning:** Wipe the speaker microphone and cable with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure no moisture enters the microphone grille or connector ports.
- **Cable Care:** Avoid sharp bends, kinks, or excessive pulling on the cable to prevent internal damage. The PU material cable is designed for durability, but proper handling extends its lifespan.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Connector Inspection:** Periodically check the 2-pin connector for any signs of wear, corrosion, or bent pins.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No audio from speaker/earpiece.	Microphone not fully connected. Radio volume too low. Speaker microphone volume too low. Earpiece not fully connected.	Ensure the 2-pin connector is firmly seated in the radio. Increase the volume on your radio. Rotate the volume adjustment knob on the speaker microphone clockwise. Ensure the 3.5mm earpiece jack is fully inserted.
Transmit audio is low or muffled.	Speaking too far from the microphone. Microphone grille obstructed. Radio settings (VOX, mic gain) incorrect.	Speak directly into the microphone grille. Check for and clear any debris from the microphone grille. Consult your radio's manual to adjust microphone gain settings.
Intermittent connection.	Loose connector. Damaged cable or connector pins.	Reseat all connectors firmly. Inspect the cable and pins for visible damage. If damaged, replacement may be necessary.

7. SPECIFICATIONS

Feature	Detail
Brand	BAOFENG
Model Name	AR-152
Microphone Form Factor	Lavalier
Connectivity Technology	Auxiliary
Connector Type	2-Pin K Type (3.5mm & 2.5mm jacks)
Special Feature	Volume Adjustment, 360° Rotating Clip
Compatible Devices	BAOFENG AR-152, UV-5R, UV-82, BF-888S, BF-F8+, UV-S9 PLUS, BF-F9 V2+, GT-3TP, etc.
Material	Metal (housing), PU (cable)
Item Weight	5.9 ounces
Package Dimensions	7.05 x 5.31 x 1.97 inches
Included Components	1X Speaker Microphone

8. WARRANTY AND SUPPORT

This product is typically covered by a standard manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support, troubleshooting assistance, or to inquire about replacement

parts, please contact BAOFENG customer service through their official website or the retailer from whom you purchased the product.

For further information, you may visit the [BAOFENG Store on Amazon](#).

© 2023 BAOFENG. All rights reserved.
Information in this manual is subject to change without notice.

Related Documents - AR-152

	<p>Baofeng UV-5R Programming Guide: CHIRP & Manufacturer Software</p> <p>A comprehensive guide to programming Baofeng UV-5R series radios using CHIRP software and the manufacturer's programming tool. Covers system requirements, software installation, connection, and parameter settings.</p>
	<p>Baofeng UV-5R Programming Guide: Step-by-Step Instructions</p> <p>Learn how to program your Baofeng UV-5R, UV-5RA, UV-5X3, GT-3, BF-F8, BF-F9 two-way radios with this step-by-step guide for setting up repeaters and simplex frequencies.</p>
	<p>Baofeng UV-5R Series Two-Way Radio User Manual</p> <p>Comprehensive user manual for Baofeng (Pofung) UV-5R series two-way radios and compatible models. Covers safety, features, unpacking, assembly, battery charging, controls, LCD display, menu settings, technical specifications, and troubleshooting. Includes details on antenna installation, battery usage, and advanced functions like VOX, Squelch, and DTMF tones.</p>
	<p>Baofeng HT Radio Manual Programming Guide: UV-5R, BF-F8HP, and More</p> <p>A comprehensive guide to manually programming memory channels on Baofeng HT radios, including models like UV-5R, UV-6R, BF-F8, GT3, BF-F8HP, UV-5X3, and UV-82 series. Learn simplex and duplex channel setup, menu options, and troubleshooting.</p>
	<p>The Baofeng Radio Bible: Master Your Baofeng Radio for Any Scenario</p> <p>A comprehensive guide to mastering Baofeng radios, covering features, programming, emergency preparedness, and advanced communication techniques for various scenarios including natural disasters and wartime.</p>

Kabel USB do Baofeng UV-5R, UV-82, UV-6R, BF-888s



[Programowanie Radiotelefonów Baofeng za pomocą Oprogramowania CHIRP](#)

Przewodnik krok po kroku dotyczący programowania radiotelefonów Baofeng UV-5R, UV-82, UV-6R, BF-888s przy użyciu kabla USB i oprogramowania CHIRP. Zawiera instrukcje instalacji sterowników, podłączania, konfiguracji pamięci i ustawień zaawansowanych.

Documents - BAOFENG – AR-152



[RT Systems Product Guide 2024: Radio Programming Software](#)

Explore the comprehensive 2024 product guide from RT Systems, detailing their radio programming software and USB cables. Learn about features, compatibility, and how to enhance your radio experience.

lang:en score:23 filesize: 21.89 M page_count: 43 document date: 2024-04-26