

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS YPF-G9919ZP-MH Square Chronograph Watch User Manual

OLEVS YPF-G9919ZP-MH

OLEVS YPF-G9919ZP-MH Square Chronograph Watch User Manual

Model: YPF-G9919ZP-MH

1. INTRODUCTION

Thank you for choosing the OLEVS YPF-G9919ZP-MH Square Chronograph Watch. This manual provides detailed instructions for the proper use, maintenance, and care of your new timepiece. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.





Figure 1: OLEVS YPF-G9919ZP-MH Square Chronograph Watch. This image displays the watch face with its square design, chronograph sub-dials, and brown leather strap.

2. PRODUCT OVERVIEW

The OLEVS YPF-G9919ZP-MH watch features a square case, a multi-function chronograph, 12/24 dual time display, and a calendar window. It is equipped with an original quartz movement for accurate timekeeping and a comfortable leather strap. The watch also includes a luminous function for visibility in low light conditions and is water-resistant.



Figure 2: Watch Dial and Controls. This diagram illustrates the main components of the watch face, including the crown, pushers, 24-hour sub-dial (3 o'clock position), chrono seconds sub-dial (6 o'clock position), chrono minute sub-dial (9 o'clock position), and date window (4-5 o'clock position).

Key Components:

- **Crown:** Used for setting time and date.
- **Pushers:** Used to operate the chronograph functions.
- **24-Hour Sub-dial:** Displays time in a 24-hour format (located at 3 o'clock).
- **Chrono Seconds Sub-dial:** Measures seconds during chronograph operation (located at 6 o'clock).
- **Chrono Minute Sub-dial:** Measures minutes during chronograph operation (located at 9 o'clock).
- **Date Window:** Displays the current date (located between 4 and 5 o'clock).
- **Luminous Hands and Markers:** Provide visibility in low light.

3. SETUP AND INITIAL ADJUSTMENT

3.1 Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to adjust the hour and minute hands to the desired time. Ensure the 24-hour sub-dial also reflects the correct AM/PM.
3. Push the crown back to the normal position.

3.2 Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date in the date window.
3. Push the crown back to the normal position.
4. **Note:** To avoid issues, do not set the date between 9:00 PM and 3:00 AM, as this is when the watch's internal

mechanism is engaged in changing the date.

3.3 Operating the Chronograph

1. **Start:** Press the top pusher to start the chronograph. The chrono seconds hand will begin to move.
2. **Stop:** Press the top pusher again to stop the chronograph. The elapsed time will be displayed on the sub-dials.
3. **Reset:** Press the bottom pusher to reset the chronograph. All chronograph hands will return to their zero positions.

4. OPERATING YOUR WATCH

4.1 Luminous Function

The watch hands and markers are coated with a luminous material. After exposure to light, they will glow in the dark, allowing for easy time reading. The intensity and duration of the glow depend on the exposure time and intensity of light.



Figure 3: Luminous Display. This image shows the watch face with its hands and hour markers glowing brightly in a dark environment, demonstrating the luminous function.

4.2 Water Resistance

This watch is water-resistant to 30 meters (3ATM), meaning it can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or hot water activities (e.g., hot showers, saunas), as extreme temperature changes and steam can compromise the water seals.



Figure 4: Water Resistance Demonstration. The image shows the watch with water droplets on its surface, illustrating its resistance to splashes and rain.

4.3 Official Product Video

Watch this official video from the seller for a dynamic overview of the OLEVS YPF-G9919ZP-MH watch's features and design.

Your browser does not support the video tag.

Video 1: OLEVS Square Watches for Men. This video showcases the watch's design, chronograph functions, and overall aesthetic, highlighting its suitability for various occasions.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt. For the leather strap, avoid excessive moisture and harsh chemicals.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures, direct sunlight for prolonged periods, and strong magnetic fields, which can affect accuracy.
- **Chemicals:** Avoid contact with solvents, detergents, perfumes, and cosmetic products, as they can damage the case, strap, or seals.
- **Battery Replacement:** The watch uses a high-quality battery with a life of up to 3 years. When the battery needs replacement, it is recommended to take the watch to a qualified watch technician to ensure proper sealing and function.
- **Strap Care:** The brown leather strap is designed for comfort and durability. To prolong its life, avoid prolonged exposure to water and sweat, and allow it to air dry if it gets wet.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace the battery (recommended by a professional).
Incorrect time/date	Time/date not set correctly or crown is pulled out.	Ensure the crown is pushed in completely. Re-set time and date as per Section 3.
Chronograph hands not resetting to zero	Requires calibration.	Consult a watch technician for calibration.
Fogging under crystal	Exposure to extreme temperature changes or compromised water resistance.	Avoid extreme temperature changes. If fogging persists, have the watch inspected by a professional.

7. SPECIFICATIONS

Feature	Detail
Brand	OLEVS
Model Number	YPF-G9919ZP-MH
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	42 Millimeters
Case Thickness	12 Millimeters
Band Material	Leather
Band Width	12 Millimeters
Band Length	250 Millimeters
Clasp Type	Buckle
Crystal Material	Synthetic Sapphire
Water Resistance Depth	30 Meters (100 Feet)
Special Features	Chronograph, Date, Luminous, 12/24 Hour Display
Item Weight	88 Grams



Figure 5: Watch Back Engravings. This image shows the stainless steel back of the watch, engraved with the OLEVS logo, "STAINLESS STEEL BACK", "WATER RESISTANT", and model number "OLS9919".

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your OLEVS YPF-G9919ZP-MH watch comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear (e.g., battery, strap, crystal scratches).

8.2 Customer Support

For any questions, concerns, or warranty claims regarding your watch, please contact the seller through the Amazon platform where the purchase was made. They will be able to provide assistance and guide you through the necessary steps.

© 2026 OLEVS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09Y8ZY9NK>

More documents and user manuals: <https://manuals.plus/>