



Manuals.plus /

› Navitech /

› Navitech Keyboard Case for Pritom TronPad L10 10" Tablet User Manual

Navitech Keyboard Case for Pritom TronPad L10 10" Tablet

Navitech Keyboard Case for Pritom TronPad L10 10" Tablet User Manual

1. INTRODUCTION

This manual provides instructions for the Navitech Black Keyboard Case, designed for use with the Pritom TronPad L10 10-inch Tablet. This accessory transforms your tablet into a laptop-like experience, offering both protection and enhanced functionality. Please read this manual thoroughly before using the product.

2. PRODUCT FEATURES

- **Real Laptop-Style Keyboard:** Provides a tactile typing experience similar to a traditional laptop keyboard.
- **Integrated Kickstand:** Allows for comfortable viewing and typing angles, mimicking a laptop setup.
- **Plug and Play Connectivity:** Requires minimal power from your tablet and does not require batteries for the keyboard.
- **Protective Case:** Safeguards your tablet from bumps and shocks.



Image 2.1: The Navitech Keyboard Case with a tablet inserted, demonstrating the kickstand in an upright position for viewing or typing.

3. SETUP INSTRUCTIONS

1. **Insert Tablet:** Carefully slide your Pritom TronPad L10 10-inch tablet into the designated frame within the case. Ensure all ports and buttons are accessible and not obstructed.
2. **Connect Keyboard:** Locate the keyboard connector (typically a USB-A or USB-C plug, depending on your tablet's port) and insert it into the corresponding port on your tablet. The keyboard draws power directly from the tablet.
3. **Position Kickstand:** Extend the integrated kickstand on the back of the case to prop up your tablet to a comfortable viewing or typing angle.



Image 3.1: Side view of the keyboard case showing the kickstand fully extended, providing stability for the tablet.



Image 3.2: Rear view of the keyboard case, illustrating the kickstand mechanism that supports the tablet.

4. OPERATING INSTRUCTIONS

Once connected, the keyboard functions as a standard external input device for your tablet. No additional

software or drivers are typically required.

4.1 Basic Keyboard Functions

- **Typing:** Use the keys as you would on a standard computer keyboard for text input.
- **Function Keys (Fn):** Some keys may have secondary functions (e.g., volume control, screen brightness) accessible by holding down the 'Fn' key and pressing the corresponding function key (F1-F12). Refer to your tablet's documentation for specific compatibility with external keyboard function keys.



Image 4.1: A detailed view of the keyboard layout, showing the arrangement of keys and function key labels.

5. MAINTENANCE

5.1 Cleaning

- **Exterior Case:** Wipe the exterior of the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Keyboard:** Use a soft, dry brush or compressed air to remove dust and debris from between the keys. For stubborn marks, lightly dampen a cloth with water or a mild cleaning solution and gently wipe the keycaps. Ensure no liquid enters the keyboard mechanism.

5.2 Storage

When not in use, close the case to protect both the tablet and the keyboard. The case features a magnetic closure to keep it securely shut.



Image 5.1: The keyboard case in its closed position, secured by the magnetic flap, providing full protection for the tablet and keyboard.

6. TROUBLESHOOTING

- **Keyboard Not Responding:**
 - Ensure the keyboard connector is fully and securely plugged into your tablet's port.
 - Try unplugging and re-plugging the connector.
 - Restart your tablet.
 - Verify that your tablet's operating system supports external USB keyboards.
- **Keys Not Functioning Correctly:**
 - Check for any debris or obstructions under the keys.
 - Ensure the keyboard is clean (refer to Maintenance section).

7. SPECIFICATIONS

Feature	Detail
Brand	Navitech
Compatible Devices	Pritom TronPad L10 10" Tablet
Color	Black
Form Factor	Case
Special Features	Kickstand
Shell Type	Hybrid

8. WARRANTY AND SUPPORT

This Navitech Keyboard Case is covered by a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims or technical support, please contact your retailer or the Navitech customer service department through their official website or contact channels provided at the time of purchase. Please retain your proof of purchase for warranty validation.