



Manuals.plus /

- › COBIZI /
- › COBIZI 10x10 Pop Up Canopy Tent with 4 Sidewalls Instruction Manual

## COBIZI 10x10 Pop Up Canopy Tent with 4 Sidewalls

# COBIZI 10x10 Pop Up Canopy Tent with 4 Sidewalls Instruction Manual

Model: 10x10 Pop Up Canopy Tent with 4 Sidewalls

Brand: COBIZI

## INTRODUCTION

This instruction manual provides essential information for the safe and effective setup, operation, and maintenance of your COBIZI 10x10 Pop Up Canopy Tent with 4 Sidewalls. Please read this manual thoroughly before assembly and retain it for future reference.




Image: The COBIZI 10x10 Pop Up Canopy Tent with 4 Sidewalls, showcasing its robust frame and included accessories.

## PACKING LIST

Verify that all components are present before beginning assembly:

- 1x 10x10 Commercial Pop-up Canopy Frame
- 1x 10x10 Canopy Top Cover
- 4x PU coated Panels (3x Sidewalls with Window and 1x Sidewall with Zipper)
- 4x 420D Oxford cloth PVC coated Sandbags
- 8x Ground Pegs
- 4x Wind Ropes
- 1x Wheeled Bag
- 1x Manual

# PACKING LIST



Image: Visual representation of all components included in the COBIZI 10x10 Pop Up Canopy Tent package.

## SETUP INSTRUCTIONS

The COBIZI 10x10 Pop Up Canopy Tent is designed for quick and easy assembly by 1-2 people without tools.

1. **Step 1: Extend the Frame**

Remove the fully assembled frame from the wheeled bag. With a partner, partially extend the frame to about 50% of its full width.

2. **Step 2: Attach the Canopy Top Cover**

Place the canopy top cover over the partially extended frame. Ensure the cover is correctly oriented and secure it to the frame using the hook and loop tape straps located at each corner and along the frame.

3. **Step 3: Fully Extend and Lock the Frame**

With the canopy top in place, fully pull the frame apart until the sliding hub locks into place at each corner. Secure the thumb buttons on the legs to lock the frame at the desired height.

4. **Step 4: Adjust Height**

The canopy features 3 adjustable height positions (84", 88", 91"). Press the thumb button on each leg and slide the leg to the desired height until it clicks into place. Ensure all four legs are adjusted to the same height for stability.


5. **Step 5: Attach Sidewalls (Optional)**

Attach the PU coated removable sidewalls using the full strip of hook and loop fastener at the top and zippers along the vertical edges. The sidewalls can be configured as needed, with window panels or a zippered entry panel.

6. **Step 6: Secure the Canopy**


For increased stability, especially in windy conditions, use the provided sandbags, ground pegs, and wind ropes. Fill the sandbags and attach them to the canopy legs. Insert ground pegs through the feet of the legs and use wind ropes to anchor the canopy to the ground.

## Instant Set Up - Tool Free



### Step 1

Open the canopy frame



### Step 2

Push up the steel frame until the sliding hub lock into place



### Step 3

Fit the canopy with welcro straps attached and adjust the height



Image: Illustrated steps for setting up the COBIZI 10x10 Pop Up Canopy Tent.

## Setup and Feature Videos

Your browser does not support the video tag.

Video: Demonstrates the general setup process and features of the COBIZI 10x10 Heavy Duty Pop Up Canopy Tent with 4 Sidewalls.

Your browser does not support the video tag.

Video: Shows the 3-height adjustment mechanism of the COBIZI 10x10 Heavy Duty Canopy.

Your browser does not support the video tag.

Video: Details the attachment of the reinforced canopy and removable sidewalls.

## OPERATING AND FEATURES

---

The COBIZI 10x10 Pop Up Canopy Tent is engineered for durability and versatility, suitable for various outdoor events.

- **Heavy Duty Frame:** Features a full truss construction with powder-coated steel, offering durability and rust resistance. The 1.26" pipe diameter and 0.03" wall thickness provide enhanced strength, capable of holding up to 220 lbs on a single pole and withstanding up to Level 4 wind (18 mph) when properly secured.
- **Premium Canopy and Sidewalls:** Made from 420D high-quality Oxford fabric with two layers of PU coating, providing UPF 50+ sun protection (blocks 99% of UV rays) and 100% waterproofing (2.1psi waterproof pressure). The 4 removable sidewalls are connected by hook and loop fasteners and zippers.
- **Adjustable Height:** Easily adjust the canopy to 3 different heights (84", 88", 91") using the upgraded thumb latch system, designed to protect fingers from pinching.
- **Portable Design:** Weighing 62 pounds, the canopy comes with a durable wheeled bag featuring 2 solid rubber wheels and a reinforced handle for easy transport and storage.

# Patio BBQ Gazebo Shelter

## 10X10FT



**Waterproof**  
420D oxford fabric  
and double layer coating



**Corner protection**  
Thumb button design improves  
corner stability while also helping  
faster fixation and release



**Strong full  
truss structure**  
for to upgrde the  
truss strength



**Adjustable  
Height Setting**  
3 adjustable heights to  
meet your different demands



**Heavy duty Material**  
1. Powder-coated aluminum frame  
for excellent rust resistance  
2. New thickened and weighted  
design



Image: Detailed view of the canopy's waterproof fabric, corner protection, truss structure, adjustable height, and heavy-duty materials.

## Frame Strength Demonstration

Your browser does not support the video tag.

Video: A short demonstration of the COBIZI 10x10 canopy tent's frame strength through a product hanging test.

## SPECIFICATIONS

Attribute	Detail
Brand	COBIZI
Material	Steel, Oxford fabric with PU coating
Item Weight	62 Pounds
Product Dimensions	10x10 feet (1584"H)
Ultraviolet Light Protection	Yes (UPF 50+)
Water Resistance Level	Waterproof
Pole Material Type	Alloy Steel
Floor Area	100 Square Feet
Max Ceiling Height	91 Inches
Occupancy	10 Person
Assembly Required	Yes

## SAFETY GUIDELINES

To ensure safe use and longevity of your canopy tent, please adhere to the following guidelines:

- Always anchor the tent securely to the ground using the provided ropes, sandbags, and stakes, especially in windy conditions.
- Do not use the tent during extreme weather conditions, including high winds or storms.
- This tent provides UPF 50+ UV protection, but users should still take precautions against sun exposure, such as wearing protective clothing, using sunscreen, and staying hydrated.
- Inspect the tent for any signs of damage or wear before each use.
- Always follow the manufacturer's instructions for setup, use, and dismantling to ensure the tent's structural integrity.

## MAINTENANCE

Proper maintenance will extend the life of your COBIZI canopy tent:

- Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners.
- Ensure the canopy and sidewalls are completely dry before folding and storing to prevent mold and mildew.
- Store the tent in its wheeled bag in a cool, dry place away from direct sunlight when not in use.

- Regularly check all frame connections and fasteners for tightness and wear.

## SUPPORT

---

For any questions, concerns, or assistance with your COBIZI 10x10 Pop Up Canopy Tent, please contact our customer service team. We are committed to providing the best service and will respond to your inquiries within 24 hours.

Contact information can typically be found on your purchase receipt or the COBIZI official website.