

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [VOYSIGN](#) /

> [VOYSIGN Patio Bistro Side Table VS01ST003N-7 Instruction Manual](#)

## VOYSIGN VS01ST003N-7

# VOYSIGN Patio Bistro Side Table Instruction Manual

Model: VS01ST003N-7 | Brand: VOYSIGN

## 1. INTRODUCTION

Thank you for choosing the VOYSIGN Patio Bistro Side Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new metal porch end table. Designed for both outdoor and indoor use, this table features a durable, modern slatted metal tabletop with advanced powder-coating technology, making it water-resistant, UV-resistant, and rust-resistant.

## 2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the table's weight capacity (specific capacity not provided, use general caution).
- Place the table on a flat, stable surface to prevent tipping.
- Keep children away from the assembly area and small parts.
- Avoid climbing or standing on the table.
- Do not place hot items directly on the table surface without protection.

## 3. PACKAGE CONTENTS

Please check that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Tabletop (1)
- Legs (4)
- Adjustable Feet (4)
- Screws/Bolts (Quantity as per design)
- Assembly Tool (e.g., Hex Key) (1)

## 4. SETUP AND ASSEMBLY

Assembly is designed to be fast and straightforward. Please follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs to Tabletop:** Align each leg with the designated attachment points on the underside of the tabletop. Insert the screws/bolts and hand-tighten them initially.




*Image: Detail of leg attachment during assembly.*

3. **Insert Adjustable Feet:** Screw the adjustable feet into the bottom of each leg.



*Image: Adjustable foot for leveling the table.*

4. **Final Tightening:** Once all screws are aligned and inserted, use the provided tool to fully tighten all screws. **Important:** Do not overtighten.
5. **Level the Table:** Place the table in its desired location. If the table wobbles, adjust the height of the adjustable feet until it is stable.



*Image: Fully assembled VOYSIGN Patio Bistro Side Table.*

## 5. OPERATING AND USAGE

The VOYSIGN Patio Bistro Side Table is versatile and suitable for various applications:

- Use as a snack table, end table, side table, or telephone table.
- Ideal for outdoor patios, porches, balconies, or indoor living spaces.
- Its durable construction and powder-coated finish provide resistance against water, UV rays, and rust, making it suitable for various weather conditions.

## 6. MAINTENANCE

Proper care will extend the life and appearance of your table.

- **Cleaning:** Wipe the table surface with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong chemical solvents, as these can damage the finish.
- **Weather Protection:** While the table is water and rust-resistant, storing it indoors or covering it during prolonged periods of harsh weather (heavy rain, snow, extreme sun) will help maintain its condition.

- **Regular Inspection:** Periodically check all screws and bolts to ensure they remain tight.



*Image: Water-resistant surface of the table.*

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Table wobbles after assembly.	Uneven floor surface or legs not properly adjusted/tightened.	Adjust the height of the adjustable feet on the bottom of the legs until the table is stable. Ensure all screws are securely tightened.
Screws do not align during assembly.	Parts are not correctly oriented or screws are overtightened prematurely.	Loosen all screws slightly, re-align the parts, and then hand-tighten all screws before fully tightening with the tool. Refer to assembly steps.

Problem	Possible Cause	Solution
Surface appears scratched or damaged.	Rough handling during assembly or use, or contact with sharp objects.	Minor scratches may be touched up with appropriate outdoor furniture paint. For significant damage, contact customer service.

## 8. SPECIFICATIONS

Feature	Detail
Brand	VOYSIGN
Model Number	VS01ST003N-7
Color	Black
Product Dimensions	48.26 x 48.26 x 43.18 cm (19 x 19 x 17 inches)
Item Weight	4.74 kg
Material	Alloy Steel
Top Material Type	Metal
Finish Type	Powder Coated
Special Features	Easy Assembly, Rust Resistant, Water Resistant, UV Resistant
Shape	Rectangular
Style	Modern
Product Care Instructions	Wipe with Damp Cloth



*Image: Dimensional diagram of the table.*

## 9. WARRANTY

---

This VOYSIGN Patio Bistro Side Table comes with a **15-month warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims or inquiries, please retain your proof of purchase and contact our customer service team.

## 10. CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please do not hesitate to contact VOYSIGN customer service. Our friendly customer service team is ready to assist you.

Please refer to the retailer's website or your purchase documentation for specific contact information.

