

- Manuals.plus /
- > Motorola /
- > Motorola Moto Edge 5G UW 256gb Nebula Blue for Verizon (Renewed) User Manual

Motorola MOTXT21411M

Motorola Moto Edge 5G UW User Manual

Brand: Motorola | Model: MOTXT21411M

PRODUCT OVERVIEW

The Motorola Edge 5G UW is designed for an exceptional mobile experience, combining a large, vibrant display with powerful camera capabilities and robust connectivity. Its 6.8-inch Max Vision FHD+ display offers an ultra-smooth 144Hz refresh rate and HDR10 support for vivid colors and improved brightness. The device is equipped with a 108MP ultra high-resolution main camera and a 32MP high-res front camera, capable of 4K video recording and enhanced low-light sensitivity. Powering this device is a 5000mAh battery, providing up to two days of usage, with TurboPower 30 charging for quick power-ups. Connectivity includes superfast 5G and Wi-Fi 6E, along with the 'Ready For' feature for seamless integration with larger screens.



Figure 1: Front and back view of the Motorola Moto Edge 5G UW smartphone.

SETUP

What's in the Box

- Motorola Moto Edge 5G UW Smartphone
- SIM Tray Ejector

Initial Setup

1. **Insert SIM Card:** Locate the SIM tray on the side of the device. Use the provided SIM tray ejector tool to open the tray. Insert your Verizon-compatible Nano-SIM card into the tray, ensuring proper orientation. Close the tray securely.
2. **Power On:** Press and hold the power button located on the side of the phone until the Motorola logo appears.
3. **Follow On-Screen Prompts:** The phone will guide you through the initial setup process, including language selection, Wi-Fi connection, Google account sign-in, and data transfer options.
4. **Carrier Compatibility:** This device is locked for activation to Verizon only. It supports 4G, VoLTE, and 5G Sub6 NSA (via software update). It can also be activated on Verizon Prepaid Plans. For detailed carrier compatibility, refer to Verizon's official documentation.



Figure 2: Front view of the Motorola Moto Edge 5G UW, showing the display.

OPERATING INSTRUCTIONS

Display and Navigation

- **6.8" Max Vision FHD+ Display:** Enjoy immersive viewing with a large screen and high resolution (1080x2460 pixels).
- **144Hz Refresh Rate:** Experience incredibly smooth scrolling, gaming, and video playback.
- **HDR10 Support:** Provides enhanced contrast and color accuracy for compatible content.
- **Touchscreen Interface:** Navigate the device using intuitive touch gestures.

Camera Features

- **108 MP Ultra High-Res Camera System:** Capture detailed photos and 4K videos with Ultra Pixel technology.
- **32 MP High-Res Selfies:** The front camera offers 4x the low-light sensitivity for bright and clear self-portraits, even at night.
- **Seamless Camera Switching:** For vlogging or dynamic content creation, switch between front and rear cameras while recording without interruption.

Battery and Charging

- **5000mAh Battery:** Provides extended usage, up to two days on a single charge.
- **TurboPower 30 Charging:** Quickly recharge your device, gaining hours of power in just minutes.

Connectivity

- **Superfast 5G:** Download content and stream with high speeds.
- **Wi-Fi 6E:** Connect to the latest generation of faster Wi-Fi networks for improved performance.
- **Ready For:** Wirelessly connect your phone to a TV or external display to play mobile games, make video calls, or use your phone's apps on a larger screen.
- **Wi-Fi Hotspot Ready:** Utilize the device as a mobile hotspot with 2.4 GHz and 5 GHz support.



Figure 3: Back view of the Motorola Moto Edge 5G UW, highlighting the camera module.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid abrasive materials or harsh chemicals.
- **Water Repellent Design:** The device features an IP52 water repellent design, offering protection against minor splashes and spills. It is not waterproof and should not be submerged in water.
- **Software Updates:** Regularly check for and install software updates to ensure optimal performance, security, and access to new features.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not let the battery completely drain frequently.



Figure 4: Side view of the Motorola Moto Edge 5G UW, showing the slim profile.

TROUBLESHOOTING

- **Device Not Responding:** If your phone is unresponsive, press and hold the power button for approximately 10-15 seconds to force a restart.

- **Connectivity Issues:** For Wi-Fi or cellular network problems, try toggling Airplane Mode on and off, restarting the device, or resetting network settings in the phone's settings menu.
- **App Malfunctions:** If an app is not working correctly, try clearing its cache and data in the app settings, or uninstalling and reinstalling the app.
- **Battery Drain:** Check battery usage in settings to identify apps consuming excessive power. Reduce screen brightness, disable unnecessary features like GPS or Bluetooth when not in use, and close background apps.
- **Camera Flash Not Working:** Ensure the flash setting in the camera app is enabled and not set to 'Off' or 'Auto' in conditions where it might not activate. If issues persist, a factory reset may be considered as a last resort after backing up data.

SPECIFICATIONS

Feature	Detail
Model Name	Motorola Moto Edge UW
Item Model Number	MOTXT21411M
Display Size	6.8 Inches
Display Resolution	2460 x 1080 pixels
Refresh Rate	144 Hz
Operating System	Android 11.0
RAM	6 GB
Main Camera Resolution	108 MP
Front Camera Resolution	32 MP
Battery Capacity	5000 mAh
Charging Time (TurboPower 30)	9 Hours usage in 10 minutes
Product Dimensions	7 x 4 x 1 inches
Item Weight	7.1 ounces
Color	Nebula Blue (256gb)
Special Features	Fast Charging Support, IP52 water repellent design, Smartphone, Water Resistant

WARRANTY AND SUPPORT

As a renewed product, this Motorola Moto Edge 5G UW is backed by the Amazon Renewed Guarantee. This typically provides a 90-day refund or replacement policy if the product does not work as expected. For specific details regarding your purchase, including warranty coverage and how to obtain support, please refer to the documentation provided by the seller, Tchrific Deals, or visit the [Amazon Renewed Store](#).

For technical assistance or further inquiries about your Motorola device, you may also visit the official Motorola support website or contact their customer service.

© 2023 Motorola. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B09YDMWFT1>

More documents and user manuals: <https://manuals.plus/>