EINSEO Male Masturbators

EINSEO Automatic Sucking Male Masturbator

User Instruction Manual

1. Product Overview

The EINSEO Automatic Sucking Male Masturbator is designed to provide an enhanced experience with its combination of vibration and suction functionalities. This device features a 3D realistic textured inner sleeve and offers app control for customizable use. It is constructed from premium TPE material for comfort and durability.



Image 1.1: The EINSEO Automatic Sucking Male Masturbator, demonstrating its app control capabilities.

2. Safety Information

Please read all safety instructions before first use and retain for future reference.

- This product is intended for adult use only.
- Do not use if the product or any component appears damaged.
- Discontinue use immediately if you experience any discomfort or pain.
- Clean the product thoroughly before and after each use as per the cleaning instructions.
- Only use water-based lubricants with this product. Oil-based lubricants may damage the TPE material.
- Keep out of reach of children and pets.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not immerse the main body (motor part) in water. The sleeve is removable and washable.

3. Package Contents

Verify that all items are present in your package:

- EINSEO Automatic Sucking Male Masturbator (Main Unit)
- Removable TPE Inner Sleeve
- USB Type-C Charging Cable
- User Manual (this document)

4. Features

- **Tightly Enclosing Suction Sensation:** Features a vacuum suction pump for an enveloping sensation.
- **Multiple Modes:** Offers 7 powerful vibration modes and 3 suction levels.
- **One-Button Climax Mode:** Combines intense suction with rhythmic vibrations.
- **Premium TPE Material:** Soft, stretchy, and 3D textured inner sleeve.
- **App Control:** Enhanced control with four modes: Recommended, Video, DIY, and Sound Control.
- **Low Noise Operation:** Dual-motor design engineered for quiet use (≤55dB).
- **Easy to Clean:** Removable sleeve for convenient cleaning.
- **USB Rechargeable:** Type-C USB quick charging, fully charges in 3 hours.
- **Discreet Packaging:** Shipped in private packaging.



Image 4.1: Overview of the 7 vibration and 3 suction modes, highlighting the internal motor.

Image 4.2: The ergonomic classic curve design of the device, engineered for a comfortable and secure grip during use.

5. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, fully charge the device using the provided USB Type-C cable. Refer to the 'Charging' section for details.
3. **Clean:** Clean the inner sleeve thoroughly before its first use. Refer to the 'Cleaning and Maintenance' section.
4. **Assemble:** Ensure the inner sleeve is correctly inserted into the main unit. The sleeve should fit snugly.

6. Operating Instructions

6.1 Basic Operation (Button Control)




Image 6.1: Control buttons and device dimensions.

1. **Power On/Off:** Long press the On/Off button (typically the top button) for 2 seconds to turn the device on or off.
2. **Vibration Modes:** Tap the 'Vibrating & One Climax Button' (usually the middle button) to cycle through the 7 vibration modes.
3. **Suction Modes:** Tap the 'Sucking Button' (usually the bottom button) to switch between the 3 suction speeds.
4. **Climax Mode:** A specific tap or long press on the 'Vibrating & One Climax Button' may activate a combined climax mode, as indicated by the product's specific design.

6.2 App Control

The device can be controlled via a dedicated smartphone application, offering advanced customization and interactive features.



Image 6.2: The device connected to the JOYHUB app on a smartphone, illustrating app-powered control.

1. **Download App:** Search for the 'JOYHUB' app on your smartphone's app store (iOS or Android).
2. **Connect Device:** Turn on the EINSEO device. Open the JOYHUB app and follow the on-screen instructions to connect your device via Bluetooth.
3. **Explore Modes:** The app typically offers four main control modes:
    - **Recommended Mode:** Pre-set patterns for various experiences.
    - **Video Mode:** Synchronizes sensations with compatible videos.
    - **DIY Mode:** Customize vibration and suction patterns by sliding your finger on the screen.
    - **Sound Control:** Device responds to ambient sounds or voice commands.



Image 6.3: Detailed view of the four app control modes available through the JOYHUB application.

7. Cleaning and Maintenance

Proper cleaning and maintenance are essential for hygiene and product longevity.



Image 7.1: Visual guide for disassembling the device into its main components for thorough cleaning.

1. **Disassembly:** Unscrew the motor part of the product by turning it to the right. Carefully pull out the inner sleeve. The vibrator component can also be removed.
2. **Clean Inner Sleeve:** Rinse the TPE inner sleeve thoroughly with warm water and a mild, toy-safe soap. Turn the sleeve inside out to ensure all textured areas are cleaned.
3. **Clean Main Unit:** The main unit (containing the motor and electronics) is **not waterproof**. Wipe it clean with a damp cloth or a wet wipe. **Do not rinse the motor part directly with water.**
4. **Drying:** Allow all components, especially the inner sleeve, to air dry completely before reassembly. Ensure no moisture remains in the main unit.
5. **Reassembly:** Once dry, carefully reinsert the vibrator and the inner sleeve into the main unit. Screw the motor part back on, ensuring it is tightly secured.
6. **Storage:** Store the clean and dry device in a cool, dry place, away from direct sunlight.



Image 7.2: Step-by-step instructions for cleaning the removable sleeve and the main unit.

8. Charging

The device is equipped with a Type-C USB charging port.



Image 8.1: The Type-C charging port and estimated charging duration.

- Connect the provided USB Type-C cable to the charging port on the device.
- Connect the other end of the cable to a standard USB power adapter (not included) or a computer USB port.
- The charging indicator light will illuminate during charging.
- A full charge typically takes approximately 3 hours.
- Once fully charged, the indicator light may change or turn off. Disconnect the charger.
- A full charge provides approximately 1 hour of continuous use.
- **Important:** Only use chargers provided by EINSEO or certified compatible chargers.

9. Troubleshooting

If you encounter issues with your EINSEO device, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Device not properly charged.	Charge the device fully (approx. 3 hours). Ensure the charging cable is securely connected.
Weak vibration or suction.	Low battery; Inner sleeve not properly inserted; Debris obstructing mechanism.	Recharge the device. Ensure the inner sleeve is correctly and snugly fitted. Disassemble and clean the device thoroughly.
App cannot connect to the device.	Bluetooth not enabled; Device not powered on; App permissions.	Ensure Bluetooth is enabled on your phone. Turn on the device. Check app permissions in your phone settings. Restart both the device and the app.
Unusual noise during operation.	Inner sleeve misalignment; Internal component issue.	Disassemble and reassemble the inner sleeve, ensuring it is correctly seated. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact EINSEO customer support for further assistance.

10. Specifications

Feature	Detail
Model Name	Male Masturbators
Brand	EINSEO
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS), Thermoplastic Elastomer (TPE)
Vibration Modes	7
Suction Levels	3
Battery Type	1 Lithium Ion battery (included)
Charging Time	Approx. 3 hours
Usage Time	Approx. 1 hour (continuous)
Charging Interface	USB Type-C
Noise Level	≤55dB
Water Resistance Level	Waterproof (sleeve only, main unit is not)
Package Dimensions	11.18 x 4.29 x 4.29 inches
Weight	1.9 Pounds

11. Warranty and Support

EINSEO products are manufactured to high-quality standards. For warranty information, product support, or any inquiries, please refer to the contact information provided with your purchase or visit the official EINSEO website. Please retain your proof of purchase for warranty claims.

© 2025 EINSEO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question