

AIPOI 008T-956-1200

AIPOI 750ML Ultrasonic Cleaner Instruction Manual

Model: 008T-956-1200

1. INTRODUCTION

Thank you for purchasing the AIPOI 750ML Ultrasonic Cleaner. This device uses high-frequency ultrasonic waves to clean various items effectively and gently. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the main unit in water or other liquids.
- Do not operate the cleaner if the power cord or plug is damaged.
- Keep out of reach of children.
- Do not disassemble the unit. Contact qualified service personnel for repairs.
- Always unplug the unit from the power outlet when not in use or before cleaning.
- Ensure the unit is placed on a stable, dry surface.
- Do not operate without water in the tank.
- Avoid using flammable or corrosive cleaning solutions.

3. PRODUCT OVERVIEW

The AIPOI 750ML Ultrasonic Cleaner is designed for efficient cleaning of various small items. It features a durable stainless steel tank and intuitive controls.



Figure 1: AIPOI 750ML Ultrasonic Cleaner main unit.

Key Features:

- **Powerful Cleaning:** 43,000 Hz ultrasonic sound waves and 35W transducers for effective stain removal.
- **Degassing Function:** Removes dissolved air and air bubbles from the cleaning solution for optimal results.
- **User-Friendly Operation:** Digital display with preset cleaning times (90, 180, 240, 300, 480, 600 seconds) and automatic shut-off.
- **Large Volume Tank:** 750ml capacity, made from food-grade SUS 304 stainless steel.
- **Accessories:** Includes a removable cleaning basket and a watch stand.
- **Quiet Operation:** Operates at less than 60 dB.
- **Transparent Lid:** Allows observation of the cleaning process.

What's in the Box:

- AIPOI 750ML Ultrasonic Cleaner Unit
- Removable Cleaning Basket
- Watch Stand
- Power Cord
- Instruction Manual

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the ultrasonic cleaner on a flat, stable, and dry surface, away from heat sources and direct sunlight.
3. **Power Connection:** Ensure the unit is unplugged before adding water.

5. OPERATING INSTRUCTIONS

Follow these steps for effective cleaning:

EASY OPERATION



Figure 2: Easy operation steps for the ultrasonic cleaner.

1. **Fill the Tank:** Open the lid and fill the stainless steel tank with clean tap water. Do not exceed the "MAX" fill line. For enhanced cleaning, you may add a small amount of non-corrosive cleaning solution or detergent (Figure 2, Step 1 & 2).
2. **Place Items:** Carefully place the items to be cleaned into the cleaning basket, then lower the basket into the tank. Ensure items are fully submerged but not overcrowded (Figure 2, Step 3). For watches, use the provided watch stand.
3. **Close Lid:** Close the transparent lid.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet.
5. **Select Cleaning Time:** Press the "SET" button repeatedly to cycle through the available cleaning times: 90, 180, 240, 300, 480, 600 seconds. The selected time will be displayed on the digital screen (Figure 2, Step 4).
6. **Start Cleaning:** Press the "ON" button to start the cleaning cycle. The unit will begin generating ultrasonic waves.
7. **Degassing Function:** For optimal cleaning results, especially with new water, consider using the "DEGAS" function. This removes dissolved air from the water, which can interfere with ultrasonic cavitation. Press the "DEGAS" button to activate this function before starting a regular cleaning cycle.

8. **Monitor Progress:** You can observe the cleaning process through the transparent lid.
9. **Completion:** The unit will automatically shut off once the selected cleaning time has elapsed.
10. **Remove Items:** Unplug the unit. Open the lid and carefully lift out the cleaning basket. Rinse the cleaned items under clean water and dry them thoroughly with a soft cloth.
11. **Empty Tank:** Disconnect the power cord. Carefully pour out the dirty water from the tank.

Suitable Items for Cleaning:



Figure 3: Versatile cleaning for various personal items.

- Jewelry (necklaces, rings, earrings, bracelets)
- Eyeglasses and sunglasses
- Watches (waterproof only, use watch stand)
- Dentures and retainers
- Makeup brushes
- Small metal parts and tools

Items NOT Suitable for Ultrasonic Cleaning:

- Soft or porous stones (e.g., pearls, emeralds, opals, turquoise)
- Items with loose stones or settings
- Non-waterproof watches
- Wooden items
- Items that are easily discolored or damaged by water

6. MAINTENANCE AND CARE

- **After Each Use:** Unplug the unit and empty the water from the tank. Wipe the tank interior and exterior with a soft, damp cloth.
- **Cleaning the Unit:** Do not use abrasive cleaners or immerse the main unit in water.
- **Storage:** Store the cleaner in a cool, dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outage; unit malfunction.	Ensure power cord is securely plugged in. Check power outlet. If problem persists, contact support.
Cleaning results are poor.	Insufficient water; items overcrowded; incorrect cleaning solution; air bubbles in water.	Ensure water level is adequate. Clean fewer items at a time. Use appropriate cleaning solution. Use the "DEGAS" function.
Unit stops during operation.	Cleaning cycle completed; overheating.	This is normal if the cycle finished. If not, unplug and let cool down for 10-15 minutes before restarting.
Unusual noise or vibration.	Unit not on a stable surface; internal issue.	Ensure unit is on a flat, stable surface. If noise persists, discontinue use and contact support.

8. SPECIFICATIONS

- **Model:** 008T-956-1200
- **Brand:** AIPOI
- **Tank Capacity:** 750 ml
- **Ultrasonic Frequency:** 43 KHz
- **Ultrasonic Power:** 35 W
- **Tank Material:** SUS 304 Stainless Steel
- **Product Dimensions (L x W x H):** 18.4 x 18.2 x 12.7 cm (approx. 7.24 x 7.17 x 5 inches)
- **Product Weight:** 1.16 kg (approx. 2.56 lbs)
- **Preset Cleaning Times:** 90s, 180s, 240s, 300s, 480s, 600s
- **Noise Level:** < 60 dB

- **ASIN:** B09YGS9MZJ
- **Date First Available:** April 21, 2022

Product size



Figure 4: Product dimensions.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact AIPOI customer service through your purchase platform or the contact details provided with your product packaging. Please have your model number (008T-956-1200) and ASIN (B09YGS9MZJ) ready when contacting support.

Note: Specific warranty terms may vary by region and retailer. Please refer to the documentation included with your purchase for detailed warranty information.

