

- Manuals.plus /
- › GreenForest /
- › GreenForest Computer Desk Instruction Manual

GreenForest THOR-BK-S

GreenForest Computer Desk Instruction Manual

Model: THOR-BK-S
Brand: GreenForest

1. PRODUCT OVERVIEW

The GreenForest Computer Desk (Model: THOR-BK-S) is a versatile and durable workstation designed for home office, study, writing, or gaming. It features a spacious desktop, integrated printer shelf, reversible storage shelves, a movable monitor stand, and dual hooks for accessories. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting.



Figure 1: GreenForest Computer Desk (Model: THOR-BK-S) in a typical setup.

2. PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact GreenForest customer support.

- Desktop Panel (1)
- Printer Shelf Unit (1)
- Movable Monitor Stand (1)
- Metal Frame Components (various)
- Accessory Hooks (2)
- Assembly Hardware (screws, bolts, L-wrench)
- Instruction Manual (this document)

Enough Space For Printer



Figure 2: Desk dimensions and components.

3. SETUP AND ASSEMBLY

Assembly is simple and straightforward, typically taking around 40 minutes. It is recommended that two people assemble the desk for ease and safety.

3.1 Preparation

- Clear a spacious area for assembly.
- Unpack all components and verify against the package contents list.
- Keep all hardware organized and within reach.

3.2 Assembly Steps

1. Attach the metal frame components to the desktop panel using the provided bolts and L-wrench. Ensure all connections are secure but do not overtighten initially.

2. Assemble the printer shelf unit according to the diagrams, ensuring the shelves are correctly oriented.
3. Attach the assembled printer shelf unit to the main desk frame. The reversible design allows installation on either the left or right side of the desk to suit your space layout.
4. Install the two accessory hooks on the side of the desk frame as desired.
5. Place the movable monitor stand on the desktop. This stand is designed to raise your screen to eye level, reducing neck and back strain.
6. Once all components are in place, tighten all bolts securely.



Reversible Computer Desk for Office

The Printer Stand can be installed on the left or right





Figure 3: Reversible design for flexible setup.



Sturdy Steel Tube Frame

30mm x 20mm thickness tube frame provides strong support for the desk, ensuring stability and sturdiness.

Figure 4: Ergonomic Detachable Monitor Stand.



Built a Gaming Zone for Yourself

Show off your amazing mainframe, peripherals, figures on the shelves. Customize the look of your gaming table to create an immersive environment.

Figure 5: Convenient side hooks for accessories.

4. OPERATING AND USAGE

The GreenForest Computer Desk is designed for optimal functionality and organization in various settings.

4.1 Workspace Organization

- **Printer Shelf:** The dedicated middle shelf on the unit is sized to accommodate most standard printers, scanners, or other office equipment, keeping your main desktop clear.
- **Storage Shelves:** Utilize the four reversible storage shelves for books, documents, office supplies, or decorative items.
- **Monitor Stand:** Position your monitor on the movable stand to achieve an ergonomic viewing height, reducing strain during long work or gaming sessions.
- **Accessory Hooks:** Use the two side hooks to hang headphones, bags, or other items, keeping them easily accessible and off the desk surface.

Reversible Design




Figure 6: Dedicated printer space and additional storage.



4 Colors and 3 Sizes Adapt to Any Space

More colors and sizes to suit different room styles and create the ideal room effect for you.



Figure 7: Efficient storage for all your essentials.

5. MAINTENANCE

To ensure the longevity and appearance of your GreenForest Computer Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desktop and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the particleboard.
- **Hardware Check:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 180 pounds on the desktop.



Figure 8: Sturdy steel tube frame for long-lasting durability.

6. TROUBLESHOOTING

If you encounter any issues with your GreenForest Computer Desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose bolts or uneven floor.	Ensure all assembly bolts are fully tightened. Adjust the desk's position on the floor or use shims if necessary.
Parts do not align during assembly.	Incorrect orientation of components.	Review the assembly diagrams carefully, especially for the reversible printer shelf unit. Ensure components are not forced.
Difficulty inserting screws.	Misaligned holes or debris.	Check for any obstructions in the screw holes. Ensure parts are correctly aligned before attempting to insert screws. Do not overtighten.

7. SPECIFICATIONS

Feature	Detail
Brand	GreenForest
Model Number	THOR-BK-S
Product Dimensions	59"D x 18.9"W x 29.5"H
Color	Black
Material	Engineered Wood (Top), Metal (Frame)
Maximum Weight Recommendation	180 Pounds
Special Features	Printer Shelf, Reversible Storage Shelves, Movable Monitor Stand, Headphone Hooks
Assembly Required	Yes
Recommended Assembly People	2

8. IMPORTANT SAFETY INFORMATION

WARNING:

- Do not exceed the maximum weight limit of 180 pounds. Overloading may cause the desk to collapse, leading to injury or damage.
- Ensure all connections are securely tightened after assembly and periodically checked. Loose connections can compromise stability.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the desktop surface without protection to prevent damage to the finish.

9. WARRANTY AND SUPPORT

GreenForest is committed to providing quality furniture products. For any questions, missing parts, or assistance with

assembly, please contact GreenForest customer support. Refer to your purchase documentation for specific warranty details.

For more information and support, visit the official GreenForest store:

[GreenForest Official Store](#)

© 2024 GreenForest. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09YH6L4B5>

More documents and user manuals: <https://manuals.plus/>