Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl SW-050100

onerbl AC/DC Adapter Charger SW-050100 User Manual

Model: SW-050100

1. Introduction

This manual provides essential instructions for the safe and efficient use of your onerbl AC/DC Adapter Charger, Model SW-050100. Please read this manual thoroughly before operating the device and retain it for future reference.

2. Safety Instructions

To ensure safe operation and prevent damage, always adhere to the following safety guidelines:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter. This will void the warranty and may cause electrical hazards.
- Ensure the adapter is used with devices that match its voltage and current specifications (5V, 1A).
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- Keep out of reach of children.



This adapter features a smart chip for multiple protection mechanisms, including short-circuit, over-voltage, and over-current protection, enhancing electrical safety during use.

3. Product Overview

The onerbl AC/DC Adapter Charger SW-050100 is designed to provide stable power to compatible electronic devices. It features a compact design for portability and ease of use.




Front and side view of the AC/DC adapter. The label indicates an input of 100-240VAC, 0.3A, 50/60Hz.



The adapter features a durable design with a PVC jacket and copper wire for reliable power transmission and longevity.

4. Specifications

Feature	Specification
Model Number	SW-050100
Input Voltage	AC 100-240V, 50/60Hz, 0.3A
Output Voltage	DC 5V
Output Current	1A
Wattage	5 Watts
Connector Type	Barrel Connector
Cable Length	76 inches (approximately 6.3 feet)
Dimensions (Adapter Body)	2.6 x 1.6 x 1.2 inches (L x W x H)
Weight	8 ounces



Visual representation of the adapter's dimensions (2.6 x 1.6 x 1.2 inches) and the cable length (76 inches).

5. Setup

Follow these steps to set up your AC/DC adapter:

1. **Verify Compatibility:** Ensure your device requires a 5V DC input with a maximum current draw of 1A and has a compatible barrel connector.
2. **Connect to Device:** Insert the barrel connector end of the adapter cable firmly into the power input port of your electronic device.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard AC 100-240V wall outlet.
4. **Power On Device:** Once connected, power on your device as usual.



The adapter connected to a power strip, ready to supply power to a compatible device.

6. Operation

The onerbl AC/DC Adapter Charger is designed for straightforward operation. Once properly connected, it will supply continuous power to your device.

- The adapter is suitable for a wide range of low-power electronic devices that require 5V DC input.
- It automatically adjusts to worldwide AC input voltages (100-240V), making it suitable for international travel with appropriate plug adapters (not included).



This adapter is compatible with a wide range of devices including set-top boxes, routers, cameras, humidifiers, digital frames, and more, provided they match the voltage and current requirements.

7. Maintenance

Proper maintenance ensures the longevity and performance of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and adapter body for any signs of damage, such as cuts, fraying, or cracks. If damage is found, discontinue use immediately.

8. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on	Adapter not properly connected; Power outlet issue; Device incompatibility; Faulty adapter.	Ensure all connections are secure. Test the power outlet with another device. Verify device voltage/current requirements. If issues persist, the adapter may be faulty.
Adapter feels hot	Normal operation under load; Overload; Poor ventilation.	A slight warmth is normal. Ensure the device's power requirements do not exceed 5V 1A. Provide adequate ventilation around the adapter. If it's excessively hot, discontinue use.

Intermittent power	Loose connection; Damaged cable.	Check all connections for tightness. Inspect the cable for visible damage. Replace if damaged.

If troubleshooting steps do not resolve the issue, please contact customer support.

9. Warranty and Support

This onerbl product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the product packaging or contact your retailer.
For technical support or inquiries, please visit the onerbl official website or contact their customer service department. Please have your model number (SW-050100) and purchase information ready when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YM1NNRZ

More documents and user manuals: **https://manuals.plus/**