

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CleverSpa](#) /

› [CleverSpa Cannes 6 Person Inflatable Hot Tub User Manual](#)

CleverSpa Cannes 6 Person (8351)

CleverSpa Cannes 6 Person Inflatable Hot Tub User Manual

Model: Cannes 6 Person (8351)

INTRODUCTION

This user manual provides comprehensive instructions for the safe and efficient setup, operation, and maintenance of your CleverSpa Cannes 6 Person Round Inflatable Outdoor Bubble Spa Hot Tub. Designed for comfort and durability, this hot tub features 130 airjets and 365 Freezeguard Technology, allowing for year-round enjoyment. Please read this manual thoroughly before initial use to ensure proper functioning and longevity of your product.



Image: The CleverSpa Cannes 6 Person Inflatable Hot Tub, showcasing its round shape and grey exterior.

SETUP

The CleverSpa Cannes hot tub is designed for quick and easy assembly, typically within 5 minutes, requiring no special tools. Follow these steps for initial setup:

1. **Site Selection:** Choose a flat, stable, and level surface capable of supporting the weight of the filled hot tub and its occupants. Ensure adequate drainage and proximity to a suitable power outlet.
2. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
3. **Inflation:** Connect the inflation hose to the hot tub's air valve and use the integrated pump to inflate the hot tub until it is firm to the touch. Do not overinflate.
4. **Filter Installation:** Install the filter cartridge into its designated housing.
5. **Filling:** Fill the hot tub with water to the recommended fill line.
6. **Power Connection:** Plug the hot tub into a grounded electrical outlet.




Image: A cutaway view illustrating the durable Triple-S fabric construction and internal layers of the CleverSpa hot tub.

OPERATING INSTRUCTIONS

Your CleverSpa Cannes hot tub features an intuitive control panel for easy operation of its functions.



Image: Close-up of the CleverSpa control panel, showing buttons for temperature adjustment, filter, bubbles, and heating functions.

- **Power On/Off:** Press the power button to turn the hot tub system on or off.
- **Temperature Control:** Use the "Temp Up" and "Temp Down" buttons to adjust the water temperature. The maximum heating temperature is 40°C.
- **Bubble Function (Airjets):** Activate the 130 airjets by pressing the bubble button. This will release thousands of soothing bubbles into the water.
- **Filter System:** The filter button controls the water filtration system. It is recommended to run the filter regularly to maintain water clarity.
- **Heating System:** The heater indicator will illuminate when the heating function is active. The 365 FreezeGuard Technology automatically activates the heater in cold conditions to prevent water from freezing, protecting the hot tub components.
- **Lock Function:** Some models feature a lock button to prevent accidental changes to settings.

MAINTENANCE

Regular maintenance is crucial for the performance, hygiene, and longevity of your CleverSpa hot tub.

- **Water Treatment:** Maintain proper water chemistry using recommended hot tub chemicals. Test water regularly for pH, alkalinity, and sanitizer levels.
- **Filter Cleaning/Replacement:** Clean the filter cartridge frequently (e.g., daily or every other day depending on usage) by rinsing it with water. Replace the filter cartridge every 1-2 weeks or as needed to ensure efficient filtration and prevent debris buildup.
- **Water Changes:** Drain and refill the hot tub every 1-3 months, or more frequently with heavy use, to ensure fresh water quality.
- **Surface Cleaning:** Clean the interior and exterior surfaces of the hot tub regularly with a soft cloth and mild cleaner.
- **365 Freezeguard Technology:** This feature automatically protects your hot tub from freezing in cold weather. Ensure the hot tub remains plugged in during colder months for this system to function effectively.
- **Cover Use:** Always use the hot tub cover when not in use to retain heat, prevent debris entry, and reduce evaporation.

TROUBLESHOOTING

Refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
Hot tub not heating	Low water level, dirty filter, heater malfunction, ambient temperature too low.	Ensure water is at correct level. Clean or replace filter. Check power connection. Allow more time for heating in cold conditions.
Bubbles not strong	Air pump issue, blockages in airjet system.	Ensure air pump is clear of obstructions. Check for kinks in air lines if accessible.
Water cloudy/dirty	Insufficient filtration, improper water chemistry, heavy usage.	Clean or replace filter. Adjust water chemistry (sanitizer, pH). Increase filtration time.
Hot tub deflating	Air leak, valve not sealed properly.	Check all air valves are securely closed. Inspect hot tub surface for punctures and repair if necessary.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact CleverSpa customer support.

SPECIFICATIONS

Brand	CleverSpa
Model Name	Cannes 6 Person
Item Model Number	8351
ASIN	B09YMB6YDB
Product Dimensions (L x W x H)	208 x 208 x 65 cm
Material Type	Polyvinyl Chloride (PVC)
Power Source Type	AC
Voltage	220 Volts
Airjets	130
Maximum Water Temperature	40°C
Special Features	365 Freezeguard Technology

WARRANTY AND SUPPORT

Your CleverSpa Cannes hot tub comes with full warranty cover, providing peace of mind. For any product-related inquiries, technical assistance, or warranty claims, please contact the dedicated UK-based Aftersales Team.

For the most up-to-date contact information and warranty details, please refer to the official CleverSpa website or the documentation included with your purchase.

Note: Always refer to the official CleverSpa website or included documentation for the most current warranty terms and support contact details.