

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Devoko](#) /
- › [Devoko 7-Piece Patio Dining Set Instruction Manual](#)

Devoko VC-DVW7P

Devoko 7-Piece Patio Dining Set Instruction Manual

Model: VC-DVW7P

1. INTRODUCTION

Thank you for choosing the Devoko 7-Piece Patio Dining Set. This set is designed to enhance your outdoor living space, providing a comfortable and stylish area for dining and conversation. It features a durable acacia wood table top, hand-woven rattan chairs with comfortable cushions, and a sturdy steel frame. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new patio dining set.



Image: The Devoko 7-Piece Patio Dining Set, featuring a rectangular acacia wood table and six black rattan chairs with beige cushions, set up on a patio next to a swimming pool.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- Always adjust the feet of the swivel seat for balance to prevent tip-over.
- Follow the assembly instructions carefully to ensure safe setup.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the weight capacity of the chairs (400 lbs per chair).
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Do not stand on the table or chairs.
- Place the furniture on a flat, stable surface to prevent wobbling or tipping.

3. PACKAGE CONTENTS

Your Devoko 7-Piece Patio Dining Set will be delivered in three separate boxes. Please be patient if you only receive some of the boxes initially, as they may arrive at different times. Verify that all components are present before beginning assembly.

Included Components:

- Acacia Wood Table (1)
- Rattan Chair (6)
- Tools and Instruction Manual (1 set)

If any parts are missing or damaged, please contact Devoko customer support immediately.

4. SETUP AND ASSEMBLY

Assembly is required for this patio dining set. It is recommended to assemble the furniture on a soft surface like a carpet to prevent scratches. Do not fully tighten screws until all components are aligned.

Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface. Identify all parts according to the included parts list.
2. Begin assembling the chairs first. Attach the chair components loosely, ensuring all holes align. Some rattan material may partially cover holes; use the provided Allen wrench to clear them if necessary.
3. Once all chair components are in place, gently tighten the screws about 50% or just under snug. This allows for minor adjustments.
4. Repeat for all six chairs.
5. Assemble the table according to the instructions. Ensure the acacia wood top is properly seated and secured.
6. Once all chairs and the table are assembled, place them upright. Then, go back and fully tighten all screws on both the chairs and the table. Ensure not to overtighten to avoid stripping the threads.
7. Adjust the adjustable feet on the chairs and table to ensure stability and prevent wobbling.



Image: Technical diagram illustrating the dimensions of the Devoko patio dining table (59.1" L x 35.4" W x 29.1" H) and a chair (25.8" W x 23.6" D x 34.6" H, seat height 18.3", cushion thickness 1.97").



Easy to Assemble

COMPLETE ACCESSORIES

Whether you're hosting a delightful al fresco dinner or enjoying a leisurely brunch with friends, our furniture sets the stage for unforgettable moments

DEVOKO
DAILY VACATION

Image: A banner image emphasizing 'Easy to Assemble' with a family enjoying a meal outdoors on the patio set, highlighting the complete accessories provided for assembly.

5. OPERATING AND USAGE

The Devoko 7-Piece Patio Dining Set is designed for outdoor use, perfect for family gatherings, meals, and relaxation in your garden, patio, or backyard.

- **Seating:** The set includes six comfortable chairs with soft, breathable, and elastic foam-filled seat cushions. The seat covers are removable for easy cleaning.
- **Dining:** The 35x59 inch acacia wood table top provides ample space for food, drinks, and decorations.
- **Stability:** The steel frame structure ensures sufficient strength and stability for safe use.



HIGH-QUALITY ACACIA WOOD

Does not fade or crack easily

Image: A family of five enjoying a meal on the Devoko patio dining set in a lush green backyard, showcasing the high-quality acacia wood table that resists fading and cracking.



LARGE TABLETOP


Up to 6 people

Image: A family of six gathered around the large tabletop of the Devoko dining set, demonstrating its capacity to comfortably seat up to six people for outdoor meals.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your patio dining set.

- **Cleaning:** Wipe the surfaces with a damp cloth, then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The seat covers are removable for cleaning. Follow the care instructions on the cushion tags.
- **Wood Care:** The acacia wood is treated for anti-corrosion, but for prolonged protection and to prevent fading, consider applying a waterproof stain sealer periodically.
- **Protection:** To protect the furniture from harsh weather conditions (rain, sun, snow), especially when not in use, cover it with a suitable outdoor furniture cover or store it in a shed or garage.
- **Rattan:** The hand-woven rattan is designed for all kinds of weather, but regular cleaning will help maintain its appearance.




All-weather Rattan



Thickened Cushion



Adjustable Feet



Natural Acacia Wood

Image: A composite image showing close-up details of the Devoko patio dining set, including the all-weather rattan weave, a thickened cushion with zipper, an adjustable foot, and the natural acacia wood tabletop.

7. TROUBLESHOOTING

This section addresses common issues you might encounter during assembly or use.

Problem	Possible Cause	Solution
Holes do not align during assembly.	Screws were tightened too early; rattan material obstructing holes.	Ensure all screws are only loosely fastened until all parts are in place. Use the provided Allen wrench to gently clear any rattan material from the screw holes.

Problem	Possible Cause	Solution
Screws do not thread in or strip easily.	Overtightening; misaligned screw.	Ensure screws are inserted perpendicular to the hole. Do not overtighten; tighten by hand for final turns to avoid stripping. If a screw is stripped, contact customer support for replacement parts.
Furniture is wobbly after assembly.	Uneven tightening of screws; uneven surface; feet not adjusted.	Ensure all screws are fully and evenly tightened. Place the furniture on a flat, level surface. Adjust the leveling feet on the bottom of the chairs and table until stable.
Product arrived with minor scratches or chips.	Shipping damage.	Inspect all parts upon arrival. For minor cosmetic issues, touch-up paint or wood repair kits may be used. For significant damage, contact customer support with photos.
Missing parts upon delivery.	Incomplete shipment (multiple boxes).	Confirm all expected boxes have arrived (this set ships in three boxes). If parts are still missing after all boxes are received, contact customer support.

8. SPECIFICATIONS

- **Model Number:** VC-DVW7P
- **Product Dimensions (Table):** 59.1 x 35.4 x 29.1 inches (L x W x H)
- **Item Weight:** 124 pounds (total set)
- **Material:** Acacia Wood (tabletop), Rattan (chairs), Steel (frame)
- **Fabric Type (Cushions):** 100% Polyester
- **Color:** Black (rattan), Beige (cushions)
- **Special Features:** 6 Chairs, Acacia Wood Table, Outdoor Dining Set, Hand-Woven Rattan, Adjustable Feet
- **Care Instructions:** Wipe with Dry, Wipes with Damp Cloth

9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, Devoko is committed to customer satisfaction. For any questions, concerns, or assistance with your product, please contact Devoko customer support or the seller directly. You can visit the official Devoko store for more information and contact options:

[Visit the Devoko Store on Amazon](#)

Please have your model number (VC-DVW7P) and purchase information ready when contacting support.

