



[Manuals.plus](#) /

› [AMHANCIBLE](#) /

› AMHANCIBLE C Shaped End Table User Manual

AMHANCIBLE HET04C

AMHANCIBLE C Shaped End Table User Manual

Model: HET04C

INTRODUCTION

Thank you for choosing the AMHANCIBLE C Shaped End Table. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new end table. Please read this manual thoroughly before assembly and retain it for future reference.



Image: A set of two AMHANCIBLE C Shaped End Tables, showcasing their design, integrated charging stations, and side storage bags.

IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Do not exceed the maximum weight limit of 22 lbs (10 kg) on the tabletop to prevent damage or injury.
- Ensure the table is placed on a level surface to prevent tipping or instability.
- Do not use the charging station with damaged cords or plugs to prevent electrical shock or fire.
- Keep liquids away from the charging station to avoid electrical hazards.
- This product is intended for indoor use only.
- Keep small parts and packaging materials away from children to prevent choking hazards.

PACKAGE CONTENTS

Before assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Tabletop with Charging Station	2
B	C-Shaped Metal Frame (Left)	2
C	C-Shaped Metal Frame (Right)	2
D	Storage Bag	2
E	Adjustable Feet	8
F	Screws (various sizes)	Assorted
G	Allen Wrench / Screwdriver	1

Note: The product comes as a set of two tables. Quantities listed are for one table, multiply by two for the full set.

SETUP AND ASSEMBLY

Assembly is straightforward and typically takes 15-30 minutes per table. It is recommended that two people assemble the table for ease and safety.

1. Step 1: Attach Adjustable Feet

Screw the adjustable feet (E) into the bottom of the C-shaped metal frames (B and C). Ensure they are securely tightened but allow for minor adjustments later.



Image: Adjustable feet being installed on the table base. These feet help stabilize the table on uneven surfaces and protect floors.

2. Step 2: Assemble the Metal Frame

Connect the two C-shaped metal frames (B and C) using the provided screws (F). Ensure the holes align correctly. Do not fully tighten screws until all parts are loosely assembled.

3. Step 3: Attach Tabletop

Carefully place the tabletop with charging station (A) onto the assembled metal frame. Align the pre-drilled holes on the tabletop with the holes on the metal frame. Secure the tabletop using the appropriate screws (F). Fully tighten all screws from Step 2 and Step 3.



Image: Dimensional diagram of the C-shaped end table, illustrating key measurements for assembly and placement.

4. Step 4: Install Storage Bag

Attach the storage bag (D) to the side of the metal frame using the designated fasteners or hooks. Ensure it is securely attached and hangs properly.



Image: Side view of the table highlighting the integrated storage bag with various pockets for organization.

5. Step 5: Final Adjustments

Once assembled, gently shake the table to check for stability. Adjust the adjustable feet (E) as needed to ensure the table is level and does not wobble.

OPERATING INSTRUCTIONS

Using the Charging Station

The AMHANCIBLE C Shaped End Table is equipped with a built-in charging station for your convenience.

- **Power Connection:** Plug the 4.9 ft power cord from the charging station into a standard 120V wall outlet.
- **AC Outlets:** The charging station includes two 120V/12A AC outlets. These are suitable for powering lamps,

laptops, or other small appliances.

- **USB Ports:** Two USB ports (5V/3A total, including one USB-A and one USB-C) are available for charging mobile phones, tablets, and other USB-powered devices.



Image: The integrated charging station with two AC outlets and two USB ports, demonstrating its capability to charge multiple devices simultaneously.

Utilizing the Storage Bag

The attached storage bag features multiple pockets for organizing various items:

- **Large Pockets:** Ideal for tablets, magazines, or notebooks.
- **Small Pockets:** Perfect for remote controls, keys, phones, glasses, or other small accessories.




Image: The multi-pocket storage bag, shown holding a variety of personal items for convenient access.

Versatile Placement and Use

The C-shaped design allows the table to slide easily under sofas, beds, or chairs, making it highly versatile for various uses:

- **Living Room:** Use as a convenient side table for drinks, snacks, or remote controls.
- **Bedroom:** Functions as a bedside table for charging devices or holding books.
- **Home Office:** Provides a stable surface for a laptop, transforming into a temporary workstation.
- **TV Tray/Snack Table:** Ideal for meals or snacks while relaxing on the couch.



Image: A visual representation of the table's versatility, showcasing its use in different rooms and for various activities.



Image: A user comfortably working on a laptop positioned on the C-shaped table, illustrating its ergonomic design for sofa-side use.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your AMHANCIBLE C Shaped End Table.

- **Cleaning:** Wipe the tabletop and metal frame with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Clean up spills immediately to prevent staining, especially on the wooden tabletop.
- **Charging Station:** Ensure the charging station remains dry. Do not attempt to clean the electrical components with liquids.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Storage Bag:** The fabric storage bag can be spot cleaned with a mild detergent and water. Allow to air dry completely before reattaching.



Image: Demonstrating how to clean the tabletop with a soft cloth, emphasizing easy maintenance.

TROUBLESHOOTING

If you encounter any issues with your AMHANCIBLE C Shaped End Table, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Table is wobbly/unstable.	Uneven floor; loose screws; adjustable feet not properly set.	Ensure the table is on a flat surface. Tighten all assembly screws. Adjust the adjustable feet until the table is stable.
Charging station not working.	Power cord not plugged in; wall outlet not active; device not properly connected; charging station malfunction.	Check if the power cord is securely plugged into a live wall outlet. Test the outlet with another device. Ensure your device's charging cable is fully inserted into the USB port or AC outlet. If the issue persists, contact customer support.
Missing parts during assembly.	Packaging error.	Carefully check all packaging materials. If parts are genuinely missing, contact AMHANCIBLE customer support with your purchase details.
Storage bag not attaching securely.	Incorrect attachment method; damaged fasteners.	Refer to Step 4 of the assembly instructions. Ensure the fasteners are correctly aligned and engaged. If fasteners are damaged, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	AMHANCIBLE
Model Name	HET04C
Product Dimensions (D x W x H)	11.41"D x 15.35"W x 23.22"H
Item Weight	7 Kilograms (approx. 15.4 lbs) per table
Maximum Weight Recommendation	10 Kilograms (approx. 22 lbs)
Color	Rustic Brown
Material Type	Engineered Wood (Top), Carbon Steel (Frame)
Power Cord Length	4.9 ft

Feature	Detail
AC Outlets	2 (120V/12A)
USB Ports	2 (5V/3A total, USB-A and USB-C)
Included Components	Assembly Guide, Installation Tool
Number of Items	2 (Set of two tables)

WARRANTY AND SUPPORT

AMHANCIBLE provides a **Lifetime Warranty** for this product, as stated in the product specifications. This warranty covers manufacturing defects and ensures the quality and durability of your end table.

For any questions, missing parts, damaged components, or warranty claims, please contact AMHANCIBLE customer support directly. Please have your purchase details and model number (HET04C) ready when contacting support.

You can visit the official AMHANCIBLE store for more information and contact options: [AMHANCIBLE Store](#)