

Saras K-1089E+L

Saras Huayu Universal A/C Remote Control K-1089E+L User Manual

Model: K-1089E+L

INTRODUCTION

Thank you for choosing the Saras Huayu Universal A/C Remote Control K-1089E+L. This remote is designed to operate a wide range of air conditioning units. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

SETUP

1. Battery Installation

The remote control requires two AAA batteries (not included). Ensure correct polarity when inserting batteries.

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
3. Close the battery compartment cover securely.



Image: Back of the remote control with the battery compartment open, illustrating where to insert two AAA batteries. Manual code input instructions are also visible on the battery cover.

2. Code Setting (Manual Input)

If you know the specific code for your air conditioner brand, you can input it directly.

1. Refer to the provided code table (usually found in the remote's packaging or a separate leaflet) to find the 4-digit code for your A/C brand.
2. Press and hold the **SET** button for approximately 3 seconds until the 4-digit code on the remote's display starts flashing.
3. Enter the 4-digit code using the number buttons (0-9) on the remote.
4. Point the remote at your A/C unit and press the **OK** button to confirm. The A/C unit should respond if the code is correct.

3. Code Setting (Automatic Search)

If you do not know the code for your A/C unit, use the automatic search function.

1. Ensure your A/C unit is powered off.
2. Point the remote control directly at your A/C unit.
3. Press and hold the **SET** button. The remote will begin cycling through codes, and the code on the display will change rapidly.
4. Release the **SET** button immediately when your A/C unit turns on or responds (e.g., beeps).
5. Press the **OK** button to confirm the code. Test basic functions like power and temperature adjustment. If the A/C does not

respond correctly, repeat the automatic search process.

OPERATING INSTRUCTIONS

Familiarize yourself with the remote control's buttons and their functions.



Image: Front view of the remote control and its accompanying stent holder. The remote features an LCD screen and clearly labeled buttons for various functions.



Image: The remote control held in a hand, demonstrating its size and ergonomic design for user comfort.

- **Power (Orange Button):** Turns the A/C unit on or off.
- **Mode:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **TEMP (+/-):** Adjusts the temperature setting up or down.
- **FAN:** Changes the fan speed (Auto, Low, Medium, High).
- **M.SWING / A.SWING:** Activates or adjusts the horizontal (M.SWING) and vertical (A.SWING) air swing functions.
- **ON TIME / OFF TIME:** Sets a timer for the A/C unit to turn on or off automatically.
- **CLOCK:** Sets the current time on the remote's display.
- **Fast Cool / Fast Heat:** Activates rapid cooling or heating modes for quick temperature changes.
- **AC1 / AC2:** These buttons may be used for quick selection of pre-programmed codes or specific brand functions.
- **1 BRAND / 2 BRAND:** Similar to AC1/AC2, these buttons might allow direct access to codes for specific popular brands.

- **LOCK:** Locks the remote control buttons to prevent accidental changes. Press again to unlock.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote stops responding. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly and have sufficient charge. Replace if necessary.
 - Ensure there are no obstructions between the remote and the A/C unit's receiver.
 - Confirm the remote is pointed directly at the A/C unit.
- **A/C unit not responding to commands:**
 - Verify that the correct code for your A/C brand has been set. Try re-entering the code manually or using the automatic search function.
 - Ensure the A/C unit is powered on and not in a standby mode that prevents remote input.
- **Display is dim or blank:**
 - Replace the batteries.

SPECIFICATIONS

Model	K-1089E+L
Brand	Saras Huayu
Power Supply	2 x AAA Batteries (not included)
Color	White
Features	Universal compatibility, LCD display, Digital Search Mode, LED light

WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact your retailer. For technical support or further assistance, please contact the seller or the manufacturer directly through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question