

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Starry Sky Moon Phase Men's Automatic Mechanical Watches User Manual

OLEVS HZ-O-G9923PL-YL

OLEVS Starry Sky Moon Phase Men's Automatic Mechanical Watch

Model: HZ-O-G9923PL-YL

Brand: OLEVS

INTRODUCTION

This manual provides detailed instructions for the proper use and care of your OLEVS Starry Sky Moon Phase Automatic Mechanical Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.





Image: Front view of the OLEVS Starry Sky Moon Phase Automatic Mechanical Watch with a blue dial and leather strap.

SETUP

Initial Winding

As an automatic mechanical watch, it does not require a battery. For initial use or after a period of inactivity, manually wind the watch by turning the crown clockwise approximately 30-40 times until the second hand begins to move consistently. The watch will then self-wind with the motion of your wrist during wear.

Setting the Time and Date

1. Pull the crown out to the first click position to adjust the date. Turn the crown clockwise or counter-clockwise to set the desired date.
2. Pull the crown out to the second click position to adjust the time. Turn the crown to set the hour and minute hands. Ensure the moon phase indicator aligns with the correct time of day (AM/PM).
3. Push the crown back in to the normal position to start the watch.



Image: The OLEVS watch displayed on a textured surface, highlighting its design against a starry backdrop.

OPERATING FEATURES

Moon Phase Display

The watch features a unique moon phase display that rotates over time, showcasing the celestial movement. This is an aesthetic feature and does not necessarily correspond to the actual astronomical moon phase.

Luminous Display

The dial incorporates a special luminous design, allowing the stars and moon phase elements to glow in low-light conditions after being exposed to light. This enhances readability and visual appeal in the dark.



Image: The watch dial glowing in the dark, showcasing its luminous features.

Automatic Movement

The watch is powered by a high-quality mechanical movement that is self-winding. It harnesses the natural motion of your arm to keep accurate time. Regular wear ensures continuous operation without manual winding.



Image: Rear view of the OLEVS watch, revealing the intricate automatic mechanical movement through the transparent case back.

MAINTENANCE

Water Resistance

This watch is water-resistant up to 30 meters (3ATM), suitable for daily use such as hand washing or light rain. It is not recommended for swimming, diving, or showering, as prolonged water exposure or high-pressure water jets can damage the watch.



Image: The OLEVS watch partially submerged in water, demonstrating its 30-meter water resistance.

Cleaning and Care

- Wipe the watch case and crystal with a soft, dry cloth regularly to remove dust and fingerprints.
- For the leather strap, avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture to prevent cracking or discoloration. Clean with a damp cloth and mild soap if necessary, then air dry completely.
- Avoid exposing the watch to strong magnetic fields, as this can affect the accuracy of the mechanical movement.

TROUBLESHOOTING

Watch Not Keeping Time / Stopping

- **Insufficient Winding:** If the watch has not been worn for a while, manually wind it by turning the crown clockwise 30-40 times. Ensure you wear the watch regularly for sufficient self-winding.
- **Magnetic Interference:** Keep the watch away from strong magnetic sources (e.g., speakers, refrigerators, mobile phones) which can magnetize the movement and affect accuracy. If magnetized, professional demagnetization may be required.

Date Not Changing Correctly

- Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight. Avoid adjusting the date between 9 PM and 3 AM, as this can damage the date mechanism.

SPECIFICATIONS

Feature	Detail
Item Model Number	HZ-O-G9923PL-YL

Movement Type	Automatic Mechanical
Water Resistance	30M (3ATM)
Clasp Type	Double Locking Foldover Clasp
Case Material	Stainless Steel (Silver)
Band Material	Leather (Blue)
Dial Features	Starry Sky, Moon Phase, Luminous
Dimensions	4.53 x 4.37 x 2.91 inches (Package)
Weight	11.99 ounces

WARRANTY AND SUPPORT

OLEVS offers a 2-year product warranty for this watch. If you encounter any issues or require assistance, please contact the seller, Houze watch, through the Amazon platform. They provide professional after-sales support. For additional information, you may refer to the official user guide available as a PDF [User Guide \(PDF\)](#)

PRODUCT VIDEOS

Your browser does not support the video tag.

Video: An overview of the OLEVS Men's Sky Moon Automatic Mechanical Watch, showcasing its design and features.

ADDITIONAL PRODUCT IMAGES



Image: The OLEVS watch worn on a wrist, paired with a brown sweater, demonstrating its fit and style.



Image: The OLEVS watch worn on a wrist with a formal suit and cufflinks, highlighting its dress watch appeal.



Image: Promotional banner for OLEVS Automatic Mechanical Watch, emphasizing its "Starry Sky - Blues" advanced design.



Image: Close-up of the OLEVS watch dial, illustrating the rotating starry mirror feature.



Image: The OLEVS watch highlighting its special starry luminous feature, showing the glow effect.



Image: Two variants of the OLEVS watch, one in rose gold and one in silver, showcasing the available styles.



Image: The OLEVS watch worn by a person on a motorcycle, illustrating its versatility for different lifestyles.



Image: The OLEVS watch worn by a person in a leather jacket, showcasing its modern and stylish appearance.

© 2024 OLEVS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question