Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Donerton I09

Donerton Wireless Earbud 5.3 Headphones User Manual

Model: I09

Introduction

Thank you for choosing Donerton Wireless Earbud 5.3 Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: Donerton Wireless Earbuds (Model I09) in their charging case, showcasing the sleek design and digital display.

What's in the Box

- 2 x Wireless Earbuds (Left and Right)
- 1 x Fast Charging Case
- 1 x Type-C Charging Cable
- 3 x Pairs of Silicone Earplugs (S / M / L)
- 1 x User Manual (This Document)

Product Overview

The Donerton I09 earbuds feature a stylish design with advanced functionality for an enhanced audio experience.



Image: Overview of Donerton True Wireless Earbud key features including Hi-Fi Stereo Sound, Bluetooth 5.3, IP7 Waterproof, Ergonomic Design, One-Step Pairing, 80H Playing Time, Dual-Mic, and Auto Power On/Off.

Key Features:

- **Hi-Fi Stereo Sound:** Enjoy immersive audio with powerful bass and clear highs.



Image: Visual representation of Hi-Fi stereo sound waves emanating from an earbud, indicating superior audio quality.

- **Bluetooth 5.3:** Ensures a stable and efficient wireless connection.
- **Long Playtime:** Up to 80 hours of total playtime with the charging case.
- **IP7 Waterproof:** Protects earbuds from sweat and rain, ideal for sports.
- **LCD Digital Display:** Shows battery levels of the case and individual earbuds.
- **Touch Controls:** Intuitive touch-sensitive areas for managing music and calls.




Image: A person using Donerton earbuds while taking a selfie, demonstrating their practical use in daily activities.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the charging case and earbuds. The charging case extends the playtime significantly.

- Place the earbuds into the charging case. Ensure they are correctly seated; the earbuds' LED indicators will light up to confirm charging.
- Connect the Type-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
- The LCD digital display on the charging case will show the battery percentage of the case and the charging status of each earbud.
- A full charge for the case provides up to 80 hours of additional playtime for the earbuds.



Image: The Donerton charging case connected via USB-C, illustrating its compact design and the digital display showing battery levels.

2. Initial Pairing (One-Step Pairing)

The earbuds are designed for easy, one-step pairing with your device.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for "I09" in the list of available devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds' LED indicators will turn off or flash slowly.



Image: A smartphone screen showing "I09" in the Bluetooth device list, demonstrating the one-step pairing process with the earbuds in their open charging case.

Note: After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on your device.

3. Wearing the Earbuds

For optimal sound quality and comfort, choose the correct size of silicone earplugs (S/M/L) and adjust the earbuds to fit snugly in your ears.



Image: A person wearing the Donerton Wireless Earbuds, illustrating the in-ear fit and discreet design.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, long-press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging. Alternatively, long-press the touch area on both earbuds for 5 seconds.

Touch Controls

The Donerton I09 earbuds feature intuitive touch controls for easy management of music and calls.

UPGRADED TOUCH CONTROL



Image: Diagram illustrating the touch control functions: Previous Song, Next Song, Volume Up, Pause/Start, Answer/Hang Up, Volume Down.



Image: A robotic hand interacting with an earbud's touch surface, symbolizing the advanced touch control functionality.

Function	Action (Left Earbud)	Action (Right Earbud)
Play/Pause	Single tap	Single tap
Next Song	Double tap	Double tap
Previous Song	Triple tap	Triple tap
Volume Up	Long press	N/A
Volume Down	N/A	Long press
Answer/End Call	Single tap	Single tap
Reject Call	Long press for 2 seconds	Long press for 2 seconds
Activate Voice Assistant	Quadruple tap	Quadruple tap

Single Earbud Mode

You can use either the left or right earbud independently. Simply take one earbud out of the charging case, and it will automatically connect to your device. The touch controls for single earbud use may vary slightly (e.g., volume control might not be available on both earbuds simultaneously).

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Clean the charging contacts on both the earbuds and the case to ensure proper charging.

Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

Water Resistance (IP7)

The Donerton I09 earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for use during workouts and in rainy conditions.



Image: Donerton earbuds with water droplets, demonstrating their IP7 waterproof rating, suitable for protection against sweat and rain.

Important: The charging case is NOT waterproof. Do not expose the charging case to water or moisture.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Earbuds not charging	Poor contact with charging pins; charging cable/adapter issue; case battery low.	Ensure earbuds are correctly seated in the case. Clean charging contacts. Try a different charging cable or adapter. Charge the case fully.
Earbuds not pairing with device	Bluetooth off; earbuds not in pairing mode; interference; previously paired device.	Ensure Bluetooth is enabled on your device. Take earbuds out of case to enter pairing mode. Turn off Bluetooth on other nearby devices. Forget "I09" in your device's Bluetooth settings and re-pair.
Only one earbud working	One earbud not connected; low battery on one earbud.	Place both earbuds back in the case, close the lid, then open again. Ensure both are charged. If issue persists, reset earbuds (refer to manufacturer's website for specific reset instructions if not in manual).
Low volume or poor sound quality	Earbuds not properly seated; ear tips too small/large; earwax buildup; device volume low.	Adjust earbuds for a snug fit. Try different size ear tips. Clean earbud mesh. Increase volume on both earbuds and connected device.
Call quality issues (e.g., static, muffled sound)	Environmental noise; microphone obstruction; weak signal.	Move to a quieter environment. Ensure microphone area is clear. Stay within Bluetooth range of your device.

Specifications

Feature	Detail
Model Name	I09
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters
Battery Life (Earbuds)	5-6 hours per single charge
Total Playtime with Charging Case	Up to 80 Hours
Charging Time (Quick Charge)	10 minutes charge for 1 hour playtime
Water Resistance Level	IP7 Waterproof (Earbuds only)
Audio Driver Size	6 mm Composite Diaphragm
Frequency Range	20 Hz - 20 kHz
Control Method	Touch Control
Material (Case)	PC and ABS Construction
Color	White

Warranty and Support

Donerton products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official Donerton website.
If you encounter any issues or have questions regarding your Donerton Wireless Earbud 5.3 Headphones, please contact our customer support team:

- **Website:** Visit the Donerton Store on Amazon
- Please have your model number (I09) and purchase details ready when contacting support.

© 2024 Donerton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YRCDNXD

More documents and user manuals: **https://manuals.plus/**