CAB55 B09YRVHD87

CAB55 Rolling Sewing Machine Case Instruction Manual

Model: B09YRVHD87

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your CAB55 Rolling Sewing Machine Case. Designed for convenience and protection, this case allows for easy transport of most standard-sized sewing machines and accessories.



The CAB55 Rolling Sewing Machine Case, showcasing its primary function as a portable storage solution for sewing machines.

Key Features

- **Travel with Comfort and Ease:** Equipped with 2 smooth-rolling wheels and a sturdy, lightweight aluminum frame for effortless transport. Features top handles and a shoulder strap for versatile carrying. Measures 13.25 inches, suitable as a carry-on for most international flights.
- **Generous Storage Space:** Accommodates machines up to 17 x 10.2 x 13.3 inches, fitting most standard-sized sewing machines (e.g., SINGER, Brother, Janome). Includes 6 custom pockets and unique thread spool holders for organized storage of notions. Sturdy see-through pockets allow for easy item location and protection from sharp tools.
- **Protect Your Precious Machine:** Features a removable hard base for enhanced sturdiness and protection.

Well-padded sidewalls safeguard your machine from physical damage, ensuring its safety during travel.

- **Premium Quality:** Constructed with a durable two-wheel foundation and a lightweight aluminum frame, providing a smooth, bump-free ride. Wheels turn easily for convenient handling. Designed to be easy to fold for storage.



This image illustrates the key dimensions of the sewing machine case and its separate wheeled trolley, highlighting its compact and portable design.

Setup and Assembly

The CAB55 Rolling Sewing Machine Case is designed for quick and easy setup.

Attaching the Trolley

1. Unfold the detachable trolley by extending its handle and unfolding the base. Ensure all locking mechanisms are securely engaged.
2. Place the sewing machine case onto the trolley's platform. The case is designed to sit securely on the trolley.

3. Utilize the integrated straps or external bungee cords (if desired for extra security) to firmly secure the case to the trolley. This helps prevent movement during transport.

Preparing the Interior

1. Open the main compartment zipper.
2. Insert the removable hard base into the bottom of the main compartment for added stability and protection.
3. Arrange the internal dividers or pockets as needed to accommodate your sewing machine and accessories.



The interior of the case features multiple mesh pockets for organizing sewing notions and a spacious main compartment for the machine.

Operation

Transporting Your Machine

The case offers two primary methods of transport:

Rolling Transport

1. Ensure your sewing machine is securely placed inside the main compartment and the case is firmly attached to the trolley.
2. Extend the trolley handle to a comfortable height.
3. Tilt the trolley slightly and roll the case using the two wheels. The durable wheels are designed for smooth movement over various surfaces.

Carrying Transport

1. For short distances or when navigating stairs, detach the case from the trolley.
2. Use the reinforced top handles for hand-carrying.
3. Alternatively, attach the adjustable shoulder strap (if included) for over-the-shoulder carrying.



This image demonstrates the versatility of the case, showing both shoulder-carrying and rolling options for convenient transport.

Maintenance and Care

- **Cleaning:** Wipe the exterior with a damp cloth and mild soap. For stubborn stains, a soft brush can be used. Allow to air dry completely.
- **Interior Care:** Periodically empty the case and shake out any dust or debris. The mesh pockets can be wiped clean.
- **Zipper Care:** To ensure smooth operation, occasionally apply a zipper lubricant or a small amount of wax to the zipper teeth.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to preserve its material integrity. The trolley can be folded for compact storage.

Troubleshooting

Case Instability / Machine Movement

If your sewing machine feels unstable or moves excessively inside the case during transport:

- **Verify Machine Fit:** Ensure your machine's dimensions are within the specified limits (up to 17 x 10.2 x 13.3 inches).
- **Utilize Internal Padding:** While the case offers some padding, consider adding additional foam or soft material around your machine to fill any empty space and prevent shifting, especially for smaller machines.
- **Secure to Trolley:** Double-check that the case is securely fastened to the trolley. Although internal straps are not included, external bungee cords can be used to further secure the case to the trolley frame for enhanced stability.
- **Removable Base:** Confirm the removable hard base is correctly inserted at the bottom of the main compartment to provide a stable foundation.

Zipper Difficulty

If zippers are stiff or difficult to operate:

- **Lubrication:** Apply a zipper lubricant, graphite from a pencil, or a small amount of bar soap along the zipper teeth.
- **Clear Obstructions:** Check for any fabric or threads caught in the zipper mechanism and carefully remove them.

Product Specifications

Feature	Detail

Feature	Detail
Brand	CAB55
Model	B09YRVHD87
Color	Grey
Max Machine Dimensions	17 x 10.2 x 13.3 inches
Wheels	2 durable wheels
Frame	Sturdy & lightweight aluminum
Internal Storage	6 custom pockets, thread spool holders
Base	Removable hard wooden board
Carrying Options	Top handles, shoulder strap, rolling trolley
First Available	April 25, 2022

Warranty and Support

CAB55 offers a 2-year quality warranty on every rolling case purchased. For any questions or problems regarding your CAB55 Rolling Sewing Machine Case, please contact our customer service team.

For further assistance, please visit the official CAB55 Store:CAB55 Store on Amazon.

© 2023 CAB55. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question