

## Fieldmann FZR 9019-B

# Fieldmann Replacement Blade Instruction Manual

Model: FZR 9019-B

## 1. INTRODUCTION

---

Thank you for choosing the Fieldmann FZR 9019-B Replacement Blade. This manual provides important information regarding the safe installation, proper use, and maintenance of your new blade. Please read these instructions carefully before installation and keep them for future reference. This blade is designed for use with Fieldmann Electric Lawn Mowers FZR 4611-B and FZR 4616-B.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

Always observe basic safety precautions when handling sharp objects and operating power tools. Failure to follow these instructions may result in serious injury.

- **Disconnect Power:** Always ensure the lawn mower is unplugged from the power source before attempting any installation, maintenance, or cleaning.
- **Wear Protective Gear:** Use heavy-duty gloves to protect your hands from sharp edges during handling and installation. Safety glasses are also recommended.
- **Secure the Mower:** Place the lawn mower on a stable, flat surface to prevent it from tipping over during blade replacement.
- **Inspect for Damage:** Before installation, inspect the new blade for any manufacturing defects or damage. Do not install a damaged blade.
- **Proper Disposal:** Dispose of the old blade responsibly, as it may still be sharp.

## 3. PRODUCT OVERVIEW

---

The Fieldmann FZR 9019-B is a high-quality replacement blade designed to restore optimal cutting performance to your electric lawn mower. It is crafted for durability and precision.




Image: Fieldmann FZR 9019-B Replacement Blade. This image shows the 46cm replacement blade, highlighting its design and sharp edges. It is a direct replacement for compatible Fieldmann electric lawn mowers.

### Key Features:

- Precision blades for superior cutting performance.
- Manufactured from high-quality, rust-resistant material.
- Designed to stay sharp longer and cut more efficiently.
- Fine replacement blade suitable for most electric lawn mowers (specifically FZR 4611-B/FZR 4616-B).
- Length: 46cm.

## 4. INSTALLATION INSTRUCTIONS

---

Follow these steps carefully to replace the blade on your Fieldmann electric lawn mower. Always prioritize safety.

1. **Prepare the Mower:** Ensure the lawn mower is completely unplugged from the power supply. Tilt the mower onto its side, ensuring the carburetor (if applicable) is facing upwards to prevent fuel leakage.
2. **Secure the Blade:** To prevent the blade from turning while you loosen the nut, wedge a block of

wood between the blade and the mower deck.

- 3. Remove the Old Blade:** Using an appropriate wrench, loosen the blade retaining nut (usually counter-clockwise). Remove the nut, washer, and the old blade. Note the orientation of the old blade for correct installation of the new one.
- 4. Clean the Area:** Clean any grass clippings or debris from the blade mounting area on the mower deck.
- 5. Install the New Blade:** Place the new Fieldmann FZR 9019-B blade onto the blade shaft, ensuring it is correctly oriented (the cutting edges should face the direction of rotation, typically downwards towards the grass). The blade should sit flush against the blade adapter.
- 6. Reattach Hardware:** Place the washer and then the retaining nut back onto the shaft.
- 7. Tighten the Nut:** Tighten the retaining nut securely with the wrench (usually clockwise). Ensure it is tightened to the manufacturer's specified torque, if available in your mower's manual. Remove the wooden block.
- 8. Check Balance:** After installation, manually rotate the blade to ensure it spins freely and is balanced.

## 5. OPERATION

---

Once the new blade is securely installed, your lawn mower is ready for operation. Always refer to your specific lawn mower's instruction manual for detailed operating procedures, safety guidelines, and recommended cutting heights. Ensure the blade is sharp and free of damage before each use for optimal cutting performance.

## 6. MAINTENANCE AND CARE

---

Proper maintenance extends the life of your blade and ensures consistent cutting quality.

- Cleaning:** After each use, disconnect the mower from power and carefully clean grass clippings and debris from the blade and underside of the mower deck.
- Sharpening:** The blade will dull over time. Sharpen the blade regularly using a blade sharpener or file, maintaining the original cutting angle. Ensure the blade remains balanced after sharpening. If you are unsure, consult a professional.
- Inspection:** Periodically inspect the blade for cracks, bends, or excessive wear. A damaged blade can be dangerous and should be replaced immediately.
- Storage:** Store the blade (if removed) or the mower in a dry place to prevent rust.

## 7. TROUBLESHOOTING

---

If you encounter issues after replacing your blade, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Poor cutting quality / Uneven cut	Blade is dull or damaged. Blade is installed incorrectly.	Sharpen or replace the blade. Re-install the blade, ensuring correct orientation and tightness.

Problem	Possible Cause	Solution
Excessive vibration during operation	Blade is unbalanced (due to uneven sharpening or damage). Blade is not securely tightened.	Check blade balance and re-sharpen if necessary, or replace the blade. Ensure the blade retaining nut is tightened securely.
Blade does not spin freely	Obstruction under the deck. Blade installed incorrectly or binding.	Disconnect power and clear any obstructions. Re-check blade installation for proper fit and clearance.

## 8. TECHNICAL SPECIFICATIONS

---

Below are the technical specifications for the Fieldmann FZR 9019-B Replacement Blade:

Specification	Detail
Item Model Number	FZR 9019-B
Manufacturer	Fieldmann
Product Dimensions (L x W x H)	45.5 x 4 x 3.2 cm
Item Weight	398 grams
Power Type	Mechanical (for electric mower)
Product Reference	FZR 9019-B
ASIN	B09YRYMMY6
Date First Available	21 May 2022
Spare Parts Availability	Information unavailable

## 9. WARRANTY AND SUPPORT

---

Specific warranty information for this replacement blade is not provided in the product details. For warranty claims, technical support, or further assistance, please contact Fieldmann customer service or refer to the documentation provided with your original Fieldmann lawn mower.