

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [KREAFUNK](#) /
- › [KREAFUNK aGO II FABRIC Portable Bluetooth Speaker Instruction Manual](#)

## KREAFUNK KFWT142

# KREAFUNK aGO II FABRIC Portable Bluetooth Speaker

Model: KFWT142

Brand: KREAFUNK

## INTRODUCTION

The KREAFUNK aGO II FABRIC is a compact and powerful portable Bluetooth speaker designed to deliver impressive sound quality wherever you go. Its stylish Danish design, combined with robust features like IPX5 waterproofing and True Wireless Stereo (TWS) functionality, makes it an ideal companion for both indoor and outdoor use. The speaker also incorporates sustainable design elements, featuring a soft recycled textile front made from 98% recycled PET bottles.




Image: Overview of KREAFUNK aGO II FABRIC features, including its waterproof rating, battery life, and compact design, shown in multiple color options.

## PRODUCT OVERVIEW

## Key Features

- **Bluetooth 5.0:** For stable and efficient wireless connectivity.
- **6W Digital Amplifier:** Delivers powerful and clear audio.
- **True Wireless Stereo (TWS):** Connect two aGO II FABRIC speakers for an immersive stereo sound experience.
- **IPX5 Waterproof:** Resistant to water splashes from any direction, suitable for use in bathrooms or outdoors.
- **Long Playback Time:** Up to 10 hours of continuous music playback on a single charge (at initial settings).
- **Compact and Lightweight:** Weighs only 180g with dimensions of 8.0 x 8.0 x 3.6 cm, making it highly portable.
- **Sustainable Design:** Front grille made from 98% recycled PET bottles.

## Included Components

- KREAFUNK aGO II FABRIC Speaker
- USB to USB-C Charging Cable



Image: The KREAFUNK aGO II FABRIC speaker in black, showcasing its compact design and integrated leather strap.



Image: A collection of KREAFUNK aGO II FABRIC speakers displaying the range of available colors.

## SETUP

---

### 1. Charging the Speaker

Before first use, fully charge your aGO II FABRIC speaker. Use the included USB-C charging cable and connect it to a compatible USB power adapter (not included) or a computer's USB port.

- **Charging Time:** Approximately 2-3 hours for a full charge.
- The LED indicator will show charging status (specific indicator behavior not detailed in source, typically red for charging, off/green for full).

どこでも  
吊り下げられる

ループ付き



音楽を  
好きな場所で

浴室や車内、屋内から  
屋外まで、どんな場所でも  
しっかり設置ができます。



Image: The speaker's loop for easy portability and hanging, demonstrating its versatile placement options.

## 2. Powering On/Off

- **To Power On:** Press and hold the power button (location not specified, typically on the side or bottom) until you hear an audible cue or see the LED indicator light up.

- **To Power Off:** Press and hold the power button again until the speaker turns off.

### 3. Bluetooth Pairing


To connect your aGO II FABRIC speaker to a device (smartphone, tablet, laptop):

1. Ensure the speaker is powered on and in pairing mode (usually indicated by a blinking LED).
2. On your device, go to Bluetooth settings and enable Bluetooth.
3. Search for available devices and select "KREAFUNK aGO II FABRIC" (or similar name) from the list.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will typically become solid.

### 4. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two aGO II FABRIC speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be your primary speaker), press and hold the power button (or a dedicated TWS button if available, not specified) until it enters TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation sound once connected.
4. Once TWS paired, connect your device to the primary speaker via Bluetooth as described in step 3.



## ステレオペアリング

2台のaGO II FABRICをペアリングすれば、  
家中どこでも迫力のステレオサウンドに。

ペアリング操作も簡単。本体の電源ボタン  
を長押しすればペアリングができます。  
aGO II 2台を繋げて、より立体感のある  
サウンドを体験してみましょう。



Image: Two aGO II FABRIC speakers demonstrating True Wireless Stereo pairing for a richer audio experience.

## OPERATING INSTRUCTIONS

---

## Music Playback

Once connected via Bluetooth, you can control music playback directly from your connected device. The speaker may also have integrated buttons for basic controls:

- **Play/Pause:** Single press the multi-function button (if available).
- **Volume Up/Down:** Press the '+' or '-' buttons (if available).
- **Next/Previous Track:** Long press the '+' or '-' buttons (if available).

## Call Function


The aGO II FABRIC speaker includes a built-in microphone and call answer button, allowing you to take calls hands-free, even in wet environments like a bathroom, without risking your phone.

- **Answer Call:** Press the call button (or multi-function button) once when a call comes in.
- **End Call:** Press the call button (or multi-function button) once during a call.
- **Reject Call:** Press and hold the call button (or multi-function button) for a few seconds.

## Water Resistance (IPX5)

The speaker's IPX5 rating means it is protected against low-pressure water jets from any direction. This makes it suitable for use in environments where it might get splashed, such as by the pool, at the beach, or in the bathroom. However, it is not designed to be submerged in water.

# BATH TIME



## バスタイムも一緒に

IPX5の防水機能付きだから、バスルームの中に持ち込んでお気に入りの音楽を楽しめます。

通話応答ボタンとマイクも、搭載しているので電話を濡らすことなくバスルームでの通話が可能に。

Image: The aGO II FABRIC speaker in a bathroom, highlighting its IPX5 waterproof capability for enjoying music during bath time.

## Cleaning

To clean your speaker, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the speaker's finish or fabric.

## Battery Care

The built-in rechargeable battery has a limited lifespan. Over time and with repeated use, the battery's capacity will gradually decrease. To maximize battery life:

- Avoid fully discharging the battery frequently.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Charge the speaker periodically if stored for a long time to prevent deep discharge.

## Storage

When storing the speaker, especially for long periods, ensure it is turned off and kept in a dry environment away from extreme temperatures and direct sunlight.

## TROUBLESHOOTING

---

### Speaker Does Not Power On or Charge

- Ensure the charging cable is securely connected to both the speaker and the power source.
- Try using a different USB-C cable or power adapter.
- Verify the power outlet or USB port is functional.

### No Sound or Poor Sound Quality

- Check the volume level on both the speaker and your connected device.
- Ensure the speaker is properly paired via Bluetooth to your device.
- If using TWS, ensure both speakers are correctly paired to each other and then to your device.
- Move the speaker closer to your device to avoid interference.

### Bluetooth Disconnection

- Ensure the speaker and your device are within the effective Bluetooth range.
- Avoid obstacles between the speaker and your device that might interfere with the signal.
- Try unpairing and re-pairing the speaker with your device.

### Short Battery Life

- Battery capacity naturally decreases over time with usage.
- Ensure the speaker is fully charged before use.
- High volume levels can reduce playback time.

## SPECIFICATIONS

---

Feature	Detail
Model Name	KFWT142
Bluetooth Version	5.0
Output Power	6W
Playback Function	Stereo Playback (True Wireless Stereo)
Waterproof Rating	IPX5
Weight	180 g
Dimensions (L x W x H)	8.0 x 8.0 x 3.6 cm
Continuous Playback Time	Up to 10 hours (initial settings)
Charging Time	Approx. 2-3 hours
Charging Port	USB Type-C
Compatible Devices	iOS, Android, Mac OS, Windows, Linux
Materials	Metal, Plastic (with recycled textile front)
Included Components	USB to USB-C Charging Cable

## WARRANTY AND SUPPORT

KREAFUNK products are manufactured to high-quality standards. For information regarding product warranty, returns, or technical support, please refer to the official KREAFUNK website or contact your local retailer. Keep your proof of purchase for any warranty claims.

For frequently asked questions, you may also refer to the brand's support resources:

- Why choose KREAFUNK? (Waterproof Design):** KREAFUNK speakers feature powerful waterproof performance, allowing you to enjoy music without worrying about the weather. Enjoy music freely outdoors, camping, or while traveling.
- Why choose KREAFUNK? (Pairing Function):** Connect two KREAFUNK speakers for a more immersive sound experience.
- Why choose KREAFUNK? (Sustainable Materials):** KREAFUNK is committed to developing more environmentally friendly products, collaborating with Danish textile company Gabriel to use recycled materials. Contributing to a sustainable future from the world of music.

