

[manuals.plus](#) /› [KREAFUNK](#) /› [KREAFUNK aGO II Tissu Portable Bluetooth Speaker User Manual](#)

KREAFUNK aGO II Tissu

KREAFUNK aGO II Tissu Portable Bluetooth Speaker User Manual

Model: aGO II Tissu (KFWT146)

1. INTRODUCTION

Thank you for choosing the KREAFUNK aGO II Tissu Portable Bluetooth Speaker. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it carefully before use and retain it for future reference.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- KREAFUNK aGO II Tissu Portable Bluetooth Speaker
- USB to USB-C Charging Cable
- User Manual (this document)

3. PRODUCT OVERVIEW

The KREAFUNK aGO II Tissu is a compact and waterproof portable Bluetooth speaker designed for high-quality audio on the go. It features a durable construction with upcycled fabric and leather elements.



Figure 3.1: Front view of the KREAFUNK aGO II Tissu speaker, showcasing its soft yellow casing, grey fabric grille, and brown leather strap.

Controls and Ports



Figure 3.2: Side view of the speaker, illustrating the power button, volume controls, and the USB-C charging port.

- **Power Button:** Press and hold to turn on/off.
- **Volume Up/Next Track Button:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track Button:** Short press for volume down, long press for previous track.
- **USB-C Charging Port:** For connecting the charging cable.

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge your aGO II Tissu speaker.

1. Connect the small end of the included USB-C charging cable to the USB-C port on the speaker.
2. Connect the standard USB end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, off or green for fully charged, refer to product specific LED behavior if available).
4. Once fully charged, disconnect the cable.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power Button for approximately 3 seconds until you hear an audible cue or see the LED indicator light up.
- **To Power Off:** Press and hold the Power Button for approximately 3 seconds until you hear an audible cue or the LED indicator turns off.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Pairing

To connect your aGO II Tissu speaker to a Bluetooth-enabled device (smartphone, tablet, laptop):

1. Ensure the speaker is powered on and in pairing mode (the LED indicator will typically flash blue rapidly). If not, you may need to press and hold the Bluetooth button (often combined with the power button or a dedicated button) to initiate pairing mode.
2. On your device, go to the Bluetooth settings.
3. Search for available devices. You should see "KREAFUNK aGO II Tissu" or a similar name in the list.
4. Select the speaker to pair. Once paired, the LED indicator will usually turn solid blue, and you will hear a confirmation sound.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

5.2. Audio Playback and Controls

- **Play/Pause:** Short press the Power Button (or a dedicated Play/Pause button if available).
- **Volume Adjustment:** Short press the Volume Up (+) or Volume Down (-) buttons.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.
- **Voice Control:** The speaker supports voice control functionality, likely by passing through commands to your connected smartphone's voice assistant. Press the Power Button (or a dedicated button) to activate your device's voice assistant.

5.3. Waterproof Feature

The aGO II Tissu speaker is waterproof. This means it can withstand splashes and light rain. However, it is not designed for submersion in water. Ensure the USB-C charging port cover is securely closed before exposing the speaker to moisture.

6. MAINTENANCE

6.1. Cleaning

To clean your speaker, use a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the speaker's finish and fabric grille.

6.2. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its lifespan.

7. TROUBLESHOOTING

If you encounter issues with your aGO II Tissu speaker, refer to the following common problems and solutions:

Problem	Possible Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.

Problem	Possible Solution
Cannot pair with Bluetooth device.	Ensure the speaker is in pairing mode (LED flashing). Turn off and on Bluetooth on your device. Move the speaker closer to your device. Forget the speaker from your device's Bluetooth list and try pairing again.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly paired. Check if the audio source is playing.
Sound distortion.	Reduce the volume on both the speaker and your connected device. Move the speaker closer to your device to improve Bluetooth signal.
Charging not working.	Check the USB-C cable and power adapter for damage. Try a different cable or power source. Ensure the charging port is clean and free of debris.

8. SPECIFICATIONS

- Brand:** KREAFUNK
- Model Name:** aGO II Tissu
- Model Number:** KFWT146
- Color:** Soft Yellow
- Connectivity Technology:** Bluetooth, USB
- Wireless Communication Technology:** Bluetooth
- Speaker Size:** 53 mm
- Maximum Speaker Output Power:** 6 Watts
- Control Method:** Voice (via connected device)
- Power Source:** Electric Cable (for charging internal battery)
- Waterproof:** Yes
- Material:** Plastic, silicone, upcycled leather, upcycled fabric grille, metal
- Recommended Uses:** For smartphone or tablet
- Compatible Devices:** Laptop, Smartphone, Tablet
- Included Components:** USB to USB-C charging cable

9. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Keep the speaker away from strong magnetic fields.
- Avoid dropping or subjecting the speaker to strong impacts.
- Ensure the charging port cover is sealed when near water to maintain waterproof integrity.
- Dispose of the speaker and its battery responsibly according to local regulations.

10. WARRANTY AND SUPPORT

KREAFUNK products are designed and manufactured to the highest quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official KREAFUNK website. Please have your model number (KFWT146) and proof of purchase ready when contacting support.

Related Documents - aGO II Tissu

 aGO II Bluetooth speaker Operation manual kreafunk	<u>Kreafunk aGO II Bluetooth Speaker Operation Manual</u> Official operation manual for the Kreafunk aGO II portable Bluetooth speaker. Learn about setup, charging, features, and maintenance for your wireless audio device.
 aGO II fabric Bluetooth speaker Operation manual kreafunk	<u>Kreafunk aGO II fabric Bluetooth Speaker Operation Manual</u> Comprehensive operation manual for the Kreafunk aGO II fabric Bluetooth speaker, detailing setup, usage, safety, maintenance, and technical specifications. Made from 100% recycled plastic.
 aGO mini Bluetooth speaker Operation manual kreafunk	<u>Kreafunk aGO mini Bluetooth Speaker: Operation Manual & Specifications</u> Comprehensive operation manual for the Kreafunk aGO mini Bluetooth speaker. Includes setup, pairing, charging, battery status, TWS stereo pairing, technical specifications, FCC compliance, and safety instructions. Made from 100% recycled plastic.
 aGO fabric Bluetooth speaker User manual kreafunk	<u>Kreafunk aGO fabric 2 Bluetooth Speaker User Manual</u> User manual for the Kreafunk aGO fabric 2 Bluetooth speaker, covering setup, operation, and safety instructions.
 aGO fabric 2 Bluetooth speaker Operation manual kreafunk	<u>Kreafunk aGO fabric 2 Bluetooth Speaker: Operation Manual & Safety Guide</u> Comprehensive operation manual and safety guide for the Kreafunk aGO fabric 2 Bluetooth speaker, covering setup, usage, technical specifications, and maintenance.
 aBEAT Wireless headphones with ANC Operation manual kreafunk	<u>Kreafunk aBEAT Wireless Headphones with ANC - Operation Manual</u> Comprehensive operation manual for Kreafunk aBEAT wireless headphones, detailing features like Active Noise Cancellation (ANC), Bluetooth pairing, charging, battery status, controls for music playback and calls, and important safety and maintenance information.