

[manuals.plus](#) /

› [KREAFUNK](#) /

› [KREAFUNK aGO mini Portable Bluetooth Speaker User Manual](#)

## KREAFUNK aGO mini

# KREAFUNK aGO mini Portable Bluetooth Speaker User Manual

Model: aGO mini

## 1. INTRODUCTION

Thank you for choosing the KREAFUNK aGO mini Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your new speaker. Please read these instructions carefully before use and retain them for future reference.

## 2. PACKAGE CONTENTS

Ensure all items are present in the package:

- KREAFUNK aGO mini Portable Bluetooth Speaker
- Charging Cable (USB)

## 3. PRODUCT FEATURES

- **Compact Design:** Small and lightweight for easy portability.
- **Bluetooth Connectivity:** Wireless streaming from compatible devices.
- **Water Resistant (IPX5):** Suitable for indoor and outdoor use, protected against low-pressure water jets from any direction.
- **Long Playtime:** Up to 12 hours of wireless play on a single charge.
- **Stereo Sound:** Delivers clear audio output.
- **Quick Charging:** Fully charges within 1 hour.

## 4. PRODUCT OVERVIEW

The KREAFUNK aGO mini speaker features a minimalist design with a durable casing and a metal grille. A small

loop is integrated for easy carrying.




Image 1: Front view of the KREAFUNK aGO mini speaker in blue, showcasing its compact, spherical design and top grille.



Image 2: Two KREAFUNK aGO mini speakers placed side-by-side on a dark surface, illustrating their small size and potential for stereo pairing.



Image 3: The KREAFUNK aGO mini speaker positioned on a light-colored table, with a person seated on a sofa in the blurred background, demonstrating its use in a home environment.

## 5. SETUP

### 5.1 Charging the Speaker

1. Locate the charging port on your aGO mini speaker.
2. Connect the provided USB charging cable to the speaker's charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate. The speaker will be fully charged in approximately 1 hour.
5. Once fully charged, disconnect the charging cable.

### 5.2 Bluetooth Pairing

1. Ensure the speaker is charged and powered off.
2. Press and hold the power button (usually indicated by a symbol or tactile difference) until you hear an audible prompt or see a flashing LED light, indicating it is in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "KREAFUNK aGO mini" from the list of available devices.
5. Once connected, you will hear a confirmation sound or the LED light will change to a solid color.
6. Your speaker is now ready to play audio.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Power On/Off

- **To Power On:** Press and hold the power button for a few seconds until the indicator light turns on and you hear a startup sound.
- **To Power Off:** Press and hold the power button for a few seconds until the indicator light turns off and you hear a shutdown sound.

### 6.2 Audio Playback

- Once paired, play audio from your connected device. The sound will be transmitted to the aGO mini speaker.
- Volume control is primarily managed through your connected device. The speaker may have touch controls for basic functions.

### 6.3 Water Resistance (IPX5)

The aGO mini speaker is rated IPX5, meaning it is protected against low-pressure water jets from any direction. This makes it suitable for use in environments where it might encounter splashes, such as by a pool or during light rain. It is **not** designed for submersion in water.

## 7. MAINTENANCE

---

### 7.1 Cleaning

- Wipe the speaker with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.
- Ensure the charging port is dry before charging.

### 7.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in dusty environments.

## 8. TROUBLESHOOTING

---

- **Speaker does not power on:** Ensure the battery is charged. Connect the charging cable and try again.
- **Cannot pair with Bluetooth device:**
  - Ensure the speaker is in pairing mode (flashing LED).
  - Make sure Bluetooth is enabled on your device.
  - Move the speaker closer to your device (within 10 meters).
  - Turn off and on both the speaker and your device's Bluetooth.
  - Forget the device from your Bluetooth list and try pairing again.
- **No sound or low volume:**
  - Increase the volume on both the speaker and your connected device.
  - Ensure the speaker is properly paired and connected.
  - Check if the audio source on your device is playing.

- **Short battery life:**

- Ensure the speaker is fully charged before use.
- Battery life can vary based on volume level and usage.

## 9. SPECIFICATIONS

Feature	Specification
Brand	KREAFUNK
Model Name	aGO mini
Item Model Number	18885
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Speaker Type	Outdoor and Indoor
Special Feature	Lightweight, Waterproof (IPX5)
Audio Output Mode	Stereo
Speaker Maximum Output Power	3 Watts
Power Source	Battery Powered
Battery Capacity	300 mAh (Lithium Ion)
Charging Time	1 Hour
Play Time	Up to 12 Hours
Material	Metal, Plastic
Product Dimensions	2"D x 2"W x 1.3"H
Item Weight	2.4 ounces
Control Method	Touch

## 10. WARRANTY AND SUPPORT

The KREAFUNK aGO mini Portable Bluetooth Speaker comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official KREAFUNK website.

For technical support, troubleshooting assistance, or any inquiries not covered in this manual, please contact KREAFUNK customer service through their official channels. Contact information can typically be found on the KREAFUNK website or product packaging.

## Related Documents - aGO mini

 Operation manual  kreafunk	<a href="#"><u>Kreafunk aGO fabric 2 Bluetooth Speaker: Operation Manual &amp; Safety Guide</u></a> Comprehensive operation manual and safety guide for the Kreafunk aGO fabric 2 Bluetooth speaker, covering setup, usage, technical specifications, and maintenance.
 Operation manual  kreafunk	<a href="#"><u>Kreafunk aGO II Bluetooth Speaker Operation Manual</u></a> Official operation manual for the Kreafunk aGO II portable Bluetooth speaker. Learn about setup, charging, features, and maintenance for your wireless audio device.
 Operation manual  kreafunk	<a href="#"><u>Kreafunk aGO II fabric Bluetooth Speaker Operation Manual</u></a> Comprehensive operation manual for the Kreafunk aGO II fabric Bluetooth speaker, detailing setup, usage, safety, maintenance, and technical specifications. Made from 100% recycled plastic.
 Operation manual  kreafunk	<a href="#"><u>Kreafunk aGO mini Bluetooth Speaker: Operation Manual &amp; Specifications</u></a> Comprehensive operation manual for the Kreafunk aGO mini Bluetooth speaker. Includes setup, pairing, charging, battery status, TWS stereo pairing, technical specifications, FCC compliance, and safety instructions. Made from 100% recycled plastic.
 User manual  kreafunk	<a href="#"><u>Kreafunk aGO fabric 2 Bluetooth Speaker User Manual</u></a> User manual for the Kreafunk aGO fabric 2 Bluetooth speaker, covering setup, operation, and safety instructions.
 Operation manual  kreafunk	<a href="#"><u>Kreafunk aGO mini Bluetooth Speaker Operation Manual</u></a> Learn how to operate your Kreafunk aGO mini Bluetooth speaker with this comprehensive operation manual. Covers setup, charging, playback, and stereo pairing.