Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Spigen /
- > Spigen AquaShield Waterproof Pouch and Case A621 Instruction Manual

Spigen A621

Spigen AquaShield Waterproof Pouch and Case A621 Instruction Manual


Model: A621

PRODUCT OVERVIEW

The Spigen AquaShield Waterproof Pouch and Waterproof Case A621 is designed to protect your mobile phone and other essential accessories from water, sand, dust, and other environmental elements. This product is suitable for various outdoor and indoor activities, including travel, camping, swimming, and water sports. The set includes a transparent waterproof phone case and a larger waterproof pouch.



An overview of the Spigen AquaShield set, featuring a black waterproof pouch and a transparent waterproof phone case with a lanyard.




This image illustrates the Spigen AquaShield Pouch Bag and Floating Phone Case being used during water activities, highlighting their utility for protecting essentials.

SETUP AND INITIAL USE

Waterproof Pouch Setup

Follow these steps to properly secure items within the waterproof pouch:

- 1. **Insert Items:** Place your valuables, such as wallets, keys, or small electronics, into the main compartment of the pouch.
- 2. Close the Lock: Align the top edges of the pouch and firmly close the integrated locking mechanism.
- 3. **Roll Down:** Roll the top edge of the pouch down several times to create a tight seal.
- 4. **Fasten with Hook-and-Loop:** Secure the rolled-down section using the hook-and-loop fastener to prevent unrolling and enhance the seal.



Secure Lock System.


Completely sealed to protect your phone underwater.

A step-by-step guide on how to properly seal the waterproof pouch: 1. Put items into bag, 2. Close the lock, 3. Roll down, 4. Fasten with the hook-and-loop closure.

Waterproof Phone Case Setup

To use the waterproof phone case, follow these instructions:

- 1. Pull Open the Clip: Gently pull open the two clips located at the top of the phone case.
- 2. **Insert Phone:** Carefully slide your smartphone into the transparent pouch. Ensure it is centered for optimal touchscreen access.
- 3. Lock Case by Pushing Buttons: Firmly push down on both clips until they snap securely into place, creating a watertight seal.



Instructions for securing the waterproof phone case: 1. Pull open the clip, 2. Put phone into bag with ease, 3. Lock case by pushing the buttons, and an image of the Dura Strap.


OPERATION

Touchscreen Functionality

The transparent waterproof phone case is designed to maintain touchscreen compatibility, allowing you to check messages, take photos, and use your phone's functions while it is protected inside the case.

Wearing Options

Both the waterproof pouch and phone case come with adjustable straps for convenient carrying. The pouch features a Dura Strap that can be adjusted to fit various users and worn as a cross-body bag or around the waist, providing hands-free convenience during activities.



Dura Strap.

Durable eslatic strap helps you stay hands-free.

This image demonstrates the versatility of the Dura Strap, showing how the pouch can be worn as a cross-body bag or around the waist, along with strap length measurements.

Universal compatibility

Spacious size to keep your valuables safe and secured.



This image showcases the spacious size of the waterproof phone case, demonstrating its compatibility with various smartphone models like the Galaxy S23 Ultra and iPhone 14 Pro Max, and illustrates the adjustable Dura Strap.

MAINTENANCE

To ensure the longevity and effectiveness of your Spigen AquaShield products, please follow these care instructions:

- Cleaning: Hand wash only. Use mild soap and water to clean the surfaces. Avoid harsh chemicals or abrasive materials.
- **Drying:** After each use, especially in saltwater, rinse the pouch and case with fresh water and allow them to air dry completely before storage.
- **Storage:** Store in a cool, dry place away from direct sunlight and sharp objects that could puncture the material.

Troubleshooting

If you encounter issues with the waterproof performance, consider the following:

- **Seal Integrity:** Always perform a quick check of the sealing mechanisms (clips, rolls, hook-and-loop) before submerging the product. Ensure no debris is caught in the seal.
- **Damage Check:** Inspect the pouch and case for any visible tears, punctures, or damage to the material that could compromise its waterproof capabilities.
- **Test Before Use:** It is recommended to perform a waterproof test with a tissue inside the pouch/case before placing your actual devices or valuables, especially for critical applications.

SPECIFICATIONS

- Model: A621
- Waterproof Rating: IPX8 Certified (Safe for use in water up to 30 meters / 100 feet)
- Compatibility: Universal size for most smartphones (e.g., Galaxy S23 Ultra, iPhone 14 Pro Max)
- **Features:** Transparent touchscreen compatible phone case, floatable phone case design with air pocket, adjustable waist/neck strap (Dura Strap)
- Strap Length (Pouch): Approximately 810mm ~ 1117mm
- Strap Length (Phone Case): Minimum 15.7 inches (400mm) Maximum 22 inches (560mm)
- Care Instructions: Hand Wash Only

• Department: Unisex

• Manufacturer: Spigen





IPX8 Certified Waterpoof Rating.

Safe to use in water up to 30 meters (100ft).

Detailing the IPX8 waterproof certification, indicating the product's ability to withstand continuous immersion in water up to 30 meters (100 feet).





Floatable Waterproof Case.

Less likely to get lost, even if you drop it in the water. Air Pocket protects device from impact.

This image highlights the floatable design of the waterproof phone case, featuring a smooth edge and an air pocket for impact protection and buoyancy.

CUSTOMER SUPPORT

For further assistance, product inquiries, or support, please visit the official Spigen website or contact Spigen customer service through their designated support channels.

Official Spigen Website: www.spigen.com