

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VIKING](#) /

› [VIKING Car Wash Brush \(Model 997801\) - Instruction Manual](#)

VIKING 997801

VIKING Car Wash Brush (Model 997801) Instruction Manual

Brand: VIKING

Model: 997801

PRODUCT OVERVIEW

The VIKING Car Wash Brush is a 16.5-inch long tool designed for effective cleaning of various vehicle surfaces. Its ergonomic design and soft, triple-flagged bristles provide a gentle yet thorough scrub for areas such as grills, fenders, fender flares, bumpers, wheel wells, and tires. This versatile brush is suitable for cars, bikes, motorcycles, boats, and RVs.



Image: The VIKING Car Wash Brush, showcasing its overall design and size.

KEY FEATURES

- **Long Handle (16.5 inches):** Provides extended reach for cleaning difficult-to-access areas like deep wheel wells and high fenders.




Image: The VIKING Car Wash Brush with its long handle reaching into a vehicle's wheel well, demonstrating its extended reach.

- **Soft, Triple-Flagged Bristles:** Engineered for gentle scrubbing with maximum coverage, preventing scratches on delicate surfaces while effectively removing dirt and grime.



Image: Close-up of the VIKING Car Wash Brush bristles, highlighting their soft, dense, and flagged tips for gentle cleaning.

- **Protective Rubber Bumper:** A rubberized edge around the brush head prevents accidental scratches or marks on vehicle surfaces during use.



Image: The rubber bumper around the head of the VIKING Car Wash Brush, designed to protect vehicle surfaces.

- **Ergonomic Handle with Non-Slip Grip:** Designed for comfortable handling and secure grip, even when wet, enhancing control during cleaning tasks.



Image: Diagram illustrating the ergonomic handle and non-slip rubber grip of the VIKING Car Wash Brush.

USAGE INSTRUCTIONS

Preparation

Before use, ensure the brush is clean and free of any debris that could scratch your vehicle. Prepare a bucket of your preferred car wash soap and water.

Cleaning Wheels and Tires

Dip the brush into the soapy water, ensuring the bristles are thoroughly saturated. Apply the brush to the wheels and tires, scrubbing gently to remove dirt, brake dust, and grime. The long handle allows for easy access to inner wheel surfaces and tire sidewalls.

Your browser does not support the video tag.

Video: Demonstrating the effective use of the VIKING Car Wash Brush for cleaning vehicle wheels and tires, highlighting its reach

and scrubbing action.

Cleaning Grills and Fenders

For grills, fenders, and fender flares, use the brush with soapy water to clean intricate areas and contours. The soft bristles are safe for painted surfaces, but always test in an inconspicuous area first. The rubber bumper helps prevent accidental contact damage.

Your browser does not support the video tag.

Video: Showcasing the VIKING Car Wash Brush being used to clean a vehicle's front grill, demonstrating its ability to reach tight spaces.

General Vehicle Cleaning

This brush can also be used for other vehicle parts like bumpers and wheel wells. Its design makes it suitable for various vehicle types, including cars, trucks, motorcycles, boats, and RVs.

Your browser does not support the video tag.

Video: Illustrating the versatility of the VIKING Car Wash Brush for cleaning various parts of a vehicle, including the grill and fender areas.

MAINTENANCE

- Cleaning the Brush:** After each use, rinse the brush thoroughly with clean water to remove all soap residue and debris.
- Drying:** Shake off excess water and allow the brush to air dry completely before storing.
- Storage:** Store the brush in a clean, dry place away from direct sunlight to prolong its lifespan.
- Inspection:** Regularly inspect the bristles for any embedded particles that could cause scratches. Remove any such particles before use.

SPECIFICATIONS

Brand	VIKING
Color	Gray
Handle Material	Rubber
Material	Rubber
Surface Recommendation	Metal, Plastic, Glass
Number of Items	1
Item Firmness Description	Soft
Item Weight	11.7 Ounces
Manufacturer	Schroeder & Tremayne, Inc.
UPC	075182099784
Item Model Number	997801
Package Dimensions	17.24 x 3.9 x 3.86 inches

WARRANTY AND SUPPORT

Warranty Information

This brush is guaranteed to provide satisfactory performance. Material items with defective workmanship that have been properly cared for as instructed will be replaced free of charge within 60 days from purchase. This warranty does not cover damage due to improper use or general wear and tear. Please retain the defective product for possible future inspection.

Customer Support

For further assistance or inquiries, please refer to the manufacturer's contact information provided on the product packaging or visit the official VIKING website.

© 2026 VIKING. All rights reserved.