Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KREAFUNK 18886

KREAFUNK aGO mini Portable Bluetooth Speaker

User Manual - Model 18886

Introduction

Thank you for choosing the KREAFUNK aGO mini Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your device. Please read it thoroughly before operation and retain it for future reference.
The aGO mini is a compact, water-resistant (IPX5) Bluetooth speaker designed to deliver quality audio both indoors and outdoors. It offers up to 12 hours of wireless playback and features a durable design for portability.

What's in the Box

- KREAFUNK aGO mini Portable Bluetooth Speaker
- Charging Cable (USB)



Image: The aGO mini speaker in pink, showcasing its compact design and integrated loop.

Product Overview

The aGO mini features a minimalist design with a speaker grille on top and a small loop for portability. The charging port and control buttons are typically located on the side or bottom of the unit. Refer to the diagram below for common component locations.



Image: A detailed view of the aGO mini speaker, highlighting its speaker grille and smooth casing.

Setup

1. Charging the Speaker

1. Locate the charging port on your aGO mini speaker.
2. Connect the included USB charging cable to the speaker and to a compatible USB power source (e.g., computer, USB wall adapter).
3. The charging indicator light will illuminate, typically red, during charging.
4. A full charge takes approximately 1 hour. The indicator light will change or turn off when charging is complete.

2. Bluetooth Pairing

1. Ensure the speaker is fully charged before initial pairing.
2. Press and hold the power button on the speaker until you hear an audible prompt or see a blinking LED, indicating it is in pairing mode.
3. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
4. Search for available devices and select "aGO mini" from the list.
5. Once connected, you will hear a confirmation sound, and the LED indicator will typically become solid blue.
6. The speaker has a Bluetooth range of up to 10 meters (32.8 feet).

Operating Instructions

Power On/Off

- To power on: Press and hold the power button until the indicator light illuminates.
- To power off: Press and hold the power button until the indicator light turns off.

Audio Playback

Once paired, audio from your connected device will automatically stream to the aGO mini. Volume control is primarily managed through your connected device. Some models may feature integrated volume buttons.

Water Resistance (IPX5)

The aGO mini is rated IPX5 water-resistant, meaning it can withstand splashes of water from any direction. It is suitable for use outdoors or near water sources like pools, but it should not be submerged in water.



Image: Two aGO mini speakers in a blue color variant, demonstrating their suitability for outdoor environments.

Maintenance

Cleaning

- Ensure the speaker is powered off and disconnected from any power source before cleaning.
- Wipe the exterior with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents.
- Do not allow water to enter the charging port or speaker grille.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery	Charge the speaker for at least 1 hour.
Cannot pair via Bluetooth	Speaker not in pairing mode; Device out of range; Previously paired device connected	Ensure speaker is in pairing mode. Move device closer. Disconnect from other devices or forget the speaker in your device's Bluetooth settings and re-pair.
No sound or low volume	Volume on speaker/device too low; Speaker not connected	Increase volume on both the speaker and your connected device. Verify Bluetooth connection.
Sound distortion	Volume too high; Device too far from speaker	Reduce volume. Move device closer to the speaker.

Specifications

Model Name: aGO mini

Item Model Number: 18886

Brand: KREAFUNK

Color: Pink

Product Dimensions: 2"D x 2"W x 1.3"H

Item Weight: 2.4 ounces

Material: Metal, Plastic

Speaker Type: Outdoor and Indoor

Special Feature: Lightweight, Waterproof (IPX5)

Connectivity Technology: Bluetooth

Wireless Communication Technology: Bluetooth

Bluetooth Range: 10 Meters (32.8 Feet)

Speaker Maximum Output Power: 3 Watts

Audio Output Mode: Stereo

Power Source: Corded Electric (via USB charging)

Charging Time: 1 Hour

Play Time: Up to 12 Hours

Batteries: 1 Lithium Ion battery required (included)

Control Method: App (implied, but primary control via device)

Compatible Devices: Laptop, Smartphone, Tablet

Warranty & Support

Warranty Information

The KREAFUNK aGO mini speaker comes with a Limited Warranty. Please refer to the warranty card included with your product or visit the official KREAFUNK website for detailed terms and conditions.

Customer Support

For further assistance, technical support, or warranty claims, please contact KREAFUNK customer service. You can find contact information on the official KREAFUNK website or through your retailer.



Image: The aGO mini speaker held in a hand, illustrating its compact and portable nature.

© 2023 KREAFUNK. All rights reserved.

For more information, visit KREAFUNK Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YT5ZD6X

More documents and user manuals: **https://manuals.plus/**