Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Faugcol 131430

Faugcol Lawn Mower Tractor Belt (Model 131430) Instruction Manual

1. Product Overview

This manual provides essential information for the installation, maintenance, and safe operation of your Faugcol Lawn Mower Tractor Belt. This belt is designed for various lawn mower and tractor models, ensuring efficient power transmission.



Image: A Faugcol lawn mower belt, coiled and resting on green grass, showcasing its durable construction.

2. Compatibility

The Faugcol Lawn Mower Tractor Belt (Model 131430) is a replacement part compatible with a range of lawn mower and tractor models. Please verify your equipment's required belt specifications before installation.

Replaces Part Numbers:

- Toro: 116160, 11-6160, 21-0890
- Murray: 26659
- Honda: 76181-763-A02
- Bunton: PL1361
- Dayco: L572
- Dixon: 7725
- Gates: 6972

- Goodyear: 85720
- Jacobsen: 343359
- Westwood: 1721
- Yazoo: 205-518

Fits Models:

- Toro: 05-38SY01, 05-42RY01, 05-42SY01, 05-42SY02, 05-42SY03, 05-52SY01, 05-52SY02, 78415, 78460
- Honda: H3011, H3011H, H3013H

3. Features

This Faugcol belt is constructed with high-quality materials to ensure durability and reliable performance.

- **Material:** Durable Rubber construction.
- **Design:** Serpentine belt style for efficient power transfer.
- **Dimensions:** 5/8 inch width, 72 inch length.
- **Performance:** Engineered for high tensile strength and wear resistance.



Image: A close-up view of the Faugcol lawn mower belt, highlighting its textured surface and construction details.

4. Installation / Setup

Proper installation is crucial for the longevity and performance of your lawn mower belt. Always refer to your equipment's specific service manual for detailed instructions and safety precautions.

1. **Safety First:** Ensure the lawn mower or tractor is turned off, the engine is cool, and the spark plug wire is disconnected to prevent accidental starting.
2. **Access the Deck:** Depending on your model, you may need to remove the mower deck or lift the equipment to access the belt system.
3. **Remove Old Belt:** Carefully observe the routing of the old belt before removing it. Take photos if necessary. Release any tensioners or idler pulleys to remove the worn belt.
4. **Inspect Pulleys:** Check all pulleys for wear, damage, or misalignment. Replace any faulty components to prevent premature belt failure.
5. **Install New Belt:** Route the new Faugcol belt according to the original path. Ensure it sits correctly in all pulley

grooves.

6. **Tension Adjustment:** Re-engage tensioners or adjust as per your equipment's manual to achieve the correct belt tension. The belt should be snug but not overly tight.
7. **Reassemble:** Reattach any removed components and reconnect the spark plug wire.
8. **Test Run:** Start the equipment and engage the blades (if applicable) at a low speed in a safe area to ensure the belt operates smoothly without slipping or unusual noises.



Image: A Faugcol lawn mower belt correctly installed on a complex pulley system, demonstrating proper routing.

5. Maintenance

Regular inspection and maintenance will extend the life of your Faugcol belt and ensure optimal performance of your equipment.

- **Regular Inspection:** Periodically check the belt for signs of wear, cracks, fraying, glazing, or stretching. Replace the belt if any damage is observed.
- **Cleanliness:** Keep the belt and pulleys free from grass clippings, dirt, oil, and other debris. Clean with a dry cloth or

brush. Avoid using harsh chemicals.

- **Proper Storage:** If removing the belt for seasonal storage, store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Tension Check:** Ensure the belt maintains proper tension. An overly loose belt can slip, while an overly tight belt can cause premature wear on both the belt and pulleys.

6. Troubleshooting

If you encounter issues with your lawn mower belt, consider the following common problems and solutions:

- **Belt Slipping:** This often indicates incorrect tension (too loose) or worn pulleys. Check and adjust tension, or inspect/replace pulleys.
- **Excessive Noise (Squealing/Grinding):** Can be caused by a misaligned belt, worn pulleys, or incorrect tension. Verify belt routing, inspect pulleys, and adjust tension.
- **Premature Belt Wear/Breakage:** Often due to improper installation, misaligned pulleys, worn bearings, or operating the equipment beyond its capacity. Ensure correct installation and check all related components.
- **Vibration:** May indicate a damaged or unbalanced belt, or issues with pulleys or other rotating parts. Inspect the belt for damage and check pulleys.

7. Specifications

Attribute	Detail
Model Number	131430
Brand	Faugcol
Material	Rubber
Width	5/8 inches (0.63 inches)
Length	72 inches
Belt Style	Serpentine
Item Weight	11.2 ounces

8. Product Videos

Watch these official videos for additional information on the Faugcol Lawn Mower Belt.

Your browser does not support the video tag.

Video: An overview of the Faugcol Lawn Mower Belt, demonstrating its features and manufacturing process. This video highlights the quality and construction of the belt.

Your browser does not support the video tag.

Video: A demonstration of the lawn mower deck drive belt in action, showing its function and fit within a lawn mower system.

9. Warranty & Support

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer

service. Keep your purchase receipt for warranty claims.

Manufacturer: Faugcol

Return Policy: 30-day refund/replacement policy (as per Amazon's policy at the time of data extraction).

© 2024 Faugcol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YTY3TK6

More documents and user manuals: **https://manuals.plus/**