H.Koenig SMOO16

H.Koenig SMOO16 Mini Blender User Manual

Model: SMOO16

1. Introduction

Thank you for choosing the H.Koenig SMOO16 Mini Blender. This compact and powerful 300W blender is designed for preparing fresh smoothies and drinks quickly and conveniently. With its 570 mL portable bottles and durable stainless steel blades, it is ideal for a healthy lifestyle on the go. Please read this manual carefully before first use to ensure safe and optimal operation of your appliance.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Unplug the blender from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base in water or other liquids. Clean only with a damp cloth.
- Avoid contact with moving parts. Keep hands and utensils out of the blending bottle while blending to prevent severe injury and/or damage to the blender.
- The blades are sharp. Handle with extreme care when assembling, disassembling, or cleaning.
- Do not blend hot liquids, as this may cause pressure buildup and result in scalding or injury.
- Never operate the blender without ingredients in the bottle.
- Do not overfill the blending bottle beyond the maximum fill line.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

3. Product Components

The H.Koenig SMOO16 Mini Blender includes the following components:

- Blender Motor Base (300W)
- Blade Assembly with 4 Stainless Steel Blades
- 2 x 570 mL Portable Blending Bottles (BPA-free)
- 2 x Travel Lids with Silicone Contours



Image: H.Koenig SMOO16 Mini Blender components including the motor base, blade assembly, and a portable blending bottle.



Image: Three empty H.Koenig SMOO16 portable bottles, each with a travel lid, ready for use or storage.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the blending bottles, travel lids, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1-2 cm) to ensure optimal blending.
4. **Fill Bottle:** Add your desired ingredients to one of the 570 mL blending bottles. Always add liquids first, then soft ingredients, and finally harder ingredients or ice. Do not exceed the maximum fill line indicated on the bottle.
5. **Attach Blade Assembly:** Screw the blade assembly firmly onto the open end of the filled blending bottle. Ensure it is securely tightened to prevent leaks.
6. **Place on Base:** Invert the bottle (with the blade assembly facing down) and place it onto the motor base. Align the tabs on the bottle with the slots on the base and twist clockwise until it locks into place.



Image: The H.Koenig SMOO16 Mini Blender with a blending bottle filled with various fruits, securely attached to the motor base, ready for operation.

5. Operating Instructions

1. **Connect Power:** Plug the blender into a standard electrical outlet.
2. **Start Blending:** Press and hold the power button on the front of the motor base to begin blending. For best results and to prevent overheating, blend in short pulses (e.g., 10-20 seconds on, then a few seconds off).

3. **Monitor Consistency:** Continue blending until your desired consistency is achieved. If ingredients are too thick, you may need to add more liquid.
4. **Stop Blending:** Release the power button to stop the blending process.
5. **Remove Bottle:** Twist the blending bottle counter-clockwise to unlock it from the motor base, then lift it off.
6. **Enjoy Your Drink:** Unscrew the blade assembly from the bottle. Screw on a travel lid to take your drink with you, or pour it into a glass.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your H.Koenig SMOO16 Mini Blender.

1. **Unplug:** Always ensure the blender is unplugged from the power outlet before cleaning.
2. **Clean Bottles and Lids:** The blending bottles and travel lids are dishwasher safe. For best results and to prolong their life, hand washing with warm, soapy water is recommended, especially for the silicone parts. Rinse thoroughly.
3. **Clean Blade Assembly:** Carefully wash the blade assembly immediately after use. You can rinse it under running water, being extremely cautious of the sharp blades. A small brush may be used to remove any residue. The blade assembly is also dishwasher safe.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
5. **Storage:** Store the blender and its components in a clean, dry place.

7. Troubleshooting

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; Bottle not correctly assembled on base.	Ensure the power cord is securely plugged into an outlet. Check that the bottle is twisted and locked onto the motor base.
Ingredients are not blending smoothly.	Too little liquid; Ingredients are too large; Overfilled bottle.	Add more liquid. Cut ingredients into smaller pieces. Do not exceed the MAX fill line. Blend in short pulses.
Blender leaks during operation.	Blade assembly not tightened; Bottle not correctly seated.	Ensure the blade assembly is screwed tightly onto the bottle. Verify the bottle is securely locked onto the motor base.
Motor smells or overheats.	Overloading; Continuous operation for too long.	Reduce the amount of ingredients. Blend in short pulses (max 1 minute continuous, then rest for 2 minutes). Unplug and let cool down.

8. Specifications

- **Model:** SMOO16
- **Power:** 300 Watts
- **Capacity:** 570 Milliliters (per bottle)

- **Blades:** 4 Stainless Steel Blades
- **Material:** Stainless Steel (base), BPA-free Plastic (bottles), Silicone (lids/contours)
- **Special Features:** Portable, Multiple Attachments (bottles), Dishwasher Safe (bottles and blade assembly)
- **Power Source:** Corded Electric

9. Warranty and Support

The H.Koenig SMOO16 Mini Blender comes with an extended **2-year warranty**.
For any technical assistance, warranty claims, or spare parts, please contact H.Koenig customer support. An authorized after-sales service (SAV) workshop is available in France to provide reliable support.
Please retain your proof of purchase for warranty purposes.