



Manuals.plus /

- › Sameo /
- › Sameo ULTRAZONE Wireless 8-Bit Game Console User Manual

## Sameo SE/7349

# Sameo ULTRAZONE Wireless 8-Bit Game Console User Manual

Model: SE/7349

## 1. INTRODUCTION

---

Thank you for choosing the Sameo ULTRAZONE Wireless 8-Bit Game Console. This console offers a classic gaming experience with 362 built-in games and supports 8-bit cartridges. Enjoy wireless gameplay with the included cordless joysticks. This manual provides essential information for setup, operation, and troubleshooting to ensure you get the most out of your gaming experience.



Image 1.1: Sameo ULTRAZONE Wireless 8-Bit Game Console with two wireless joysticks.

## 2. WHAT'S IN THE BOX

---

Please check the package contents to ensure all items are present:

- 1 x Sameo ULTRAZONE Game Console
- 2 x Wireless Joysticks
- 1 x Power Adapter (5.0V DC ~ 500mA)
- 1 x AV Cable (1.5 meter length)
- 1 x Warranty Card
- 1 x User Manual (this document)
- *Note: 2 x AAA batteries are required for each controller (total 4 AAA batteries), not included.*



Image 2.1: Retail packaging of the Sameo ULTRAZONE Game Console.



Image 2.2: Back of the retail packaging, listing contents and features.

### 3. SETUP INSTRUCTIONS

Follow these steps to set up your Sameo ULTRAZONE Game Console:

1. **Connect Power Adapter:** Insert the power adapter into a wall outlet and the other end into the designated power slot on the UltraZone machine.
2. **Connect AV Cable:** Insert the AV cable's yellow plug into the yellow video input port on your TV and the white plug into the white audio input port. Connect the 3.5mm jack end of the AV cable into the UltraZone machine's AV output port.
3. **TV Compatibility Note:** If your TV does not have AV input slots, an AV to HDMI converter (sold separately) may be required.
4. **Insert Batteries into Controllers:** Open the battery compartment on each wireless joystick and insert 2 AAA batteries (not included), ensuring correct polarity.
5. **Power On Console:** After completing the connections, press the power button located on the left side of the UltraZone machine to turn it on.



### Installation Guideline For UltraZone

- **Insert the Power Adapter in the plug point and the other end into the designated slot provided on the UltraZone machine.**
- **Insert the AV cable in the TV (yellow point to yellow port and same for white) and the other end which is the 3.5mm Jack in the UltraZone machine.**
- **If in case your TV doesn't have the AV slot you can buy the AV to HDMI converter. (sold separately)**
- **Insert 2 - AAA batteries in each Controller and press the round button in the center to star Playing Wirelessly.**
- **To turn on the machine after completing the above steps simply press the power button which is on the left side of the UltraZone machine.**
- **To quit the game or to reset simply press the center button on the controller or the reset button on the UltraZone machine.**



Image 3.1: Visual guide for console installation.

## 4. OPERATING INSTRUCTIONS

Once the console is set up and powered on, follow these steps to start playing:

1. **Start Wireless Play:** Press the round button in the center of your wireless joystick to activate it and begin playing.
2. **Game Selection:** The console comes with 362 built-in games. Navigate through the game menu using the joystick's directional pad and action buttons.
3. **Using Cartridges:** The console supports 8-bit game cartridges. Insert a compatible cartridge into the designated slot on the console before powering on, or reset the console after insertion if already on.
4. **Quit or Reset Game:** To exit a game or reset the console, press the center button on the controller or the 'RESET' button on the UltraZone machine.



Image 4.1: Sameo ULTRAZONE console in use, displaying gameplay on a television.

*A video demonstrating gameplay would be embedded here if available.*

## 5. TROUBLESHOOTING

If you encounter any issues, please refer to the following troubleshooting tips:

- **No Power:**
  - Ensure the power adapter is securely connected to both the console and a working power outlet.
  - Verify the power button on the console is pressed.
- **No Signal on TV / Black Screen:**
  - Check that the AV cable is firmly connected to both the console and the correct input ports (yellow for video, white for audio) on your TV.
  - Ensure your TV is set to the correct AV input source (e.g., AV1, Video, Input).
  - If your TV lacks AV input, confirm you are using a compatible AV to HDMI converter (sold separately) and it is correctly installed.
- **Wireless Controller Not Responding:**
  - Check and replace the AAA batteries in the controller, ensuring correct polarity.
  - Press the center round button on the controller to ensure it is powered on and attempting to connect.
  - Ensure there are no obstructions between the controller and the console.
- **Game Freezing or Lagging:**

- Try pressing the 'RESET' button on the console or the center button on the controller to restart the game.
  - If using a cartridge, ensure it is clean and properly seated in the slot.
- **Poor Graphics Quality:**
    - The Sameo ULTRAZONE is an 8-bit game console, designed to deliver a classic retro gaming experience. The graphics are characteristic of this era and are not comparable to modern high-definition systems.

## 6. SPECIFICATIONS

<b>Platform</b>	TV Plug & Play
<b>Input Device</b>	Joystick
<b>Brand</b>	Sameo
<b>Model Number</b>	SE/7349
<b>Color</b>	BLACK
<b>Connectivity Technology</b>	Cartridge slot (AV output)
<b>Wireless Communication</b>	Wireless (for joysticks)
<b>Built-In Games</b>	362
<b>Cartridge Support</b>	8-bit cartridges
<b>Power Adapter</b>	5.0V DC ~ 500mA
<b>AV Cable Length</b>	1.5 meter
<b>Item Weight</b>	400 Grams
<b>Country of Origin</b>	China

## 7. WARRANTY AND SUPPORT

The Sameo ULTRAZONE Wireless 8-Bit Game Console comes with a **6-month manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any inquiries, please contact:

**Manufacturer:** Sameo Distribution (India) Pvt Ltd.

**Address:** Lower Parel, Mumbai-400011, India

Please retain your purchase receipt as proof of purchase for warranty purposes.