

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HANDY](#) /

› [HANDY Automatic Male Masturbator User Manual - Model Handy](#)

HANDY Handy

HANDY Automatic Male Masturbator

Model: Handy

Brand: HANDY

INTRODUCTION

This manual provides essential information for the safe and effective use of your HANDY Automatic Male Masturbator. Please read these instructions thoroughly before operating the device and retain them for future reference.



Image: The HANDY Automatic Male Masturbator, showcasing its sleek black design and the attached clear sleeve, highlighting its immersive pleasure capabilities.

SAFETY INFORMATION

- Keep away from children.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

- The device is **not water resistant**. Do not submerge in water or expose to excessive moisture.
- Use only **water-based lubricants** with the sleeves to prevent material degradation.

WHAT'S INCLUDED

Your HANDY package includes the following components:

- The Handy Unit
- TrueGrip™ Original Sleeve
- TrueGrip™ Velcro Band
- Power Supply (Region-Matched Adapter)
- User Manual



Image: An illustration showing all items included in the Handy box: the main unit, a TrueGrip sleeve, a TrueGrip band, and the power supply.

SETUP

1. Power Connection

1. Connect the power supply to the power cable.
2. Plug the power supply into a wall socket.
3. Plug the power cable into the HANDY device. The device will power on automatically.

2. Sleeve Attachment

1. Ensure the TrueGrip™ Velcro band is securely attached to the device.
2. Place your chosen sleeve into the TrueGrip™ band.
3. Adjust the tension of the Velcro band to securely hold the sleeve in place. The buttons on the device should face you for easy access and control.

3. Initial Boot-Up

Upon powering on, the HANDY device will enter offline mode by default, indicated by a green pulsing LED light. During this boot-up sequence, the internal slider will adjust to its lowest possible position to calibrate. Your device is now ready for use.

Your browser does not support the video tag.

Video: 'Getting Started with Handy' - This video demonstrates the initial setup process, including connecting the power, attaching the sleeve, and the device's boot-up sequence.

OPERATING INSTRUCTIONS

Offline Mode Controls

The HANDY device features intuitive controls for adjusting stroke length and speed:

- **Power Button:** The round button at the top of the device starts and stops the motor. By default, it begins with the slowest stroke.
- **Speed Adjustment:** Use the horizontal arrow buttons to control the stroke speed. The right arrow increases speed, and the left arrow decreases it.
- **Stroke Length Adjustment:** Use the vertical arrow buttons to control the stroke length. Press and hold the up arrow to move the bottom point of the stroke higher, increasing the stroke length. Press and hold the down arrow to move the bottom point lower, shortening the stroke length. Each blink of the LED indicator signifies a change in the stroke point. A red blink indicates the limit of adjustment has been reached.

DREAM COLLECTION

LIPS:

- Texture and shape feel just like the mouth
- Bumpy internal patterns
- Close-ended



LOTUS:

- Textured entrance for extra stimulation
- Curves, wavy patterns, and strategically placed bubbles in the innermost section
- Close-ended



TOUCH:

- Ribbed texture and petals to please you
- Bumpy internal patterns
- Open-ended



CHRYSM:

- Suction effect reduces intense sensitivity
- Alternating loose and tight areas
- Close-ended



Image: A visual representation of the HANDY's control panel, illustrating the buttons for manual speed and stroke length adjustments.

Smart Connectivity

The HANDY offers advanced connectivity options for an enhanced experience:

- **Dual Connect:** Features Wi-Fi and Bluetooth 4.2 built-in for versatile connection.
- **VR Compatible:** Experience real-time synchronization with digital content for immersive experiences.

- **Video Sync Engine:** Matches device action with on-screen content instantly.
- **Remote Control:** Control the device yourself or allow a partner to control it remotely via the Handyfeeling app.
- **Open API:** Fully customizable for developers, allowing for advanced integration.
- **Privacy First:** Anonymous usage with no account needed and no data storage.

Your browser does not support the video tag.

Video: 'Handy in Motion' - This video demonstrates the device's movement and speed capabilities, showcasing its dynamic operation.

MAINTENANCE

Sleeve Cleaning

To ensure hygiene and longevity of your TrueGrip™ sleeve:

1. Remove the sleeve from the device.
2. Wash the sleeve with mild soap and warm water. Avoid excessively hot water, as this can damage the TPE material.
3. Pat the sleeve dry with a towel.
4. Turn the sleeve inside out to air dry thoroughly before storing.
5. **Important:** Only use water-based lubricants with the sleeves. Other types of lubricants can degrade the sleeve material.

TrueGrip™ Band Cleaning

The TrueGrip™ band can be washed with mild soap or detergent and warm water. Allow it to air dry completely.

Device Cleaning

The HANDY device itself is **not waterproof** and should not be submerged in water. To clean the device:

- Use a damp cloth to wipe the exterior surfaces.
- Ensure the device is completely dry before storing.

Storage

Store your sleeve and device in a cool, dry place, away from direct sunlight. Ideally, keep them in their original packaging. Do not store sleeves touching other toys, as this may discolor and degrade the sleeve material.

Your browser does not support the video tag.

Video: 'How to Clean The Handy the Right Way' - This video provides a step-by-step guide on cleaning the device and its components to maintain hygiene and product integrity.

TROUBLESHOOTING

If you encounter any issues with your HANDY device, please consider the following:

- **Device Not Powering On:** Ensure the power supply is correctly connected to both the wall outlet and the device. Check for any visible damage to the power cable.
- **Motor Not Moving:** Verify that the device is powered on (green LED pulsing). If in offline mode, ensure the power button has been pressed to start the motor.
- **Connectivity Issues:** For Wi-Fi or Bluetooth connectivity, ensure your device is within range and that the Handyfeeling app (if used) is up to date. Refer to the app's instructions for specific connection steps.
- **Sleeve Slippage:** Ensure the TrueGrip™ Velcro band is tightened sufficiently to hold the sleeve securely. If using lubricant, confirm it is water-based and applied appropriately to avoid excessive slipperiness.
- **Unusual Noises:** If the device makes unusual noises, power it off immediately and inspect for any obstructions or damage. Contact customer support if the issue persists.

SPECIFICATIONS

Feature	Detail
Speed Range	10 - 600 Strokes per minute
Variable Stroke Length	0 - 110mm (0 - 4.33 in)
Power Source	Mains Powered (AC adapter) for consistent performance
Max Noise Level	60 dB
Dimensions (Length)	23cm (9.06 in)
Weight	700g (1.54 lbs)
Material	POM & ABS
Water Resistance Level	Not Water Resistant




Image: A detailed graphic outlining the technical specifications of the HANDY device.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your HANDY device, please refer to the official HANDY website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

© 2024 HANDY. All rights reserved.