

Riedel 6330/28

Riedel Veloce Champagne Wine Glass Instruction Manual

Model: 6330/28

INTRODUCTION

This instruction manual provides essential information for the proper use, care, and maintenance of your Riedel Veloce Champagne Wine Glasses. Designed with a specific shape to enhance the aroma and taste of champagne, these glasses are crafted using advanced machine production techniques. Please read this manual thoroughly before first use and retain it for future reference.

SETUP AND INITIAL USE

Unpacking

Carefully remove the glasses from their packaging. Inspect each glass for any signs of damage. If any damage is observed, do not use the product and contact customer support.



This image displays two Riedel Veloce Champagne glasses. The glass on the left is filled with sparkling wine, highlighting the effervescence and the unique diamond-shaped bowl designed to enhance the wine's aroma. The glass on the right is empty, showing its clear, elegant form.

Initial Cleaning

Before first use, wash the glasses to remove any manufacturing residues or dust. Refer to the 'Maintenance and Cleaning' section for detailed cleaning instructions.

OPERATING (USAGE)

Proper Handling

To ensure the longevity of your Riedel Veloce Champagne glasses and to fully appreciate your beverage, proper handling is recommended:

- **Holding the Glass:** Always hold the glass by its stem or base to avoid warming the champagne with your hand and to prevent fingerprints on the bowl.
- **Pouring:** Pour champagne slowly and at an angle to preserve effervescence and prevent excessive foaming. Fill the glass to approximately one-third or half of its capacity to allow for aroma concentration.
- **Swirling:** Gently swirl the glass to release the champagne's aromas. The diamond shape of the Veloce bowl is specifically designed to enhance this experience.





A single Riedel Veloce Champagne glass, filled with sparkling wine, demonstrating its capacity and the visual appeal of the beverage within its specialized shape.



A detailed view of the base of a Riedel Veloce Champagne glass, featuring the subtle Riedel logo etched into the foot. This illustrates the thin, stable base and the delicate stem.

MAINTENANCE AND CLEANING

Dishwasher Cleaning

Riedel Veloce Champagne glasses are dishwasher safe. To prevent damage, follow these guidelines:

- Place glasses securely in the top rack, ensuring they do not touch other items.
- Use a gentle cycle and a mild detergent.
- Avoid harsh detergents or abrasive cleaning agents.
- If possible, use a steam or air-dry setting to minimize water spots.

Hand Washing

For optimal care and to maintain the brilliance of the glass, hand washing is recommended:

1. Wash the glass under warm water with a small amount of mild dish soap.
2. Use a soft sponge or cloth to gently clean the bowl, stem, and base.
3. Rinse thoroughly with clean, warm water.
4. Polish immediately with a lint-free microfiber cloth to prevent water spots and enhance shine. Hold the glass by the bowl when polishing the base, and by the base when polishing the bowl, to avoid twisting the stem.

Storage

Store glasses upright in a cabinet or on a shelf where they are protected from accidental knocks or falls. Avoid storing glasses upside down on their rims, as this can lead to chipping.

TROUBLESHOOTING

Common Issues and Solutions

- **Water Spots:** If water spots appear after washing, re-wash the glass using distilled water or polish with a microfiber cloth and a small amount of white vinegar.
- **Cloudiness/Film:** A cloudy film can result from hard water or improper detergent. Try soaking the glass in white vinegar for 15-30 minutes, then rinse and dry. For persistent issues, consider using a specialized glass cleaner.
- **Breakage:** Due to their fine design, these glasses are delicate. Handle with care, especially when washing and storing. Avoid sudden temperature changes.

SPECIFICATIONS

The Riedel Veloce Champagne Wine Glass (Model 6330/28) features the following specifications:

Feature	Detail
Brand	Riedel
Model Number	6330/28
Material	Crystal Glass
Color	Clear
Dimensions (W x H)	5.05" x 11.14" (approximate packaging dimensions)
Glass Size (L x W x H)	3.15" x 3.15" x 9.72"
Item Weight	6.72 ounces
Unit Count	2.0 Count
Care Instructions	Dishwasher Safe



247mm, 9.72"

79mm, 3.11"





This diagram provides precise measurements of the Riedel Veloce Champagne glass, including its height (9.72 inches / 247mm), bowl width (3.11 inches / 79mm), and base diameter (3.39 inches / 86mm).

ABOUT RIEDEL GLASSWARE

Riedel is renowned for its dedication to crafting varietal-specific glassware that enhances the wine-drinking experience. The company's history spans over 260 years, with a continuous focus on innovation and quality in glass production.

Manufacturing Process

This video provides a tour of the Riedel factory in Kufstein, Austria, demonstrating the intricate process of glassmaking, from molten glass to finished product. It highlights the craftsmanship and technology involved in creating Riedel glassware.

Riedel's Legacy

This video explores the rich 260-year history of Riedel, featuring interviews with prominent chefs and members of the Riedel family. It delves into the philosophy behind varietal-specific glassware and the evolution of wine glass design.






WARRANTY INFORMATION

Riedel products are manufactured to high-quality standards. For specific warranty details regarding your Riedel Veloce Champagne Wine Glasses, please refer to the warranty card included with your purchase or visit the official Riedel website. The warranty typically covers manufacturing defects.

CUSTOMER SUPPORT

Should you have any questions, require assistance, or need to report an issue with your Riedel Veloce Champagne Wine Glasses, please contact Riedel customer support through their official website or the contact information provided in your product packaging. When contacting support, please have your model number (6330/28) and purchase details ready.

© 2025 Riedel. All rights reserved.

	<p>Riedel STX-200 User Manual: Setup and Operation Guide</p> <p>Comprehensive user manual for the Riedel STX-200, detailing setup, configuration, and operation of this Skype TX-based broadcast system for high-quality video and audio calls.</p>
<p>Preview</p>	<p>Riedel Juggler User Manual: TETRA Digital Radio Integration</p> <p>User manual for the Riedel Juggler system, detailing its capabilities for integrating TETRA digital trunked radio networks with Riedel Artist Digital Matrix Intercoms. Essential guide for setup, operation, and technical specifications.</p>
	<p>Riedel Bolero Beltpack Quick Start Guide</p> <p>A quick start guide for the Riedel Bolero Wireless Intercom Beltpack, covering setup, operation, technical specifications, and service information.</p>
	<p>Riedel Artist-1024 User Manual V8.5</p> <p>This user manual provides detailed information on the Riedel Artist-1024 system, including connector pin assignments, mechanical/electrical data, and configuration. It covers features, components, licensing, and service information for the Artist-1024.</p>
	<p>Riedel Bolero 3.1 User Manual: Configuring Beltpack Keys and Functions</p> <p>A comprehensive guide to the Riedel Bolero 3.1 User Manual, detailing the configuration of beltpack keys, rotaries, quick menus, and various 'always-on' functions. Learn how to customize your wireless intercom system for optimal performance.</p>
	<p>punQtum Wireless App User Manual - Riedel Q-Series Intercom System</p> <p>Comprehensive user manual for the Riedel punQtum Wireless App, detailing setup, usage, features, and settings for the Q-Series Network Based Intercom System. Learn how to connect, manage channels, and utilize advanced functions for professional communication.</p>