

[Manuals.plus](#) /

> [Hot Wheels](#) /

> Hot Wheels Action Extreme Spins Track Set Instruction Manual

Hot Wheels GJM77

Hot Wheels Action Extreme Spins Track Set

Instruction Manual - Model GJM77

1. PRODUCT OVERVIEW

The Hot Wheels Action Extreme Spins Track Set, model GJM77, is designed to provide thrilling racing experiences for children aged 5 and up. This dynamic track features a 1.8-meter layout with pronounced loops and a fast-turning ramp, engineered for high-performance vehicle action. It encourages creativity and problem-solving through engaging play.

This set is part of the Hot Wheels Action series, focusing on dynamic stunts and high-speed challenges. It is compatible with other Hot Wheels track sets, allowing for expanded play possibilities.



Figure 1.1: The complete Hot Wheels Action Extreme Spins Track Set layout, featuring a large spinning wheel and launch ramps.

2. SAFETY INFORMATION

WARNING: Contains or may generate small parts that can cause choking. Not suitable for children under 3 years.

Always supervise children during play. Ensure all track connections are secure before launching vehicles. Do not modify the track set or use non-Hot Wheels vehicles, as this may affect performance and safety.

3. SETUP AND ASSEMBLY

While the Hot Wheels Action Extreme Spins Track Set is designed for easy setup, some assembly is required to connect the track pieces and the central spinning mechanism. Follow these general steps:

1. **Unpack Components:** Carefully remove all track pieces, connectors, and the central spinning wheel assembly from the packaging.
2. **Connect Base Sections:** Identify the main base pieces and connect them as indicated in the visual guides. Ensure a firm click for secure connections.
3. **Assemble Spinning Wheel:** Attach the large spinning wheel to its central support structure. Make sure it rotates freely.
4. **Attach Track Segments:** Connect the orange track segments to the launch ramps and the spinning wheel entry/exit points. Verify all connections are tight to prevent cars from derailing.
5. **Position Launchers:** Ensure the car launchers are correctly positioned and functional.



PLAYSET INCLUDES ONE VEHICLE. OTHER CARS SOLD SEPARATELY. SUBJECT TO AVAILABILITY.

Figure 3.1: Children engaging with the track set, demonstrating the assembly and play process.



Figure 3.2: The track set can be configured for play or stored compactly when not in use.

4. OPERATING INSTRUCTIONS

To operate your Hot Wheels Action Extreme Spins Track Set, follow these steps for maximum fun and performance:

1. **Select a Vehicle:** Choose a standard Hot Wheels die-cast vehicle. Lighter cars often perform better on loops and ramps.
2. **Place Vehicle:** Position the vehicle at the starting point of the launcher.

3. **Launch Vehicle:** Activate the launcher mechanism to propel the car onto the track.
4. **Engage Spinning Wheel:** As the car approaches the large spinning wheel, it will enter the loop. For optimal performance, you may need to manually assist the wheel's rotation or ensure sufficient launch speed.
5. **Observe the Action:** Watch as your car navigates the loops and ramps, performing extreme spins and stunts.



Figure 4.1: A Hot Wheels car successfully navigating the central spinning wheel loop.



Figure 4.2: Manual interaction with the spinning wheel can enhance the play experience.

5. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your Hot Wheels Action Extreme Spins Track Set:

- **Cleaning:** Wipe down track pieces and components with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, disassemble the track set and store it in its original packaging or a designated storage container to prevent damage and loss of small parts. Keep it away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all track connectors and moving parts for wear and tear. Replace any damaged components if necessary.

6. TROUBLESHOOTING

If you encounter issues with your Hot Wheels Action Extreme Spins Track Set, consider the following

troubleshooting tips:

Problem	Possible Cause	Solution
Car does not complete loop/stunt.	Insufficient launch speed; track not properly connected; car too heavy/light or damaged.	Ensure strong launch; check all track connections; try a different Hot Wheels car.
Track pieces do not connect securely.	Misalignment; debris in connector; damaged connector.	Align pieces carefully; clear any debris; if damaged, contact customer support.
Spinning wheel is stiff or not rotating.	Obstruction; assembly error.	Check for any foreign objects; re-check assembly of the spinning wheel mechanism.

7. SPECIFICATIONS

- **Model Number:** GJM77
- **Brand:** Hot Wheels
- **Educational Objectives:** Motor skills
- **Manufacturer Recommended Age:** 5-8 years
- **Material Type:** Plastic
- **Batteries Required:** No
- **Product Dimensions:** 61 x 100 x 33 cm (24 x 39.4 x 13 inches)
- **Product Weight:** 300 g (0.66 lbs)
- **First Available Date:** October 1, 2019

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Hot Wheels Action Extreme Spins Track Set, please refer to the contact information provided on the product packaging or visit the official Hot Wheels website. Keep your proof of purchase for any warranty claims.

Online Resources: For additional tips, tricks, and product information, visit the official Hot Wheels website or search for Hot Wheels Action videos online.

Customer Service: If you require further assistance, please contact Hot Wheels customer service through the details provided with your product.

