JVC HA-Z330T

JVC HA-Z330T Compact Wireless Earbuds User Manual

Model: HA-Z330T

1. Introduction

Thank you for choosing the JVC HA-Z330T Compact Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features in a lightweight and stylish form factor. This manual provides essential information for the proper use and maintenance of your device.

Key features include:

- **Compact and Lightweight Design:** Each earbud weighs only 4.2g, and the charging case is 28g, ensuring comfort during extended use and easy portability.
- **Active Noise Cancellation (ANC):** Reduces ambient noise for an immersive listening experience.
- **Special Earpiece Design:** Physically reduces noise for enhanced noise cancellation.
- **Clear Call Quality:** Metallic accent minimizes wind noise, combined with a high-power microphone for clear voice communication.
- **Low Latency Mode:** Minimizes audio-visual delay, ideal for gaming and video content.
- **Bluetooth 5.2:** Ensures stable and reliable wireless connectivity.
- **Telework Features:** Includes microphone mute function and single-side use capability for convenience during calls and online meetings.
- **IPX4 Water Resistance:** Protects against splashes and sweat.

2. Package Contents

Ensure all items are present in the package:

- JVC HA-Z330T Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Eartips (various sizes)
- Instruction Manual



JVC



COMPACT
TRUE WIRELESS
NOISE CANCELLING

WIRELESS HEADPHONES / ÉCOUTEURS SANS FIL
AURICULARES INALÁMBRICOS / KABELLOSER KOPFHÖRER

HA-Z330T

Eco-Friendly
Less-Plastic
Package

BT 21h
NC 17h



Image: The retail packaging for the JVC HA-Z330T earbuds, showing the earbuds and charging case.

3. Setup

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, USB wall adapter).
3. The indicator light on the case will show charging status. Once fully charged, the indicator will change or turn off.



Image: The JVC HA-Z330T charging case, closed, with the JVC logo visible.

3.2. Pairing with a Bluetooth Device

The earbuds will automatically enter pairing mode when first removed from the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices and select "JVC HA-Z330T" from the list.
4. Once connected, a voice prompt will confirm successful pairing.

Note: If pairing fails, place the earbuds back into the case, close it, and then repeat the steps.

4. Operating Instructions

4.1. Basic Controls (Touch Sensor)

The earbuds feature touch sensors for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Voice Assistant:** Triple tap on either earbud.



Image: A close-up of a JVC HA-Z330T earbud, highlighting the touch sensor area with a fingerprint icon.

4.2. Active Noise Cancellation (ANC)

The HA-Z330T features Active Noise Cancellation to reduce ambient sounds.

- **Toggle ANC:** Press and hold the **right** earbud for 2 seconds to cycle through ANC On, Ambient Sound Mode, and ANC Off.




Image: A JVC HA-Z330T earbud with sound waves emanating from it, illustrating the active noise cancelling feature.

4.3. Low Latency Mode

Activate Low Latency Mode for reduced audio delay, beneficial for gaming and video playback.

- **Activate/Deactivate Low Latency Mode:** Press and hold the **left** earbud for 2 seconds.



Image: A person using the JVC HA-Z330T earbuds while playing a game on a tablet, demonstrating the low latency mode.

4.4. Telework Features

The earbuds offer features to enhance your telework experience:

- **Microphone Mute:** During a call, triple tap on either earbud to mute/unmute the microphone.
- **Single Side Use:** Either earbud can be used independently for calls or audio playback. Simply remove one earbud from the case and leave the other in.



Image: A person using a JVC HA-Z330T earbud during a telework scenario, with icons for single-side use and microphone mute.

5. Maintenance

5.1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using abrasive cleaners, alcohol, or chemical solvents.

5.2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

5.3. Water Resistance (IPX4)

The earbuds are rated IPX4, meaning they are resistant to splashing water from any direction. They are not designed for submersion in water.

- Do not intentionally submerge the earbuds in water.
- If they get wet, wipe them dry immediately with a soft cloth.
- Ensure the charging port is dry before charging.



Image: Two JVC HA-Z330T earbuds resting on a reflective surface with water droplets, illustrating their IPX4 water resistance.

6. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Earbuds do not power on.	Battery is depleted. Place earbuds in the charging case and charge fully.
Cannot pair with device.	• Ensure Bluetooth is enabled on your device. • Make sure earbuds are in pairing mode (indicator light flashing). • Forget "JVC HA-Z330T" from your device's Bluetooth list and try pairing again. • Ensure earbuds are within Bluetooth range (approx. 10 meters).
No sound or intermittent sound.	• Check volume levels on both earbuds and your connected device. • Ensure earbuds are fully charged. • Move closer to your device to avoid interference. • Reconnect the earbuds to your device.

Problem	Possible Cause / Solution
Active Noise Cancellation is not effective.	• Ensure ANC is activated (refer to section 4.2). • Check that the eartips provide a good seal in your ear canal. Try different sizes.
Microphone not working during calls.	• Ensure the microphone is not muted (refer to section 4.4). • Check microphone settings on your connected device.

7. Specifications

Feature	Detail
Model Name	HA-Z330T
Brand	JVC
Connectivity Technology	Wireless (Bluetooth 5.2)
Ear Placement	In-Ear
Noise Control	Active Noise Cancellation
Frequency Response	20 Hz - 20,000 Hz
Impedance	16 ohms
Earbud Weight	4.2 Grams (each)
Charging Case Weight	28 Grams
Water Resistance Rating	IPX4 (Splash-proof)
Battery Type	Lithium Polymer
Rechargeable Battery	Yes
Special Features	Microphone included, Sweat resistant
Compatible Devices	Bluetooth-enabled devices (smartphones, tablets, computers)

8. Warranty and Support

JVC products are designed for reliability and performance. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official JVC website.

Online Support: For the latest information, FAQs, and support resources, please visit the official JVC support page: www.jvc.com/support/

Contact Information: Refer to your regional JVC website for specific contact details for customer service.

© 2023 JVC. All rights reserved. Specifications are subject to change without notice.