

XP-Pen Deco MW

XPPen Deco MW Bluetooth Wireless Graphics Tablet User Manual

Model: Deco MW

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your XPPen Deco MW Bluetooth Wireless Graphics Tablet. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Image: Top-down view of the XPPen Deco MW Bluetooth Wireless Graphics Tablet, showcasing its sleek black design and the prominent Bluetooth logo.

2. WHAT'S IN THE BOX

Verify that all items are present in your product packaging:

- 1x XP-PEN Deco MW Graphics Drawing Tablet
- 1x Dongle
- 1x USB A to USB-C Cable
- 1x X3 Elite Stylus
- 1x USB A to USB-C OTG Adapter
- 1x USB A to Micro USB OTG Adapter
- 10x Pen Nibs
- 1x User Manual



Image: A visual representation of the items included in the XPPen Deco MW package, including the tablet, stylus, cables, adapters, and replacement nibs.

3. SETUP

3.1 Driver Installation

Before using your Deco MW tablet, it is essential to install the latest drivers from the official XP-Pen website. Visit www.xp-pen.com, navigate to the 'Support' section, and then select the 'Download' tab. Choose 'Deco Series Pen Tablet' and locate your specific model (Deco MW) to download the appropriate driver for your operating system.

Windows Driver Installation:

Video: This tutorial demonstrates the step-by-step process for installing the Deco Series Pen Tablet driver on a Windows operating system, including downloading from the official website and following installation prompts.

Mac Driver Installation:

Video: This tutorial provides instructions for installing the Deco Series Pen Tablet driver on a Mac operating system, detailing the download process and necessary security and privacy settings adjustments.

3.2 Connection Methods

The Deco MW tablet offers multiple connection options for flexibility:

- **Cable Connection:** Connect the tablet directly to your computer using the provided USB A to USB-C cable.
- **Bluetooth Dongle Connection:** Insert the Bluetooth dongle into an available USB port on your computer. The tablet will automatically connect.
- **Wireless Bluetooth Connection:** For direct Bluetooth pairing, long-press the top-left shortcut key on the tablet for 3 seconds to enter pairing mode. Then, enable Bluetooth on your computer or mobile device and select 'Deco MW' from the list of available devices.

Support 3 connection methods

1 Bluetooth 5.0 Connection



2 Bluetooth adapter connection



3 USB cable connection



Image: An illustration showing the three available connection methods: direct USB cable, Bluetooth dongle, and wireless Bluetooth pairing, connecting the tablet to a laptop.

Video: This video provides a connection tutorial for the Deco Series, demonstrating how to establish a connection between the tablet and a computer using various methods.

3.3 System and Software Compatibility

The Deco MW tablet offers broad compatibility with various operating systems and creative software:

- **Operating Systems:** Windows 7/8/10/11, Mac OS X 10.10 (or later), Android 6.0 (or later), Chrome OS 88 (or later), and Linux systems.
- **Compatible Software:** Works with most major art software, including Photoshop, Illustrator, SAI, GIMP, Krita, MediBang Paint, FireAlpaca, Blender, and more.



Image: An illustration depicting the XPPen Deco MW's compatibility with multiple operating systems (Windows, Mac OS, Linux, Chrome OS, Android) and creative software applications.

Compatible with mobile devices



Image: This image illustrates the tablet's compatibility with mobile devices, showing connections via OTG adapters and listing compatible mobile applications like FlipaClip, MediBang Paint Pro, and ibisPaint.

Compatible with ibisPaint (iOS version)



Corresponding OS

Since iOS 12.0 and iPad OS 13.1 or later

Compatible software

ibispaint (iOS/ iPad OS) ver . 9.1.0

Image: A visual showing the XPPen Deco MW connected wirelessly to an iPhone, highlighting its compatibility with ibisPaint (iOS version 9.1.0 or later) on iOS 12.0 and iPad OS 13.1 or later.

4. OPERATING YOUR GRAPHICS TABLET

4.1 X3 Smart Chip Stylus

The Deco MW is equipped with the X3-Smart-Chip Stylus, designed for an enhanced drawing experience. Key features include:

- **Faster Response:** Improved speed in pen input.
- **Stable Performance:** Consistent and reliable operation.
- **Precise Positioning:** Accurate tracking for detailed work.
- **8192 Levels of Pressure Sensitivity:** Allows for fine control over line thickness and opacity.
- **60-Degree Tilt Function:** Enables natural shading and brush effects.
- **Battery-Free:** No need for charging the stylus.
- **Low Initial Activation Force (IAF):** Responds to minimal pressure for sensitive strokes.
- **Shorter Retraction Distance:** Provides a more pen-like feel.

X3 Smart Chip Stylus


Sharp.Stable.Precise.



8192 levels




60° tilt




Double the life span



Battery-free



0.6 mm*
retraction distance



3 grams* LAF



Image: A close-up view of the X3 Smart Chip Stylus, highlighting its internal components and key features such as 8192 pressure levels, 60-degree tilt, and battery-free design.

Video: This video introduces the X3 Smart Chip, explaining its technology and how it enhances the performance of the stylus for drawing tablets.

Video: A short video showcasing the X3 Stylus, emphasizing its sharp, precise, and stable performance during use.

4.2 Customizable Shortcut Keys

The Deco MW tablet features eight customizable shortcut keys. These keys can be programmed to various functions or shortcut combinations, effectively replacing a computer keyboard for common commands. Tactile bumps on the keys aid in quick identification, improving workflow efficiency.

8 Efficient shortcut keys




Image: A close-up of the XPPen Deco MW tablet, highlighting the eight shortcut keys on the side and illustrating their potential functions.

4.3 Setting Work Area and Rotation

The driver software allows you to define the active work area of the tablet and adjust its rotation to suit your preference. This ensures comfortable and efficient use, whether you are left-handed or right-handed, or prefer a specific orientation.

Slim enough for easy portability

Take it where you want, express your inspirations when they come. Slim device body with suitable size and good touch experience is easy for you to carry and travel.



Image: An illustration detailing the slim design and dimensions of the XPPen Deco MW, including its work area of 8x5 inches, emphasizing its portability.

5. MAINTENANCE

To maintain your XPPen Deco MW Graphics Tablet in optimal condition, follow these guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface and stylus. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the device.
- **Storage:** When not in use, store the tablet and stylus in a clean, dry place away from direct sunlight, extreme temperatures, and humidity. Protect the stylus nib from damage.
- **Pen Nib Replacement:** The tablet comes with 10 replacement pen nibs. If the stylus nib becomes worn, gently pull out the old nib with the provided nib remover tool and insert a new one.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent internal damage.

6. TROUBLESHOOTING

If you encounter issues with your Deco MW tablet, refer to the following common solutions:

- **No Pen Pressure/Stylus Not Responding:**
 - Ensure the driver is correctly installed and updated. Reinstall the driver if necessary (refer to Section 3.1).
 - Check if the stylus nib is properly inserted or needs replacement.
 - Verify that the tablet is securely connected via cable or Bluetooth.
 - Close any conflicting software that might interfere with the tablet driver.
- **Connection Issues (Bluetooth):**
 - Ensure Bluetooth is enabled on your device and the tablet is in pairing mode.
 - Remove previous pairings and attempt to reconnect.
 - Try connecting via USB cable or Bluetooth dongle to rule out direct Bluetooth issues.
- **Inaccurate Cursor Movement:**
 - Recalibrate the work area in the tablet driver settings.
 - Ensure there are no electromagnetic interferences near the tablet.
- **Shortcut Keys Not Working:**

- Check the shortcut key settings in the tablet driver to ensure they are correctly programmed.
- Verify that the driver is running in the background.

For further assistance, visit the official XP-Pen website's support section or contact customer service.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.35 x 6.3 x 0.23 inches
Item Weight	1.46 pounds
Pressure Sensitivity	8192 Levels
Operating System	Windows 7/8/10/11, Mac OS X 10.10 (or later), Android 6.0 (or later), Chrome OS 88 (or later), Linux
Connectivity Technology	Bluetooth
Batteries	1 Lithium Polymer battery required (included)


8. WARRANTY AND SUPPORT

Your XPPen Deco MW Graphics Tablet comes with a **1 Year Protection Plan**. XPPen is committed to providing lifetime service for its products. For detailed terms and conditions regarding support, returns, and refunds, please refer to the official XPPen website or contact customer service.

If you have any questions about the product or require support, you can get in touch with XPPen Technology via Amazon Message or through their official website.

Related Documents - Deco MW

 	XP-PEN Deco mini7 User Manual User manual for the XP-PEN Deco mini7 digital drawing tablet, covering safety precautions, driver installation and settings for Windows and Mac, and frequently asked questions.
 	XP-PEN Deco mini4, mini7, mini7W User Manual - Setup, Settings, and Troubleshooting Comprehensive user manual for XP-PEN Deco mini4, Deco mini7, and Deco mini7W graphics tablets, covering setup, driver installation, settings, and troubleshooting. Learn how to connect, configure, and use your device effectively.

	XP-PEN Driver User Manual - Installation and Configuration Guide Comprehensive user manual for the XP-PEN driver software, detailing installation, connection, work area customization, pen settings, and advanced features for XP-PEN graphics tablets.
	XPPen Magic Drawing Pad User Manual User manual for the XPPen Magic Drawing Pad, covering home screen navigation, power operations, file transfer (wired and Bluetooth), charging, stylus usage, preventing finger false touch, and redeeming an ibis Paint X membership. Detailed steps and notes are provided for each feature.
	XP-PEN Deco 01 V2 User Manual This user manual provides comprehensive instructions and guidance for the XP-PEN Deco 01 V2 drawing tablet, covering product overview, driver installation and uninstallation for Windows and Mac, driver settings, and frequently asked questions.
	XP-PEN Graphics Tablet Driver User Manual - Setup and Features A comprehensive user manual for XP-PEN graphics tablet drivers, detailing installation, configuration of work area, pen settings, express keys, roller/touch functions, and display adjustments. Supports various XP-PEN models including Star, Deco, Innovator, and Artist series.

Documents - XP-Pen – Deco MW



[pdf] User Manual Declaration of Conformity

Tencent Introduction 23 sept 2023 — * Veuillez consulter l'utilisation de APP B Connecter la Tablette à stylet via un appareil iOS C Allumez tablette D Connexion Bluetooth Deco MW User Manual French xp pen fr Uploads images manual decoseries all XP Pen declares that the radio equipment type IT1060B IT850B is in compliance with Directive 2014 53 EU The full text of declaration conformity ||| Introduction Merci d'avoir choisi la tablette stylet de la srie XPPen Deco. Ce manuel de l'utilisat ... utiliser le stylet 2 pour contrler le curseur. 2. Connexion sans fil uniquement pour Deco LW et Deco MW A. Connexion via un rcepteur sans fil Branchez le rcepteur sans fil sur votre ordinateur et... lang:fr score:31 filesize: 1.42 M page_count: 30 document date: 2023-09-18

Introducción




Gracias por elegir la tableta gráfica XP Pen Deco Series. Este manual de usuario está especialmente diseñado para proporcionar detalles de las funciones y características del producto. Lea este manual antes de usar el producto para garantizar un uso seguro y adecuado.

Dado a los últimos cambios del producto, el contenido puede diferir del producto final y este sujeto a modificaciones sin previo aviso.

Note: Las imágenes del Manual del Usuario son sólo de referencia. El Manual de Usuario suministrado con el dispositivo puede variar según el modelo.

Instalación del Driver



1. Conecte el cable al ordenador.
2. Instale el controlador.

1

[pdf] User Manual

Tencent Introducción XP Pen * La lista que aparece aquí es sólo para fines ilustrativos 2 Encienda el Bluetooth del ordenador añadir dispositivo busque Deco L User Manual Spanish la xp pen Uploads images manual decoserries all latam |||

Introducción Gracias por elegir la tableta gráfica XP Pen Deco Series. Este manual de usuario está especialmente diseñado para proporcionar detalles de las funciones y características del producto. Lea este manual antes de usar el producto para garantizar un uso seguro y adecuado. Dado a los últimos cambios del producto, el contenido puede diferir del producto final y este sujeto a modificaciones sin previo aviso. Note: Las imágenes del Manual del Usuario son sólo de referencia. El Manual de Usuario suministrado con el dispositivo puede variar según el modelo.

lang:es score:30 filesize: 1.44 M page_count: 30 document date: 2023-09-19

Introduction	1
Product Overview	3
Included with your product	3
Connections	11
Compatibility	11
Product Settings	11
Driver Installation	11
Introduction to the Driver	11
Driver Settings	11
Wireless	11
Wireless Receiver	11
Pen Settings	11
Bluetooth	11
Bluetooth Receiver	11
Bluetooth Settings	11
Bluetooth Receiver Settings	11
FAQ	11

Introduction



Thank you for choosing XP Pen Deco Series drawing tablet! This user manual is especially designed to detail the product's functions and features. Please read this

1

[pdf] User Manual

Tencent Installation Manual Buy XP Pen Deco MW Drawing Tablet with X3 Chip Stylus Bluetooth v5.0 chip 8 Shortcut Keys 8192 Levels of Pressure Sensitivity Elite and Fully Laminated Display Black Online at Low Prices in India XP PEN Reviews Ratings A1Zw39vOD3L m media amazon images | |||

Introduction r, check that you can use the stylus to control the cursor. 2. Wireless connection for Deco LW and Deco MW only 3 A. Connect via Wireless receiver Plug the wireless receiver into your computer and...

lang:tl score:30 filesize: 1.5 M page_count: 30 document date: 2023-05-15

Introduction




Merci d'avoir choisi la tablette à stylet de la série XP Pen Deco. Ce manuel de l'utilisateur détaille les fonctions et caractéristiques du produit. Veuillez lire ce manuel avant d'utiliser le produit afin de garantir une utilisation sûre et correcte.

En raison des dernières modifications apportées au produit, le contenu peut différer du produit final et est susceptible d'être modifié sans préavis.

Remarque : Les photos du manuel de l'utilisateur ne sont données qu'à titre indicatif. Le manuel de l'utilisateur fourni avec l'appareil peut varier selon le modèle.

Présentation générale



1. Bouton d'alimentation
2. Bouton de sélection
3. Port USB-C


1

[pdf] User Manual

Tencent Introduction XP PEN Pour Deco L et M Cet appareil numérique de classe B est conforme à la norme canadienne NMB 003 Si vous avez besoin d'une aide supplémentaire veuillez User Manual French xp pen fr Uploads images manual decoserries all |||

Introduction Merci d'avoir choisi la tablette stylet de la série XP Pen Deco. Ce manuel de l'utilisateur est spécialement conçu pour fournir des détails sur les fonctions et les caractéristiques du produit. Veuillez lire ce manuel avant d'utiliser le produit afin de garantir une utilisation sûre et correcte. En raison des dernières modifications apportées au produit, le contenu peut différer du produit final et est susceptible d'être modifié sans préavis. Remarque : Les photos du manuel de l'utilisateur ne sont données qu'à titre indicatif. Le manuel de l'utilisateur fourni avec l'appareil peut varier selon le modèle.


lang:fr score:29 filesize: 1.42 M page_count: 30 document date: 2023-09-18



[Manual do Usuário do Tablet de Desenho XP-Pen Deco](#)

Este manual do usuário fornece informações detalhadas sobre as funções, configuração, conexão, instalação de driver e solução de problemas para o tablet de desenho XP-Pen Deco.

lang:pt score:29 filesize: 1.41 M page_count: 30 document date: 2023-09-26



[\[pdf\] User Manual](#)

Tencent Installation Manual Buy XPPen Deco M Drawing Tablet with X3 chip Stylus 8 Shortcut Keys 8192 Levels of Pressure Sensitivity Elite and Fully Laminated Display Black Online at Low Prices in India XP PEN Reviews Ratings A1WoWSL7XSL m media amazon images I |||

Introduction r, check that you can use the stylus to control the cursor. 2. Wireless connection for Deco LW and Deco MW only 3 A. Connect via Wireless receiver Plug the wireless receiver into your computer and...

lang:tl score:25 filesize: 1.5 M page_count: 30 document date: 2023-05-15

Introduction 1

Product Overview 2

Included with your product 3

Connectivity 3

Compatibility 11

Product Settings 11

Driver Installation 11

Introduction to Driver 11

Driver Settings 11

Wireless 11

Driver 11

Drawing Tablet 11

Pen Settings 11

Application 11

Pen Settings 11

Bluetooth Key 11

Driver Settings 11

Driver Utility/Driver 11

FAQ 11

Introduction



Thank you for choosing XP-Pen Deco Series drawing tablet! This user manual is specially designed to detail the product's functions and features. Please read this

[pdf] User Manual

Tencent Installation Manual Buy XP Pen Deco LW 10x6 inch Graphic Tablet with Bluetooth Connectivity Battery Free X3 Chip Stylus and 8 Shortcut Keys Compatible Chrome Windows Linux Mac Android Pink PEN Reviews Ratings A1a r 1rlL m media amazon images l |||

Introduction r, check that you can use the stylus to control the cursor. 2. Wireless connection for Deco LW and Deco MW only 3 A. Connect via Wireless receiver Plug the wireless receiver into your computer and...

lang:tl score:25 filesize: 1.5 M page_count: 30 document date: 2023-05-15

Introduction 1

Product Overview 2

Included with your product 3

Connectivity 3

Compatibility 11

Product Settings 11

Driver Installation 11

Introduction to Driver 11

Driver Settings 11

Wireless 11

Driver 11

Drawing Tablet 11

Pen Settings 11

Application 11

Pen Settings 11

Bluetooth Key 11

Driver Settings 11

Driver Utility/Driver 11

FAQ 11

Introduction



Thank you for choosing XP-Pen Deco Series drawing tablet! This user manual is specially designed to detail the product's functions and features. Please read this

[pdf] User Manual

Tencent Installation Manual Buy XP Pen Deco L 10x6 inch Graphic Tablet with Battery Free X3 Chip Stylus and 8 Shortcut Keys Compatible Chrome Windows Linux Mac Android Black Online at Low Prices in India PEN Reviews Ratings A1vPuxXwalL m media amazon images l |||

Introduction r, check that you can use the stylus to control the cursor. 2. Wireless connection for Deco LW and Deco MW only 3 A. Connect via Wireless receiver Plug the wireless receiver into your computer and...

lang:tl score:25 filesize: 1.5 M page_count: 30 document date: 2023-05-15

Introduction 1

Product Overview 2

Included with your product 3

Connectivity 3

Compatibility 11

Product Settings 11

Driver Installation 11

Introduction to Driver 11

Driver Settings 11

Wireless 11

Driver 11

Drawing Tablet 11

Pen Settings 11

Application 11

Pen Settings 11

Bluetooth Key 11

Driver Settings 11

Driver Utility/Driver 11

FAQ 11

Introduction



Merci d'avoir choisi la tablette à stylet de la série XP-Pen Deco. Ce manuel de l'utilisateur détaille les fonctionnalités et caractéristiques du produit. Veuillez lire ce manuel avant d'utiliser le produit afin de garantir une utilisation sûre et correcte. En raison des différences matérielles apparentes au produit, le contenu peut différer du produit final et est susceptible d'être modifié sans préavis.

Remarque : Les photos du manuel de l'utilisateur ne sont données qu'à titre indicatif. Le manuel de l'utilisateur fourni avec l'appareil peut varier selon le modèle.

Présentation générale



- 1. Titre pour le produit
- 2. Titre de la tablette
- 3. Part USB-C

[pdf] User Manual

Tencent deco m XPPenDeco M User Manual Frenchxp pen fr Uploads images manual decoseries all Deco French |||


Introduction Merci d avoir choisi la tablette stylet de la srie XPPen Deco. Ce manuel de l utilisat ... utiliser le stylet 2 pour contrler le curseur. 2. Connexion sans fil uniquement pour Deco LW et Deco MW A. Connexion via un rcepteur sans fil Branchez le rcepteur sans fil sur votre ordinateur et...

lang:fr score:24 filesize: 1.42 M page_count: 30 document date: 2023-09-18




[pdf] Borchure

Deco M MW EN final 2022 Brochure Buy XPPen Artist 10 2nd Gen Display Tablet 1 inch Pen with tilt Support 6 Shortcut Keys 8192 Levels of Pressure Sensitivity X3 Elite Stylus Fully Laminated Green Online at Low Prices in India XP PEN Reviews Ratings B1BIPyLnAQL m media amazon images I ||| Deco M MW New Deco, innovative drawing tablet with X3 chip stylus X3 smart chip stylus Sharp Sta ... ection 1000mAh super power capacity for ultra-long standby Equipped with a Bluetooth v5.0 chip, the Deco MW drawing tablet frees you to create without the limitation of cables, allowing you to keep yo... lang:en score:21 filesize: 2.36 M page_count: 2 document date: 2022-07-19



[pdf]

Tencent 1132787 bhphotovideo lit files ||| Introduction r, check that you can use the stylus to control the cursor. 2. Wireless connection for Deco LW and Deco MW only 3 A. Connect via Wireless receiver Plug the wireless receiver into your computer and... lang:tl score:12 filesize: 2.06 M page_count: 30 document date: 2024-04-30



[pdf]

Tencent Dodávané s produktom sk ppx 138 vo sunnyssoft ||| vod u skontrolujte, ci mzete na ovdanie kurzora pouzi stylus. 2.Bezdrtov pripojenie iba pre Deco LW a Deco MW 3 A.Pripojenie cez bezdrtov prijmac Zapojte bezdrtov prijmac do portaca a stlacenm a podr... lang:es score:12 filesize: 2.01 M page_count: 30 document date: 2025-02-16