

[Manuals.plus](#) /

› [ZJYWSCH](#) /

› ZJYWSCH Grill Cover for Pit Boss Platinum Brunswick Wood Pellet Vertical Smoker Instruction Manual

ZJYWSCH WC028

ZJYWSCH Grill Cover Instruction Manual

For Pit Boss Platinum Brunswick Wood Pellet Vertical Smoker

INTRODUCTION

Thank you for choosing the ZJYWSCH Grill Cover. This heavy-duty, weather-resistant cover is specifically designed to protect your Pit Boss Platinum Brunswick Wood Pellet Vertical Smoker from the elements, ensuring its longevity and maintaining its pristine condition. This manual provides essential information on the proper use, installation, and maintenance of your grill cover.



Image: The ZJYWSCH grill cover fully installed on a Pit Boss Platinum Brunswick vertical smoker, showcasing its protective fit.

SAFETY INFORMATION

To ensure the safety and longevity of your grill cover and smoker, please observe the following:

- **Avoid prolonged exposure to extreme conditions:** Do not leave the cover on in heavy rain or prolonged direct sunlight without occasional inspection.
- **Ensure smoker is cool:** Always allow your smoker to cool completely before placing the cover on it to prevent damage to the cover material and potential fire hazards.

- **Dry before storage:** Always remove the cover after use and allow it to dry completely before folding and storing it, especially if it has been exposed to moisture. This prevents mold and mildew growth.

PRODUCT OVERVIEW AND FEATURES

The ZJYWSCH Grill Cover is engineered with premium materials and thoughtful design to provide superior protection for your Pit Boss Platinum Brunswick Vertical Smoker.

- **Heavy-Duty 600 Denier Polyester:** Constructed from a robust, water-resistant 600 Denier polyester material, designed to withstand various outdoor elements and protect your smoker from damage.
- **Velcro Straps:** Equipped with adjustable Velcro straps on both sides to ensure a snug and custom fit, preventing the cover from blowing off or flapping during windy conditions.
- **Smooth Waterproof Zipper:** Features a waterproof zipper that helps prevent water leakage, complemented by an interior PVC liner to protect against tearing during installation or removal.
- **All-Weather Resistance:** Made with a polyester PVC blend that offers comprehensive protection against harsh temperature extremes and various weather events, keeping your patio pellet smoker in excellent condition.
- **Easy to Clean:** The material is designed for easy cleaning. Simply wipe with a damp cloth or hose down with water to remove dirt, then allow it to air dry.

Water Resistant



Image: Close-up view of the water-resistant fabric, showing water droplets beading on the surface.

Waterproof Zipper



Image: Detail of the smooth, waterproof zipper, designed to prevent leaks and ensure durability.

Velcro Straps



Image: View of the adjustable Velcro straps, providing a secure and custom fit around the smoker's base.

Fit Grill Chimney



Image: The top of the cover designed to fit snugly around the smoker's chimney, ensuring full coverage.

SETUP AND INSTALLATION

Follow these steps to properly install your ZJYWSCH Grill Cover:

1. **Ensure Smoker is Cool:** Before placing the cover, make sure your Pit Boss Platinum Brunswick Vertical Smoker is completely cool and free of any hot spots.
2. **Clean Smoker Surface:** Wipe down the exterior of your smoker to remove any dust, debris, or food residue. This prevents dirt from being trapped under the cover.
3. **Unfold the Cover:** Carefully unfold the grill cover.
4. **Position the Cover:** Begin by placing the top of the cover over the smoker's chimney and top section.
5. **Slide Down:** Gently pull the cover down over the sides of the smoker, ensuring it aligns with the smoker's contours. The zipper on the side allows for easier placement.
6. **Secure Straps:** Once the cover is fully in place, fasten the Velcro straps located on both sides at the bottom. Adjust them for a snug fit to prevent the cover from shifting or being blown away by wind.

GRILL COVER SIZE

For Pit Boss Platinum Brunswick Pellet Vertical Smoker



Image: A visual representation of the grill cover's intended fit over the Pit Boss Platinum Brunswick Vertical Smoker.

OPERATING AND USAGE

Using your grill cover is straightforward, but proper handling ensures its effectiveness and longevity:

- **Daily Use:** Place the cover on your smoker whenever it is not in use, especially overnight or during periods of inclement weather.
- **Removing the Cover:** Unfasten the Velcro straps and gently pull the cover upwards and off the smoker. You may use the side zipper to facilitate removal.
- **Storage When Not in Use:** If you need to store the cover for an extended period, ensure it is clean and completely dry. Fold it neatly and store it in a cool, dry place away from direct sunlight.



Image: Two Pit Boss vertical smokers protected by ZJYWSCH grill covers on an outdoor patio, demonstrating typical usage.

MAINTENANCE AND CARE

Proper maintenance will extend the life of your grill cover:

- **Cleaning:** For light dirt, simply wipe the cover with a damp cloth. For heavier soiling, hose it down with water. Avoid using harsh detergents or abrasive brushes, as these can damage the material's protective coating.
- **Drying:** After cleaning or exposure to rain, allow the cover to air dry completely before folding or storing. This prevents mildew and odors.
- **Inspection:** Periodically inspect the cover for any signs of wear, tears, or damage. Address minor issues promptly to prevent them from worsening.
- **Storage:** When not in use for extended periods, store the cover in a dry, shaded area to protect it from prolonged UV exposure, which can degrade the material over time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cover blows off in wind.	Velcro straps not secured or not tightened sufficiently.	Ensure Velcro straps are fully fastened and adjusted snugly around the smoker's base.
Water pooling on top of cover.	Improper fit or sag in the cover.	Ensure the cover is pulled taut and evenly distributed. If pooling persists, consider placing a small object (e.g., a ball) under the cover to create a peak for water runoff.
Cover tearing or degrading prematurely.	Prolonged exposure to harsh UV rays or sharp edges on the smoker.	Minimize prolonged direct sunlight exposure if possible. Ensure no sharp edges on the smoker are rubbing against the cover. Follow proper storage guidelines when not in use.
Mildew or mold growth.	Cover stored wet or in a damp environment.	Always ensure the cover is completely dry before folding and storing. Clean any mildew with a mild soap and water solution, then thoroughly dry.

SPECIFICATIONS

Attribute	Detail
Brand	ZJYWSCH
Model Number	WC028
Compatible Grill Models	PIT BOSS PBVER5000PL10577 (Pit Boss Platinum Brunswick Wood Pellet Vertical Smoker)
Material	600 Denier Polyester, Polyvinyl Chloride (PVC) blend
Color	White
Closure Type	Zipper, Velcro Straps
Product Dimensions	9 x 9 x 2 inches (packaged)
Item Weight	3.07 pounds
UPC	735209759946

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ZJYWSCH Grill Cover, please contact the manufacturer directly. While specific warranty details are not provided in this manual, ZJYWSCH is committed to customer satisfaction. You can visit the official ZJYWSCH store for more information and contact options:

Visit ZJYWSCH
Store

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question